

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
Fee	
7. Unit Agreement Name	
Lindrith Unit	
8. Farm or Lease Name	
Lindrith Unit	
9. Well No.	
97	
10. Field and Pool, or Wildcat	
S. Blanco P.C.	
12. County	
Rio Arriba	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator
El Paso Exploration Company
3. Address of Operator
Box 289, Farmington, New Mexico 87401
4. Location of Well
UNIT LETTER <u>L</u> , <u>1800</u> FEET FROM THE <u>South</u> LINE AND <u>1110</u> FEET FROM
THE <u>West</u> LINE, SECTION <u>9</u> TOWNSHIP <u>24-N</u> RANGE <u>2-W</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)
7197' GL

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Move on location and rig up. Attempt packer removal and pull 1 1/4" tubing. Remove packer from tubing and run 3200' tubing and circulate. Spot 10 sacks of cement over perforations and displace 5 sacks into perforations leaving a cement plug from 3443' to 3100' covering Fruitland top. Perforate w/2 shots at 2850', 50' below Ojo Alamo top (2775'). Spot 40 sacks cement plug to cover Ojo and squeeze 35 sacks through perforations leaving plug from 2850' to 2515'. Perforate w/2 shots at 200' and spot 65 sacks cement plug from 200' to 50'. Spot 10 sacks cement plug in surface tubing and set P/A marker.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED FRANK T. CHAVEZ TITLE Production Engineer DATE May 15, 1982
APPROVED BY Original Signed by FRANK T. CHAVEZ TITLE SUPERVISOR DISTRICT 3 DATE MAY 21 1982
CONDITIONS OF APPROVAL, IF ANY: