

NO. OF COPIES RECEIVED	5
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.S.S.	
LAND OFFICE	
OPERATOR	3

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Revised Old
C-102 and C-103
Effective 1-1-75

3a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
3b. State Oil & Gas Lease No.	LG -0492, L-6545

SUNDRY NOTICES AND REPORTS ON WELLS	
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - "A" (FORM C-101) FOR SUCH PROPOSALS.	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Tenneco Oil Company	8. Farm or Lease Name Monument
3. Address of Operator 1860 Lincoln St., Suite 1200, Denver, Colorado 80203	9. Well No. #2
4. Location of Well UNIT LETTER D 800 FEET FROM THE North LINE AND 800 FEET FROM THE West LINE, SECTION 16 TOWNSHIP 24N RANGE 10W N.M.P.M.	10. Field and Pool, or Wildcat Undesignated Dakota
15. Elevation (Show whether DF, RT, GR, etc.) 6797' GR	12. County San Juan

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon this well as follows:

1. MIRU (tbg. & pkr. have already been removed)
2. GIH w/cement retainer and set @ 5800'.
3. Pump into perfs to insure adequate rate for cementing. Squeeze perfs w/90 sacks of cement. Pull out of cement retainer and spot 10 sacks of cement on top of retainer.
4. Spot 25 sacks cement plugs @ each: 4200' - 4000'; 2200' - 2000'; 465' - 265'.
5. Cut off well head @ or near bottom of cellar.
6. Spot surface plug from 30' - surface.
7. Install dry hole marker, fill pits, level location and clear all junk off location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____ TITLE Div. Production Manager DATE _____

APPROVED BY AR Kendrick TITLE SUPERVISOR DIST. #3 DATE AUG 12 1976

CONDITIONS OF APPROVAL, IF ANY: