submitted in lieu of Form 3160-5

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

Sundry Not:	ices and Reports on Wells		
	DEGEIVEM	5.	Lease Number Contract #150
1. Type of Well GAS	00 OCT 1 3 1999 W	6.	If Indian, All. or Tribe Name Jicarilla Apache
	OYE, CORL DIW.	7.	Unit Agreement Name
2. Name of Operator	7.7% G		-
BURLINGTQN	Birth Lindbyge dae		
RESOURCES OIL	& GAS COMPANY		
		8.	
3. Address & Phone No. of Operator PO Box 4289, Farmington, NM 87499 (505) 326-9700		۵	Jicarilla 150 #5M API Well No.
PO BOX 4289, Farmington, NM	8/499 (505) 326-9/00	э.	30-039-23018
4. Location of Well, Footage, S	ec., T, R, M	10.	Field and Pool
1815'FNL, 1850'FWL, Sec.12, T-26-N, R-5-W, NMPM			Blanco MV/Basin DK
		11.	County and State
			Rio Arriba County, NM
12. CHECK APPROPRIATE BOX TO IN	DICATE NATURE OF NOTICE, REPORT, O	OTHER	DATA
Type of Submission	Type of Action		
X Notice of Intent	Abandonment Change of		
a.lh. Barrant	Recompletion New Cons		
Subsequent Report	Plugging Back Non-Rout Casing Repair Water Si		Fracturing ff
Final Abandonment	Altering Casing Convers		
	X Other - Commingle		3
13. Describe Proposed or Comp	leted Operations		
It is intended to comming	le the subject well according to	the a	ttached procedure.
			2 2
			70
14. I hereby certify that the	foregoing is true and correct.		E E
Signed July Madhie	Title Regulatory Administra		ate 6/1799
(This space for Federal or Stat	e Office use)		
APPROVED BY	Silmit allocation form	te 🟒	10 /7/59
CONDITION OF APPROVAL, if any:	S. Emit allow tion form.	1- /	100pg of
	rson knowingly and willfully to make to any department or a		the United States any false
Title 18 U.S.C. Section 1001, makes it a crime for any perfectious or fraudulent statements or representations as to		Series OI	uge Office States any taise,

Jicarilla 150 #5M

Mesa Verde/Dakota AIN: 3593701 and 3593702 1815' FNL & 1850' FWL Unit F, Sec. 12, T26N, R5W

Latitude / Longitude: 36° 30.2096'/ 107° 18.7363'

Recommended Commingle Procedure

Project Summary: The Jicarilla 150 #5M is a dual Mesa Verde/Dakota well completed in 1982. We plan to commingle this well and install a plunger lift in order to keep the well unloaded. This well has not been pulled since completion.

- 1. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
- MOL and RU workover rig. Conduct safety meeting for all personnel on location. NU relief line. Blow down well and kill with 2% KCl water as necessary. ND wellhead and NU BOP. Test and record operation of BOP rams. Have wellhead and valves serviced at machine shop to convert to a single string wellhead (2-3/8"). Test secondary seal and replace/install as necessary.
- 3. Set a plug with wireline in the 1.81" ID SN (8227') on the Dakota tubing. TOOH laying down the 2-3/8", 4.7#, EUE Mesa Verde tubing (set at 6112') with a mud anchor, bull plug and perf sub on bottom.
- 4. Release seal assembly from the Model D Packer with straight pickup (no rotation required). Seal assembly was set with 10,000# of compression on top of the packer. If seal assembly will not come free, then cut 2-3/8" tubing above the packer and fish with overshot and jars. TOOH with 2-3/8", 4.7#, EUE Dakota tubing (set at 8268'). Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
- 5. PU and TIH with Model CK packer retrieval spear (PRS, with holes drilled near rotary shoe), rotary shoe, drain sub, top bushing, bumper sub, jars, and 4-6 drill collars on 2-3/8", 4.7#, J-55, EUE tubing. Mill out Model D packer at 6330' with air/mist. Note: when using air/mist, the minimum mist rate is 12 bph. Try to maintain air rate at 1,400 cfm. A hydrocarbon stable foamer should be utilized since this well makes significant amounts of condensate. After milling over the packer slips, POOH with tools and packer body.
- 6. TIH with 6-1/8" bit and cleanout to PBTD at +/- 8360'. TOOH with tubing.

- 7. TIH with one joint of 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off bottom. Broach all tubing and land at approximately 8300'. ND BOP and NU single string wellhead (2-1/16" master valve). Pump off expendable check and blow well in. Return well to production.
- 8. Production Operations will install plunger lift.

Recommended:

Operations Engineer

Approval:

Drilling Superintengent 5.71.99

Contacts:

Operations Engineer

Tim Friesenhahn 326-9539 (Office)

324-7031 (Pager)

Production Foreman

Ward Arnold 326-9846 (Office)

326-8340 (Pager)