

1963)

UNITED STATES DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

Instructions on reverse side

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. SF-079395	
2. NAME OF OPERATOR Frank E. Elliott		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR Box 1355, Roswell, New Mexico 88201		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 990' From S line & 1980' From W line of Section		8. FARM OR LEASE NAME Elliott C - Fed	
14. PERMIT NO.		9. WELL NO. 1	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 6792 Ground		10. FIELD AND POOL, OR WILDCAT East Bisti	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 34-25N-10W	
		12. COUNTY OR PARISH San Juan	
		13. STATE New Mexico	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is intended to plug and abandoned this well in the following manner:

1. Pull tubing, pump & rods.
2. Pump a cement plug from T.D. to 5250. (Perfs 5349-68; 5382-97) T.D. 5420.
3. Perforate 1 hole at 4500'. Set packer at 4300' & pump plug from 4500' to 4300' - inside & outside of casing.
4. Perforate 1 hole at 1800'; Set packer at 1500' & pump plug from 1800' to 1500' - inside & outside of casing.
5. Cut 5-1/2" 14# casing at 1500' and pull.
6. Set cement plug 50' in casing stub up to 150' above stub.
7. Set plug 450' to 200'. (50' in surface pipe)
8. Set 10' plug at surface.
9. Install 4" pipe marker 4' high with well name & location thereon.
10. Clean location.

RECEIVED

FEB 26 1979

U. S. GEOLOGICAL SURVEY
FARMINGTON, N. M.



18. I hereby certify that the foregoing is true and correct

SIGNED Harvey H. Hanning TITLE Agent DATE 2-22-79

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

7770CC