

DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

(Print legibly on the reverse side)

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL  GAS WELL  OTHER

2. NAME OF OPERATOR  
**Elliott Oil Company**

3. ADDRESS OF OPERATOR  
**P. O. Box 1355 Roswell, New Mexico 88201**

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)  
At surface  
**Unit F-SE 1/4 NW 1/4 Sec. 30, T26N-R13W**  
**(1980' from North & 2520' from West lines of Section)**

14. PERMIT NO. \_\_\_\_\_ 15. ELEVATIONS (Show whether DF, RT, GR, etc.)  
**6512 Gr.**

5. LEASE DESIGNATION AND NUMBER  
**SF 080402**

6. IF INDIAN, ALLOTTEE OR TRIBE NAME \_\_\_\_\_

7. UNIT AGREEMENT NAME \_\_\_\_\_

8. FARM OR LEASE NAME  
**CM&W**

9. WELL NO.  
**2**

10. FIELD AND POOL, OR WILDCAT  
**West Bisti**

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
**Sec. 30-T26N-R13W**

12. COUNTY OR PARISH  
**San Juan**

13. STATE  
**N. Mex.**

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETE

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON\*

SHOOTING OR ACIDIZING

ABANDONMENT\*

REPAIR WELL

CHANGE PLANS

(Other)


(Other) \_\_\_\_\_

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

This well was plugged & abandoned as follows:

1. Pumped cement plug from PBTD. 5359' to 5100'.
2. Filled CSNG. w/ heavy mud from 5100' to 1540'.
3. Perforated 4 holes at 1540' and squeezed 35 sacks cement into formation leaving 50' cement in casing.
4. Filled hole with heavy mud from 1490' to 450'.
5. Perforated 4 holes at 450' and squeezed 35 SKS cement into OJO Alamo formation, leaving 50' cement in CSNG.
6. Pumped 10 SKS cement in 5 1/2" CSNG, from 150' to 60'.
7. Pumped 40 SKS. cement down surface CSNG.
8. Put cement plug at surface in 5 1/2" production CSNG. and 10 3/4" surface CSNG.
9. Cut off surface CSNG and 5 1/2" CSNG. 4' below grd. level.
10. Welded steel plate across top of surface casing.
11. Cleaned location.



18. I hereby certify that the foregoing is true and correct

SIGNED \_\_\_\_\_

TITLE \_\_\_\_\_

DATE \_\_\_\_\_

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_

TITLE \_\_\_\_\_

DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: