

submitted in lieu of Form 3160-5

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

1. Type of Well  
GAS
2. Name of Operator  
**BURLINGTON**  
**RESOURCES** OIL & GAS COMPANY
3. Address & Phone No. of Operator  
PO Box 4289, Farmington, NM 87499 (505) 326-9700
4. Location of Well, Footage, Sec., T, R, M  
660' FNL, 660' FEL, Sec. 3, T-26-N, R-9-W, NMPM
5. Lease Number  
SF-078135
6. If Indian, All. or  
Tribe Name
7. Unit Agreement Name  
Huerfanito Unit
8. Well Name & Number  
Huerfanito Unit #71
9. API Well No.  
30-045-06076
10. Field and Pool  
Basin Dakota
11. County and State  
San Juan Co, NM

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment

Type of Action

- ☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☒ Other - Tubing repair
- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut off  
☐ Conversion to Injection

13. Describe Proposed or Completed Operations

It is intended to repair the tubing on the subject well according to the attached procedure.

RECEIVED  
MAY 1 1998  
OIL COM. DIV.  
DIST. C

14. I hereby certify that the foregoing is true and correct.

Signed *Donne W. Spencer* Title Regulatory Administrator Date 4/29/98  
VKH

(This space for Federal or State Office use)

APPROVED BY *AS/ Donne W. Spencer* Title \_\_\_\_\_ Date MAY - 8 1998

CONDITION OF APPROVAL, if any:

**Huerfanito Unit No. 71**  
**Basin Dakota Field**  
**660' FNL, 660' FEL**  
**Unit A, Section 3, T-26-N, R-09-W**  
**Latitude / Longitude: 36° 31.35' / 107° 46.13'**  
**DPNO: 30037**  
**Tubing Repair Procedure**

**Project Summary:** The Huerfanito Unit No. 71 is a Dakota producer drilled in 1951. The tubing in this well has not been pulled since 1962. The well currently is producing 68 mcf/d and is experiencing liquid loading. We propose to pull and inspect the tubing, install a plunger lift system and return the well to production.

1. Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. **Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS.** Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
2. MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
3. Release donut and pick up additional joints of tubing and tag bottom. (Record depth.) TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
4. If casing requires clean out, TIH with bit and bit sub and CO to PBTD prior to running casing scraper. Roundtrip casing scraper and bit to below perforations. (Do not clean out with casing scraper.) PU above perforations and flow the well naturally, making short trips for clean up when necessary. TOOH.
5. TIH with 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off bottom. Rabbit all tubing.
6. Land tubing near 6650'. ND BOP and NU wellhead. Pump off expendable check. Obtain final pitot gauge up the tubing. If well will not flow on it's own, make swab run to seating nipple. If a swab run is not necessary, run a broach on slickline to ensure that the tubing is clear. RD and MOL. Return well to production.

Recommended: *Kevin Midkiff* 4/22/98  
Operations Engineer

Approved: *Bruce D. Bony* 4/27/98  
Drilling Superintendent

Kevin Midkiff Office - (326-9807)  
Pager - (564-1653)

Production Foreman Office - (326-9560)  
Steve Florez Pager- (327-8346)