

5 NMS, Fmn

1 Ladd, Midland  
1 File

1 Ladd, DE

1 T Jones

Form Approved.  
Budget Bureau No. 42-R1424

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 3-331-C for such proposals.)

1. oil ☐ gas ☒ other ☐

2. NAME OF OPERATOR  
Ladd Petroleum Corp.

3. ADDRESS OF OPERATOR  
830 Denver Club Bldg., Denver CO 80202

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 875 FNL - 1810 FWL  
AT TOP PROD. INTERVAL:  
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐  
FRACTURE TREAT ☐  
SHOOT OR ACIDIZE ☐  
REPAIR WELL ☐  
PULL OR ALTER CASING ☐  
MULTIPLE COMPLETE ☐  
CHANGE ZONES ☐  
ABANDON\* ☒  
(other)

☐  
☐  
☐  
☐  
☐  
☐  
☐  
☐

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

JUN 04 1982

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Plan to plug and abandon the well in the following manner:

1. Set a plug from 6393' (T.D.) to 6084', which is 50' above the Dakota.
2. Set a 100' plug at 5303-5203', which is 50' above and below the Gallup.
3. Perforate and squeeze the Mesaverde at 3182' and set a 100' plug from 3282-3182'.
4. Set a 100' plug at 1755-1655', which is 50' above and below the Pictured Cliffs.
5. Set a 100' plug at 1480-1380', which is 50' above and below the Fruitland.
- \* 6. ~~Perforate and squeeze sufficient amounts of cement to cover the Ojo Alamo and set a 200' plug at 825-625'. (See attached modifications)~~
7. ~~Perforate and squeeze the surface casing shoe at 417' and set plug at 417-317'.~~
8. ~~Set a plug at surface, set P & A marker, cut off anchors, clean up and reseed location.~~

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Terry Jones TITLE Foreman DATE 6-1-82

APPROVED BY \_\_\_\_\_ (space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL IF ANY:

APPROVED


JUN 11 1982

JAMES F. SIMS

AS AMENDED DISTRICT ENGINEER

NMOCC

\*See Instructions on Reverse Side



U. S. GEOLOGICAL SURVEY  
Drawer 600  
Farmington, New Mexico 87499-00600

Attachment to Notice of  
Intention to Abandon

Re: Permanent Abandonment

Well: 1 Knauff B

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases."
2. The Farmington office (telephone (505) 325-4572) is to be notified in sufficient time for a representative to witness all plugging operations.
3. Blowout prevention equipment is required.
4. In addition to normal filling of pits and cleanup of location, additional surface restoration work may be required, i.e. ripping of pad and/or access road, reseeding, etc. We have asked the Bureau of Land Management for the surface restoration requirements for this well and we should be able to furnish you these requirements within 30 days. After plugging the well and before making final clean-up, you should contact this office unless you have already been advised as to what additional surface restoration work is required.
- \* 5. The following modifications to your plugging program are to be made (when applicable):

- a) Perforate 5 1/2" casing at 925' and squeeze cement behind casing to 825' and spot cement plug inside casing from 925' to 825'.
- b) Assign to BLM for water well.



Office Hours: 7:30 A.M. to 4:15 P.M.