Form 3160-5 (August 1999)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0135 Expires: November 30, 2000

5. Lease Serial No. NMSF-078903A

SUNDRY	NMSF-078903A 6. If Indian, Allottee or Tribe Name					
Do not use thi abandoned we						
SUBMIT IN TRI	PLICATE - Other instru	ctions on reverse sideNOV 2	2001	7. If Unit or CA/Agro	ement, Name and/or No	1.
Type of Well Oil Well				8. Well Name and No. GALLEGOS CANYON UNIT 12		
Name of Operator AMOCO PRODUCTION COM	CHERRY HLAVA E-Mail: hlavacl@bp.com		9. API Well No. 30-045-07089			
3a. Address P.O. BOX 3092 HOUSTON, TX 77253		3b. Phone No. (include area code) Ph: 281.366.4081 Fx: 281.366.0700		10. Field and Pool, or Exploratory BASIN FRUITLAND COAL		
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)				11. County or Parish, and State		
Sec 33 T28N R12W Mer NEN	SAN JUAN COUNTY, TX					
				_		
12. CHECK APPI	ROPRIATE BOX(ES) TO	O INDICATE NATURE OF N	OTICE, R	EPORT, OR OTHE	R DATA	
TYPE OF SUBMISSION	TYPE OF ACTION					
Notice of Intent	☐ Acidize	□ Deepen	☐ Production (Start/Resume)		☐ Water Shut-Off	î
	☐ Alter Casing	☐ Fracture Treat	☐ Reclamation		☐ Well Integrity	
☐ Subsequent Report	☐ Casing Repair	☐ New Construction	☐ Recomplete ☐ Other			
☐ Final Abandonment Notice	☐ Change Plans	☑ Plug and Abandon	☐ Temporarily Abandon			
	☐ Convert to Injection	Plug Back	☐ Water Disposal			
Attach the Bond under which the wor	ally or recomplete horizontally, rk will be performed or provide l operations. If the operation re pandonment Notices shall be fil	nt details, including estimated starting, give subsurface locations and measure the Bond No. on file with BLM/BIA. sults in a multiple completion or recorded only after all requirements, including	ed and true von Required sunpletion in a	ertical depths of all perting bsequent reports shall be new interval, a Form 316	filed within 30 days 60-4 shall be filed once	

Amoco Production Company requests permission to plug and abandon the subject well as per the attached procedure.

Should you have any technical questions please contact Allen Kutch @281-366-7955. For administrative concerns please contact Cherry Hlava @281-366-4081

For AMOCO PRODUCTION CO	by the BLM Well Information System MPANY, sent to the Farmington sing by Lucy Bee on 09/21/2001 ()					
Namc (Printed/Typed) CHERRY HLAVA	Title AUTHORIZED REPRESENTATIV	E				
Signature	Date 09/20/2001					
THIS SPACE FOR FEDERAL OR STATE OFFICE USE						
Approved By	Title	Date 1/19/01				
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.	Office					

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

SJ Basin Well Work Procedure

Well Name: GALLEGOS CANYON UNIT #12

Version:

Date: SEPTEMBER 19, 2001

Budget:

Repair Type: PLUG & ABANDON

SAP Code:

Objective: P&A WELL

1. TOH and LD rods. TIH and tag PBTD @ 1420'. TOH and strap 1408' 2 3/8".

2. Set cement plugs.

3. Cut off wellhead & install dry hole marker.

Pertinent Information:

Location: T28N-R12W-Sec33

API#: 30-045-07089

County:

San Juan

FlacWell: Engr:

State: New Mexico Horizon: Fruitland Coal

Procedure:

1. Check anchors. MIRU.

- 2. Check and record tubing, casing, and bradenhead pressures.
- 3. Blow down well. If necessary, kill with fresh water.
- 4. Nipple down WH. NU BOPs. Pressure test to 500 psi.
- 5. TOH and LD 5/8" & 7/8" rods. PU and tag PBTD @ 1420'. TOH and strap 1408' of 2 3/8" tbg.
- 6. TIH with tbg open ended to 1420'. Plug #1 (1297' 1420'), balance 24 sx Cl. B cement inside csg. POH, WOC & tag TOC. Top off as needed.
- 7. Pressure test casing to 500 psi for 15 minutes. POH.
- 8. RU wireline and perforate squeeze holes at 184'.
- 9. Plug #2 (0' 184'), mix approximately 74 sx Cl. B. cement to circulate good cement to surface.
- 10. ND BOP & dig cellar. Cut off wellhead and top off casings as needed.

- 11. RD rig. Remove deadmen. Install dry hole marker.
- 12. Restore location as per BLM requirements.