

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ gas ☐ other ☒ Natural Gas Stimulation
well well Experiment PS Test Well

2. NAME OF OPERATOR
U.S. Dept. of Energy/El Paso Natural Gas Co.

3. ADDRESS OF OPERATOR
U.S. DOE, P.O. Box 14100, Las Vegas, NV 89114

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
1430' FSL, 1636' FWL, Sec. 36,
AT SURFACE: T-29-N, R-4-W
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH: Same as above (Vertical Hole)

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF	<input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>	<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>	<input type="checkbox"/>
(other)		

5. LEASE SE 079701
Carson National Forest

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

9. WELL NO.
GB-3

10. FIELD OR WILDCAT NAME
Choza Mesa Pictured Cliffs

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 36, T-29-N, R-4-W

12. COUNTY OR PARISH
Rio Arriba

13. STATE
New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
KDB-7213', DF-7212', GL-7200'

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Kill well by pumping water down tubing and 7" casing annulus.
2. Nipple up annular BOP and tubing stripper on tubing head, keeping hole full.
3. Pull and inspect 2-3/8" tubing.
4. Go in hole with tubing and spot a cement plug from T.D. (4809') to 3400'. (Inside 7" casing above 4-1/2" liner top.) Tag top of plug with tubing.
5. Circulate 7" casing with water.
6. Perforate interval 600 - 604' with 4 HPF. Circulate water down 7" casing and out 7" x 9-5/8" annulus.
7. Circulate cement in 7" x 9-5/8" annulus to surface. Displace cement inside 7" annulus to 350'. Hold pressure until cement is set. Tag top of cement inside 7" casing w/tubing. Spot surface cement plug from 15' to bottom of cellar. Nipple down tubing stripper and annular BOP.
8. Install a 4" O.D. pipe for well marker extending from 6' below G.L. to 4' above G.L., w/top orange peeled & welded closed. Well name will be inscribed using a welded bead.
9. Cut 9-5/8" & 7" casings @ bottom of cellar. Remove CMP & backfill cellar w/dirt.



NOTE: Above operations are expected to be accomplished between 8-20-78 & 8-31-78.
Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED J. B. Cotten TITLE Dir., E&EA Div. DATE June 12, 1973

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____
CONDITIONS OF APPROVAL, IF ANY:



*See Instructions on Reverse Side

RECEIVED
JUN 19 1978
U. S. GEOLOGICAL SURVEY
DURANGO, COLO.

WELL NO. GB-3
PRESENT CONDITIONS

DEPTH (FT)
0 = GROUND LEVEL




FIGURE 8

WELL NO. GB-3 PROPOSED ABANDONMENT

