

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE\*  
(Other instructions on re-  
verse side)

Form approved  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.  
SF-078931-B (CA#8561)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR  
DUGAN PRODUCTION CORP.

3. ADDRESS OF OPERATOR  
P.O. Box 420, Farmington, NM 87499

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface  
2130' FNL & 1850' FEL

7. UNIT AGREEMENT NAME  
Central Cha Cha Unit

8. FARM OR LEASE NAME  
Central Cha Cha Unit

9. WELL NO.  
3

10. FIELD AND POOL, OR WILDCAT  
Cha Cha Gallup

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 31, T29N, R13W, NMPM

14. PERMIT NO.

15. ELEVATIONS (Show whether OF, RT, CR, etc.)

5866' GL; 5877' RKB

12. COUNTY OR PARISH  
San Juan

13. STATE  
NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Plan to change plugging procedure due to inability to recover rods and tubing left in hole.

Plan to plug well as follows:

1.) Run cement retainer and set 15' above top of fish (approximately 2175').

2.) Pump 118 cu.ft. class "B" cement below retainer and pull out of retainer.

3.) Spot 30 cu.ft. cement plug 1550-1335' (Pictured Cliffs). (All plugs spotted with 9.2 lb/gal mud).

4.) Spot 30 cu.ft. cement plug 1335-1120' (Fruitland).

5.) Perforate 5-1/2" casing at 270'.

6.) Pump 90 cu.ft. cement down 5-1/2" casing and circulate to surface. Leave 5-1/2" full of cement.

7.) Install dry hole marker and restore location.

18. I hereby certify that the foregoing is true and correct

SIGNED

John Alexander

TITLE

Petroleum Engineer

DATE

10-17-89

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: