



STATE OF NEW MEXICO

ENERGY, MINERALS and NATURAL RESOURCES DIVISION
OIL CONSERVATION DIVISION
AZTEC DISTRICT OFFICE



BRUCE KING
GOVERNOR

ANITA LOCKWOOD
CABINET SECRETARY

1000 RIO BRAZOS ROAD
AZTEC, NEW MEXICO 87410
(505) 334-6178

M-E-M-O-R-A-N-D-U-M (3-94-03)

TO: RAND CARROLL

FROM: Charles Gholson *CG*

SUBJECT: P&A of a well located on Federal Land with the Reclamation Fund, in accordance with the BLM-OCD cooperative agreement for plugging of Federal wells in the State of New Mexico.

DATE: April 12, 1994

Case #9213 was heard before David R. Catanach, October 21, 1987. Order R-8529 was written October 28, 1987. Estimated cost to plug the well and restore the location is \$16,000. The subject well is the Paramount Petroleum Corp., Aztec Totah Unit #7, O-20-29N-13W.

CG/cs

xc: Ken Townsend - BLM Farmington
Well Files

WELL INFORMATION AND PLUGGING PROCEDURE

Invitation to Bid No.

The information herein is taken from OCD well files. The bidder is responsible for obtaining all available data including a review of such files, on-site inspection and any other sources.

Failure to review available information will not justify for implementing supplemental rates or contract modification or

OPERATOR	PARAMOUNT PETROLEUM CORP			
WELL NAME	AZTEC TOTAH UNIT #7			
LOCATION	0 unit	20 sec.	29N township	13W range
FOOTAGE	660/S	1980/E		
COUNTY	SAN JUAN			

termination.

SUMMARY WELL DATA

SURFACE CASING: 8 5/8 @ 192' w/170 sacks

INTERMEDIATE CASING: N/A

PRODUCTION CASING: 4 1/2 10.5# @ 5362 w/400 sacks in 2 stages

TUBING: 2 3/8 @ 5312

OTHER INFORMATION: 7 7/8" hole-DV tool @ 1443

PLUGGING PROCEDURE

including site preparation and cleanup

1. Install anchors and prepare location. Some road work may be necessary.
2. Rig up service unit. Kill well if necessary. Nipple down wellhead. Nipple up BOP and stripper head.
3. Pull and lay down rods and tubing.
4. Go in hole with work string to PBTD @ 5331'. Set a cement plug 5331-5180'. WOC 4 hours and tag up. If plug is in place, go to Step 5. If not, fill to 5180'.
5. Roll hole with 8.4 lb 40 viscosity mud.
6. Perforate casing at 2800'. Set a cement retainer @2650' and spot a cement plug 2650-2800' in and outside casing. Sting out of retainer and dump 2 sacks on top.
7. Set a cement plug 1100-1250' inside casing.
8. Perforate casing @ 242' and circulate cement to surface up the Bradenhead.
9. Install marker, fill pits, clean, level and restore location in accordance with BLM regulations.