

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/ ✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
El Paso Natural Gas Company		San Juan 31-6 Unit
3. Address of Operator		9. Well No.
Box 990, Farmington, New Mexico - 87401		2
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER M, 990 FEET FROM THE South LINE AND 990 FEET FROM		Blanco Mesa Verde
THE West LINE, SECTION 28 TOWNSHIP 31N RANGE 6W NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
6469' GL		Rio Arriba

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Because of non-production it is planned to plug and abandon this well as follows:

Pull tubing, run perforating gun, shoot 4 holes in the casing opposite the base of the Ojo Alamo (2581').

Run tubing, spot 100 sack cement plug on bottom, come up the hole, spot 50 sack plug at 2581', and squeeze. Pull tubing.

Determine free point of 7" casing by stretch method, shoot casing off above the freepoint, spot a 50 sack cement plug on the casing stub by displacing cement down the freed casing, pull casing.

Spot a 25 sack cement plug at the base of the surface casing.

Place a 10 sack plug at the surface and install a dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed By:

SIGNED Donald R. Read

TITLE Petroleum Engineer

DATE 10-3-69

APPROVED BY

*A. R. Hendrich*

TITLE PETROLEUM ENGINEER DIST. NO. 3

DATE OCT 6 1969

CONDITIONS OF APPROVAL, IF ANY: