

NO. OF COPIES RECEIVED	6
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	2
LAND OFFICE	
OPERATOR	2

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
		5. State Oil & Gas Lease No.
1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator EM & NS		8. Farm or Lease Name Brown
3. Address of Operator c/o Halliburton Co., P. O. Box 960, Farmington, N. M. - 87401		9. Well No. 1
4. Location of Well UNIT LETTER 1 , 2316 FEET FROM THE South LINE AND 230 660 FEET FROM THE East LINE, SECTION 30 TOWNSHIP 30N RANGE 12W NMPM.		10. Field and Pool, or Wildcat Fulcher Kutz-P. C.
15. Elevation (Show whether DF, RT, GR, etc.)		12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

T. D. 1735'.

5 1/2" casing set at 1647' w/50 sacks of cement.

10" casing set at 40'

Est. Base OJO Alamo 350'.

Propose to plug and abandon well as follows:


Run tubing to total depth and spot a 50 sack cement plug (est. top of plug will be 1400').

Perforate 4 holes below Ojo Alamo at 400' (est. base of Ojo Alamo is 350').

Spot 50 sacks of cement over perforations and squeeze approximately 25 sacks into the perms by pumping into the casing.

Remove wellhead, surface casing flange, and 5 1/2" casing slips.

Place a 20 sack plug at the surface, install a dry hole marker.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Raymond H. Luna TITLE President, San Juan Country Club DATE 4-25-69

APPROVED BY Ernest C. Cline TITLE Sgt. Dist. III DATE 4-25-69

CONDITIONS OF APPROVAL, IF ANY: