

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I

P.O. Box 1980, Hobbs NM 88241-1980

DISTRICT II

P.O. Drawer DD, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

2040 Pacheco St.
Santa Fe, NM 87505

WELL API NO. 30-045-23663
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Jacquez
8. Well No. 2
9. Pool name or Wildcat Blanco Pictured Cliffs Extension

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	
2. Name of Operator Taurus Exploration, U.S.A., Inc.	
3. Address of Operator 2198 Bloomfield Highway; Farmington, NM 87401	
4. Well Location Unit Letter <u>G</u> <u>1730</u> Feet From The <u>North</u> Line and <u>1380</u> Feet From The <u>East</u> Line Section <u>30</u> Township <u>30N</u> Range <u>R8W</u> NMPM <u>San Juan</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 5714 GL	

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is intended to plug and abandon this well as follows:

- 1) Fill casing to surface with 75 sxs. class B cement displace to 300 feet.
- 2) Perforate 2 squeeze holes @ 175 feet.
- 3) Squeeze cement bradenhead with 60 sxs. class B cement, circulate to surface.
- 4) WOC. Tag cement inside of casing. Fill to surface.
Cut off wellhead and install dry hole marker, restore location.

RECEIVED
DEC 30 1997
OIL CON. DIV.
DIST. 3

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE Production Superintendent DATE 12/30/97
TYPE OR PRINT NAME _____ TELEPHONE NO. _____

(This space for State Use)

APPROVED BY Johnny Robinson TITLE DEPUTY OIL & GAS INSPECTOR, DIST. #3 DATE DEC 30 1997
CONDITIONS OF APPROVAL, IF ANY: _____

NOTIFY AZTEC OCD
IN TIME TO WITNESS [Signature]

4 549 prior to 12-30-97

OPERATOR <i>Taurus Exploration</i>		PROPERTY NAME <i>Jacquez</i>	WELL NO. <i>2</i>
DATE <i>12-23-97</i>	LOCATION ULSTR <i>G-30-30N-08W</i>	FOOTAGE <i>1730FNL & 1380FEL</i>	
API NO. <i>30-045-23663</i>		POOL <i>5714 GL</i>	<i>Blanco PC Ext.</i>

<i>Ojo Alamo - 1380'</i> <i>Kirtland - 1448'</i> <i>Fruitland - 2103'</i> <i>Pictured Cliffs - 2417'</i> <i>T.O.C. 950'</i>	
---------------------------------------------------------------------------------------------------------------------------------------------	--

1. Test $2\frac{7}{8}$ csg.
2. Displace cement to appx. 300'
3. Test Tbg.
4. Perforate @ 174'
5. Circulate cement to the surface