

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TWO COPIES
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.5. LEASE DESIGNATION AND SERIAL NO.
Ute Mtn. Tribal Contract
14-20-604-82

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Ute Mtn. Tribe of Indians

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Ute-Indian

9. WELL NO.

10

10. FIELD AND POOL, OR WILDCAT

Verde Gallup11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA**20-31N-14W N.M. PM**

12. COUNTY OR PARISH

San Juan

13. STATE

New Mexico**SUNDRY NOTICES AND REPORTS ON WELLS**
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT-" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Empire State Oil Company

3. ADDRESS OF OPERATOR

Box 871 Thermopolis, Wyoming4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface**660' FSL & 660' FEL Sec. 20-T31N-R14W**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5623 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETION ☐ABANDON* ☐CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☒(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting and proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The above well was plugged and abandoned as follows:

1. Set bottom plug - 23 sacks cement - across open hole section and up into 4-1/2" casing to 3100'.
2. Shot off and pulled 4-1/2" casing at lowest free point - 1400'.
3. Filled 4-1/2" casing with mud.
4. Set 20 sack cement plug across casing stub 1300-1500'.
5. Set 10 sack cement plug across bottom of surface casing 75' to 125'.
6. Set 10 sack cement plug in top of surface casing.
7. Erected regulation dry hole marker and cleaned location.
8. Well plugged and abandoned on 11-19-66.

18. I hereby certify that the foregoing is true and correct

SIGNED

Thomas E. Fenno

TITLE

EngineerDATE **2-22-67**

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED**MAR 28 1967****E. A. SCHMIDT**
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

