

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.
Ute Mtn. Tribal Contract
14-20-604-82

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Ute Mtn. Tribe of Indians

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Ute-Indian

9. WELL NO.

2-E

10. FIELD AND POOL, OR WILDCAT

Verde Gallup

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

20-31N-14W N.M. PM

12. COUNTY OR PARISH 13. STATE

San Juan

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Empire State Oil Company

3. ADDRESS OF OPERATOR

Box 871 Thermopolis, Wyoming

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980' FSL & 1980' FWL Sec. 20-T31N-R14W

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5657 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☐

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐


ABANDONMENT* ☒

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The above well was plugged and abandoned as follows:

1. Set bottom plug - 17 sacks cement - across open hole section and up into 5-1/2" casing to 2900'.
2. Filled casing with mud.
3. Shot off and pulled 5-1/2" casing at lowest free point - 1480'.
4. Set 22 sack cement plug across casing stub 1400-1500'.
5. Set 15 sack cement plug across bottom of surface casing 100-150'.
6. Set 10 sack cement plug in top of surface casing.
7. Erected regulation dry hole marker and cleaned location.
8. Well plugged and abandoned 1-12-67.



U. S. GEOLOGICAL SURVEY
BUREAU OF OIL & GAS

18. I hereby certify that the foregoing is true and correct

SIGNED

Thomas E. Fenno

TITLE **Engineer**

DATE **2-22-67**

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED

MAR 28 1967

E. A. SCHMIDT
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

St

