

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TWO
(Other instruct.
verse side)DATE
on re-Form approved.
Budget Bureau No. 42-R1424.5. LEASE DESIGNATION AND SERIAL NO.
Ute Mtn. Tribal Contract
14-20-604-82

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Ute Mtn. Tribe of Indians

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Ute-Indian

9. WELL NO.

1-E

10. FIELD AND POOL, OR WILDCAT

Verde Gallup11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA**20-31N-14W N.M. P.M.**

12. COUNTY OR PARISH

San Juan

13. STATE

New Mexico**SUNDRY NOTICES AND REPORTS ON WELLS**
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Empire State Oil Company

3. ADDRESS OF OPERATOR

Box 871 Thermopolis, Wyoming4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface**1980' FNL & 660' FWL Sec. 20-T31N-R14W**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5643 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING


ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The above well was plugged and abandoned as follows:

1. Set bottom plug - 42 sacks - across open hole section and up into 5½" casing to 2700'.
2. Filled casing with mud.
3. Shot off and pulled 5½" casing at lowest free point - 1250'.
4. Set 20 sack cement plug across casing stub 1200-1300'.
5. Set 12 sack cement plug across bottom of surface casing 90'-140'.
6. Set 10 sack cement plug across top of surface casing.
7. Erected regulation dry hole marker and cleaned location.
8. Well plugged and abandoned 2-16-67.



18. I hereby certify that the foregoing is true and correct

SIGNED

Thomas E. Fenno

(This space for Federal or State office use)

TITLE

EngineerDATE **2-27-67**

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side

APPROVED**MAR 28 1967****E. A. SCHMIDT**
ACTING DISTRICT ENGINEER

