

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE\*  
(Other instruct. on re-  
verse side)

Form approved.  
Budget Bureau No. 42 R1424.  
5. LEASE DESIGNATION AND SERIAL NO.

Ute Mtn. Tribal Contract  
14-25-604-82

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Ute Mtn. Tribe of Indians

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Ute-Indian

9. WELL NO.

8-E

10. FIELD AND POOL, OR WILDCAT

Verde Gallup

11. SEC., T., B., M., OR BLK. AND  
SUEVEY OR AREA

20-31N-14W N.M. P.M.

12. COUNTY OR PARISH 13. STATE

San Juan

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Empire State Oil Company

3. ADDRESS OF OPERATOR

Box 871 Thermopolis, Wyoming

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

660' FNL & 330' FWL Sec. 20-T31N-R14 W

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5647 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING


ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

The above well was plugged and abandoned as follows:

1. Set bottom plug - 18 sacks - across open hole section and up into 4 1/2" casing to 2550'.
2. Filled casing with mud.
3. Shot off and pulled 4 1/2" casing at lowest free point - 200'.
4. Set 16 sack cement plug across casing stub 150'-250'.
5. Set 12 sack cement plug across bottom of surface casing 75'-125'.
6. Set 10 sack cement plug in top of surface casing.
7. Erected regulation dry hole marker and cleaned location.
8. Well plugged and abandoned 2-20-67.



18. I hereby certify that the foregoing is true and correct

SIGNED

Thomas E. Fenno

TITLE

Engineer

DATE 2-27-67

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

MAR 28 1967

E. A. SCHMIDT  
ACTING DISTRICT ENGINEER

\*See Instructions on Reverse Side