

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator PAN AMERICAN PETROLEUM CORPORATION		8. Farm or Lease Name McCoy Gas Unit "A"
3. Address of Operator P. O. Box 480, Farmington, New Mexico		9. Well No. 1
4. Location of Well UNIT LETTER H 990 FEET FROM THE East LINE AND 1910 FEET FROM THE North LINE, SECTION 18 TOWNSHIP -31-N RANGE -10-W NMPM.		10. Field and Pool, or Wildcat Blanco Mesaverde
15. Elevation (Show whether DF, RT, GR, etc.) 5766 (GL)		12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

As a result of gas and water pressure being on the bradenhead, we plan to move in and work-over the McCoy Gas Unit "A" No. 1 as follows:

1. Kill well with water, pull tubing and set bridge plug above Mesaverde pay.
2. Run casing corrosion log and test 7" intermediate casing.
3. Cement off casing leak(s) and/or place cement behind 7" intermediate casing to isolate shallow formation.
4. Clean up well and return to production.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Fred L. Nelson, District Engineer
SIGNED BY **F. H. HOLLINGSWORTH**

SIGNED _____ TITLE _____ DATE **January 20, 1965**

APPROVED BY *Emmye Ames* TITLE *Sgt. Dist. 3* DATE *1-22-65*
CONDITIONS OF APPROVAL, IF ANY: