UNITED STATES EPARTMENT OF THE INTER

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells		
	5.	Lease Number SF-077651
1. Type of Well GAS	6.	
1 1883	7.	Unit Agreement Name
2. Name of Operator BURLINGTON OIL & GAS COMPANY OIL & COMPANY		
OIL & GAS COMPANY ONLY	8.	Well Name & Number
3. Address & Phone No. of Operator PO Box 4289, Farmington, NM 87499 (505) 326-9700	9.	Richardson SRC #2 API Well No. 30-045-10790
4. Location of Well, Footage, Sec., T, R, M	10.	Field and Pool
990'FNL, 1650'FWL, Sec.17, T-31-N, R-12-W, NMPM	11.	Blanco Mesaverde County and State
(5)		San Juan Co, NM
X Notice of Intent Abandonment Change of Recompletion New Constant Casing Repair Water Strain Abandonment Altering Casing Conversion X Other - Tubing Repair	truc ine ut o	tion Fracturing
It is intended to repair the tubing in the subject well according to procedure.	cordi	ng to the attached
		RECEIVED OCT 25 PH 2: 19 O PAGGARAGIA NM
14. I hereby certify that the foregoing is true and correct.		
Signed Title Regulatory Administrato		te 10/22/99
(This space for Federal or State Office use) APPROVED BY /S/JOS Flowith Title Da CONDITION OF APPROVAL, if any:	te .	

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Richardson SRC #2

Mesaverde 990'FNL, 1650' FWL

Unit C, Section 15, T-31-N, R-12-W

Latitude / Longitude: 36° 54.1919' / 108° 5.1636'

DPNO: 6658101 MV Tubing Repair Procedure

- 1. Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
- 2. MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. ND WH and NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
- 3. Mesaverde, 2-3/8" tubing is set at 4912'. Release donut, pick up additional joints of tubing and tag bottom. (Record depth.) PBTD should be at +/-5210'. TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
- 4. If fill is encountered, TIH with 3-7/8" bit, bit sub and watermelon mill on 2-3/8" tubing and round trip to below perforations, cleaning out with air/mist. NOTE: When using air/mist, minimum mist rate is 12 bph. If scale is present, contact Operations Engineer to determine methodology for removing scale from casing and perforations.
- 5. TIH with one joint of 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off bottom then ½ of the 2-3/8" production tubing. Run a broach on sandline to insure that the tubing is clear. TIH with remaining 2-3/8" tubing and then broach this tubing. Replace any bad joints. CO to PBTD with air/mist. PU above the perforations and flow the well naturally, making short trips for clean up when necessary.
- 6. Land tubing at ±5070'. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. Obtain pitot gauge up the tubing. If well will not flow up the tubing, make swab run to SN. RD and MOL. Return well to production.

Recommended: M. F. Hutty
Operations Engineer

Approved:

Bruce Dove 10-15-99
Drilling Superintendent

Operations Engineer:

Mary Ellen Lutey

Office - (599-4052) Home - (325-9387)

Pager - (324-2671)