

GROUND BED ABANDONMENT

WELL NAME: Boyd G.C. #1

LOCATION: SW/SW 58-31N-10W

- 1) Weld 6" dia. spool with diverter line to pit
- 2) MIRU
- 3) Wash in hole with 1 1/4" work string. Circulate out coke breeze. Pull anodes as they come free. Wash hole to TD ~~ft.~~
- 4) Pump * sx of neat cement w/ 1/4 lb. sk. Flocele. Pull out work string.
- 5) Top off hole with cement, set flexible pipeline marker as PxA marker.
- 6) RDMO

Ground Bed Specifications

TD _____ ft.

Hole Dia. _____ inches.

Casing Dia. _____ inches

Casing Length _____ ft.

} UNKNOWN

$$\text{sacks of cement} = (\text{dia.})^2 \times \text{T.D.} \times .00693$$

WHERE dia. = inches,
TD = Feet

JAB.GRA