

GROUND BED ABANDONMENT

WELL NAME: LAWSON LS#1

LOCATION: SE/NE 11-31N-11W

- 1) Weld 6" dia. spool with diverter line to pit
- 2) MIRU
- 3) Wash in hole with 1 1/4" work string. Circulate out coke breeze. Pull anodes as they come free. Wash hole to TD ~~ft.~~.
- 4) Pump * sx of neat cement w/ 1/4 lb. sk. Flocele. Pull out work string.
- 5) Top off hole with cement, set flexible pipeline marker as PxA marker.
- 6) RDMO

Ground Bed Specifications

TD _____ ft.	} UNKNOWN
Hole Dia. _____ inches.	
Casing Dia. _____ inches	
Casing Length _____ ft.	

* sacks of cement = $(dia)^2 \times T.D. \times .00693$
where dia. is in inches,
TD is in feet

JAB.GRA