

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> <b>Federal</b> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator	San Juan 32-8 Unit
3. Address of Operator	8. Farm or Lease Name
Box 990, Farmington, New Mexico - 87401	San Juan 32-8 Unit
4. Location of Well	9. Well No.
UNIT LETTER <u>H</u> , <u>1850</u> FEET FROM THE <u>North</u> LINE AND <u>790</u> FEET FROM	6
THE <u>East</u> LINE, SECTION <u>35</u> TOWNSHIP <u>32N</u> RANGE <u>8W</u> NMPM.	10. Field and Pool, or Wildcat
	Blanco Mesa Verde
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
6606' GL	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.


Because of non-production it is planned to plug and abandon this well as follows:

Spot a 150 sack cement plug on bottom to cover open hole (5468-6060'). Est. top of plug at 5330'.

Determine free point of 7" casing by stretch and shoot off at free point. Spot a 50 sack cement plug over casing stub and pull casing to 200'. Spot a 30 sack cement plug at base of surface casing.

Place a 10 sack cement plug at surface w/a 4' x 4" P & A marker.

Clean location.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Don Reed</u>	TITLE <u>Petroleum Engineer</u>	DATE <u>9-8-69</u>
APPROVED BY <u>Emmy Church</u>	TITLE <u>Sgt. Paul T. III</u>	DATE <u>9-9-69</u>
CONDITIONS OF APPROVAL, IF ANY:		