

State of New Mexico
Energy, Minerals and Natural Resources Department
Oil Conservation Division

Sundry Notices and Reports on Wells

1. Type of Well
GAS

2. Name of Operator

**BURLINGTON
RESOURCES**

OIL & GAS COMPANY

3. Address & Phone No. of Operator

PO Box 4289, Farmington, NM 87499 (505) 326-9700

4. Location of Well, Footage, Sec., T, R, M

1450' FNL, 1190' FWL, Sec. 1, T-31-N, R-13-W, NMPM, San Juan County, NM

API # (assigned by OCD)
30-045-22533

5. Lease Number
Fee

6. State Oil&Gas Lease #

7. Lease Name/Unit Name

Hancock Com

8. Well No.
#1A

9. Pool Name or Wildcat
Blanco Mesaverde

10. Elevation:

Type of Submission

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment

Type of Action

☐ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☒ Other - Tubing Repair

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut off

☐ Conversion to Injection

13. Describe Proposed or Completed Operations

It is intended to repair the tubing in the subject well according to the attached procedure.

RECEIVED
NOV 17 1999

OIL CON. DIV.
DIST. 3

SIGNATURE

John Cole

Regulatory Administrator November 15, 1999

trc

(This space for State Use)

ORIGINAL SIGNED BY CHARLIE T. KIRBY

DEPUTY OIL & GAS INSPECTOR, DIST. 3

NOV 17 1999

Approved by

Title

Date

Hancock Com #1A
Mesaverde
1450'FNL, 1190' FWL
Unit E, Section 1, T-31-N, R-13-W
Latitude / Longitude: 36° 55.9103' / 108° 9.5453'
DPNO: 5001201
Tubing Repair Procedure

1. Hold safety meeting. Comply with all NMOC, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. **Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS.** Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
2. **CAUTION: A PISTON IS IN THE BOTTOM OF THE TUBING STRING.** MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. ND WH and NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
3. Mesaverde, 1-1/2", 2.9# tubing is set at 4640'. RIH w/ wireline and tag for piston. (Wireline records indicate the piston is @ 4579'). Set tubing plug ±5' above piston. Fill tubing with half of its volume w/ 2% KCL water. Release donut, pick up additional joints of tubing and tag bottom. (Record depth.) PBTB should be at +/- 4709'. TOOH laying down tubing. Send tubing to yard for salvage.
4. If fill, TIH with 3-7/8" bit, bit sub and watermelon mill on 2-3/8" tubing and round trip to below perforations, cleaning out with air/mist. **NOTE: When using air/mist, minimum mist rate is 12 bph.** If scale is present, notify Operations Engineer and determine method for removing scale from casing and perforations.
5. TIH with one joint of 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off bottom then 1/2 of the 2-3/8" production tubing. Run a broach on sandline to insure that the tubing is clear. TIH with remaining 2-3/8" tubing and then broach this tubing. Replace any bad joints. CO to PBTB with air/mist. PU above the perforations and flow the well naturally, making short trips for clean up when necessary.
6. Land tubing at ±4640'. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. Obtain pitot gauge up the tubing. If well will not flow on it's own, make swab run to SN. RD and MOL. Return well to production.

Recommended: M.E. Lutey
Operations Engineer

Approved: Dwaine W. Boyer 10-5-99
• Drilling Superintendent

Operations Engineer: Mary Ellen Lutey
Office - (599-4052)
Home - (325-9387)
Pager - (324-2671)