Form 3160-5 (August 1999)

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

FORM APPROVED OMB NO. 1004-0135 Expires: November 30, 2000

6. If Indian, Allottee or Tribe Name

5. Lease Serial No.

/			
M-	ハつつ	117	c
νм-	uz.	ᄔ	0

SUNDRY	NOTICES	AND	REPORTS	ON	WELLS			
o not use this form for proposals to drill or to re-enter an								

Do not use this form for prop ahandoned well. Use Form 3160-3 (APD) for such proposals.

abandoned wen. Goe rom	10100 0 (717 2) 70.	000 proposition 0.11	/: /: !	n/a
SUBMIT IN TRIPLICATE - 0	Other instructions	on reverse side		7. If Unit or CA/Agreement, Name and/or NN/A
1. Type of Well Oil Well X Gas Well Other 2. Name of Operator Marathon Oil Company		Vivi II		N/A 8. Well Name and No. Ohio "F" Government 9. API Well No.
3a. Address P.O. Box 552 Midland, TX 79702 4. Location of Well (Footage, Sec., T., R., M., or Survey L.	ode)	30-045-23000 10. Field and Pool, or Exploratory Area Blanco Mesaverde		
Sec. 20, T-31-N, R-12-W 990' FNL & 1800' FWL U.L. "C" San Juan Co. N.M.	DOV(EQ) TO INI	DICATE NATURE OF NOT	TICE DED	11. County or Parish, State San Juan N.M.
12. CHECK APPROPRIATE TYPE OF SUBMISSION	BOX(ES) TO INC	*****	OF ACTION	
Notice of Intent Subsequent Report Final Abandonment Notice	Acidize Alter Casing Casing Repair Change Plans Convert to Injecti	Deepen Fracture Treat New Construction Plug and Abandon Plug Back	Reclamati	ete Other

Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof lift the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has 13. determined that the final site is ready for final inspection.)

Propose to add new Mesaverde perfs, and stimulate same.

Please see attached procedure for details.



14. I hereby certify that the foregoing is true and correct Name (Printed/Typed)	Title	
Jerry Fletcher	Engineer Tech. Date 8-21-00	
THIS SPACE FOR	FEDERAL OR STATE OFFICE USE	
Approved by 1/4	Title	Date NOV 6 2000
Conditions of approval, if any, are attached. Approval of this notice does a certify that the applicant holds legal or equitable title to those rights in the which would entitle the applicant to conduct operations thereon.	not warrant or Office subject lease	

Title 18 U.S.C. Section 1001, and Title 43 U.S.C. Section 1212, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

District I

District II

State of New Mexico Energy, Minerals & Natural Resources Department

Form C-102 Revised October 18, 1994

Instructions on back

OIL CONSERVATION DIVISION 2040 South Pacheco Santa Fe, NM 87505

Submit to Appropriate District Office State Lease - 4 Copies

Fee Lease - 3 Copies

811 S. 1st Street, Artesia, NM 88210-2834 District III 1000 Rio Brazos Rd., Aztec, NM 87410 District IV 2040 South Pacheco, Santa Fe, NM 87505

¹ API Number

30-045-23000

PO Box 1980, Hobbs, NM 88241-1980

200 MG 24 M 1: 45 AMENDED REPOR

³ Pool Name

Blanco Mesaverde

WELL LOCATION AND ACREAGE DEDICATION PLAT

² Pool Code

72319

⁴ Property	Code		5 Property Name 6 Well Number								
			Ohio "F" Government 1A								
⁷ OGRID	No.								Elevation		
1402	21		Marathon Oil Company G.						3.L. 6000'		
¹⁰ Surface Location											
UL or lot no.	Section	Township	Range	Lot. Idn	Feet from t	he	North/South Line	Feet from the	East/West line County		
"C"	20	31-N	12-W		990	1	North	1800' FWL San Ju			San Juan
	11 Bottom Hole Location If Different From Surface										
UL or lot no.	Section	Township	Range	Lot. Idn	Feet from t	he	North/South Line	ne Feet from the East/West line County			County
12 Dedicated Acres 320 N/2	s ¹³ Join	t or Infill 14	Consolidation	1 Code 15 Or	der No.	-					
NO ALLO	WABLE						NTIL ALL INT APPROVED BY			ON:	SOLIDATED
	<u> </u>	<u> </u>			\			17 OPERA	TOR (CERT	FICATION
								I hereby certify t	hat the i	informatio	n contained herein is
	ŀ	40,	1				`	true and complete	to the l	best of my	knowledge and belief.
		6									
1800'											
7.00		——●					•	1			
							·	_ lu	- 7	letu	tu
								Signature			
l								Jerry Flet	cher		
`								Printed Name	_		ì
							`	Engineer T	ech.		
 								Title			į
	、	\	_ 、	_				Date			
								18 SLIBAE	VOR (СЕВТІ	FICATION
								I hereby certify ti	hat the w	vell locati	on shown on this plat
								was plotted from me or under my	field no supervisi	ites of action, and	ctual surveys made by that the same is true
			l					and correct to the b	best of my	belief.	
			ĺ								
								N/A			
ļ								Date of Survey			
								Signature and Sea	of Profe	ssional Su	rveyer:
	ŀ										1
	ļ										
:	ł										1
			1								į
								Certificate Number			

WORKOVER PROCEDURE

OHIO "F" GOVERNMENT #1A

Kutz Canyon Field 990' FNL & 1800" FWL, Sec. 20, T31N, R12W San Juan County, New Mexico

Date: August 15, 2000

Purpose: Add Menefee Pay

KB: 6012' **GWI: 100%**

TD: 5050' AFE #: AFE Days: 6

NRI: 87.5%

GL: 6000'

PBTD: 5003'

AFE Amount:

Surface Csg:

9-5/8" 36# K-55 @ 217' cmt'd w/ 200 sks (circulated)

Production Csg:

7" 23# K-55 @ 4629' cmt'd w/ 450 sks

[Drift = 6.241]

80% Burst = 3488 psil

Production Lnr:

4-1/2" 10/5# J-55 from 4420' to 5050' cmt'd with 200 sks (circulated)

[Drift = 3.927"

80% Burst = 3832 psi]

Tubing:

~159 jts 2-3/8" J-55 EUE tubing @ 4965' (Note: Top 19 joints may be N-80)

Perforations:

Mesaverde (Point Lookout): 4732'-4943'

Anticipated BHP: ±500 psi in the Point Lookout

±1800 psi (estimated original pressure) in the Menefee

Comments:

1) Use 2% KCl (no substitutes) in all workover fluids

2) Use 3-1/2" 9.3# N-80 tubing (Drift = 2.867", 80% Burst = 8128 psi) as frac string

PROCEDURE

- 1. Inspect location and improve if necessary. Install and test safety anchors to 22,500#.
- 2. MIRU PU. Kill well. ND wellhead. NU 7-1/16" BOP as per Mid-Continent Region's "Workover and Completion Guidelines". Function test BOP. POOH with 2-3/8" production tubing. RIH with a 7" RBP on 2-3/8" production tbg. Set RBP @ ±250'. Test pipe rams to 1500 psi. Release from plug and POOH. Test blind rams to 1500 psi. RIH and pull RBP.
- 3. RIH with 4-1/2" CIBP on production tubing. Set CIBP at ±4650'. RIH with 7" test packer. Set pkr @ ±4170' & pressure test CIBP & TOL to 2000 psi. POOH with packer.
- 4. RU electric line. NU & test lubricator to 1500 psi. Run GR-CCL log and correlate to Schlumberger DIL dated 5/27/78. RIH w/3-1/8" casing guns loaded 1 SPF with premium charges & perforate the Menefee as follows: 4226', 39', 66', 93', 4309', 29', 55', 59', 67', 76', 89', 4417', 27', 66', 4507', 15', 77', 85', 87', and 89' (20 shots). POOH & RD EL.
- 5. Change pipe rams to 3-1/2". RIH with 7" treating packer on 3-1/2" workstring. Hydro-test tubing below slips to 7000 psi. Set packer @ ±250'. Test pipe rams to 1500 psi. Continue testing tubing in hole. Set packer @ ±4150'. Test tubing x casing annulus to 500 psi.
- 6. RU stimulation company. RU for immediate flow back. Hold safety meeting. Test lines to 7000 psi. Break down perfs with 1000 gals 15% FE HCl and 30 Bio-balls. SI for ~1 hour to allow balls to dissolve. Stimulate Menefee perfs as per recommendation @ 40-45 BPM with 80,000# of 20/40 sand. Limit maximum treating pressure to 6000 psi. Flow back well immediately between 1 and 2 BPM. If flow rate is less than ½ BPM then attempt to slowly pump one tubing volume of clean fluid into well and SI until well is dead. RD stimulation company. Continue flowing well until it dies or cleans up.
- 7. Kill well as necessary. RIH with sinker bar and tag sand. Release packer and POOH laying down work string.
- 8. RIH with bit on 2-3/8" tubing. Jet well clean and drill out CIBP @ ±4650'. CO to PBTD. POOH laying down DC's and bit. (Note: Expect gas bubble and/or loss of hydrostatic head when CIBP is drilled out).
- 9. RIH w/ notched collar, mud joint and seating nipple on 2-3/8" production tubing. CO to PBTD @ 5003'. Land EOT @ ±4900'. ND BOP. NU wellhead. Jet or swab well in as necessary. RD PU. Turn well over to production.

XC: D. W. Arnst D. K. Barker M. D. Bidwell J. A. Bucci G. W. Donaghey T. P. Kacir

W. S. Landon R. J. Longmire R. Skinner

Well File