

GROUND BED ABANDONMENT

WELL NAME: Boyd G.C. C#1

LOCATION: NW/NW Sec. 8-31N-10W

- 1) Weld 6 " dia. spool with diverter line to pit
- 2) MIRU
- 3) Wash in hole with 1 1/4" work string. Circulate out coke breeze. Pull anodes as they come free. Wash hole to 220 ft.
- 4) Pump 55 sx of neat cement w/ 1/4 lb. sk. Flocele. Pull out work string.
- 5) Top off hole with cement, set flexible pipeline marker as PxA marker.
- 6) RDMO

Ground Bed Specifications

TD 220 ft.

Hole Dia. 6 inches.

Casing Dia. 7 inches

Casing Length 25 ft.

JAB.GRA