

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease
State ☐ Fee ☒
3. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Southland Royalty Company	8. Farm or Lease Name McDaniel
3. Address of Operator P.O. Drawer 570, Farmington, New Mexico 87499	9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> <u>230</u> FEET FROM THE <u>North</u> LINE AND <u>280</u> FEET FROM THE <u>East</u> LINE, SECTION <u>19</u> TOWNSHIP <u>29N</u> RANGE <u>11W</u> NMPM.	10. Field and Pool, or Wildcat Fulcher Kutz P. C.
15. Elevation (Show whether DF, RT, GR, etc.) 5523' GL	12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐
Revised
PLUG AND ABANDON ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

SOUTHLAND ROYALTY COMPANY hereby proposes to plug and abandon the subject well in the following manner:

- 1) Rig up and pull 1" pipe.
- 2) Establish rate down 3-1/2" casing and pump 80 sacks cement with 3% CaCl₂ (94 cu.ft.). Displace to 510'. Shut in and allow to set.
- 3) Shot squeeze hole at 510'.
- 4) TIH with 2-3/8" work string and squeeze 41 sacks (49 cu.ft.) cement with 3% CaCl₂. Volume is 50% excess to cover Ojo Alamo at 336'.
- 5) Spot 28 sacks (33 cu.ft.) cement inside casing. Volume to fill to surface.
- 6) Pull and lay down tubing.
- 7) Cut off casing and dump cement to fill to surface. Install dry hole marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Petroleum Engineer DATE 10-27-83

APPROVED BY [Signature] TITLE Oil and Gas Division DATE

CONDITIONS OF APPROVAL, IF ANY: