

Submit 1 Copy To Appropriate District Office  
 District I - (575) 393-6161  
 1625 N. French Dr., Hobbs, NM 88240  
 District II - (575) 748-1283  
 811 S. First St., Artesia, NM 88210  
 District III - (505) 334-6178  
 1000 Rio Brazos Rd., Aztec, NM 87410  
 District IV - (505) 476-3460  
 1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico  
 Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION  
 1220 South St. Francis Dr.  
 Santa Fe, NM 87505

WELL API NO. 30-025-31538	✓
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>	
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name RR SIMS, <del>TR</del> "A"	✓
8. Well Number: 2	✓
9. OGRID Number 4323	
10. Pool name or Wildcat TEAGUE SAN ANDRES NORTH	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well  Gas Well  Other

2. Name of Operator  
Chevron USA INC. ✓

3. Address of Operator  
15 Smith Rd. Midland, TX 79705

4. Well Location  
 Unit Letter N : 660 feet from the South line and 1650 feet from the West line  
 Section 4 Township 23S Range 37E NMPM County Lea

11. Elevation (Show whether DR, RKB, RT, GR, etc.)  
3320' GR



12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK  PLUG AND ABANDON   
 TEMPORARILY ABANDON  CHANGE PLANS   
 PULL OR ALTER CASING  MULTIPLE COMPL   
 DOWNHOLE COMMINGLE

OTHER:

INT TO PA AM  
 P&A NR \_\_\_\_\_ P&A R \_\_\_\_\_  
 RBDMS \_\_\_\_\_ TA \_\_\_\_\_

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. Call and notify NMOCD 24 hrs. before operations begin.
2. MIRU. Set CIBP@3900'+25sx of Class "C" cement on top (SA). Circulate hole w/MLF.
3. Spot 25sx Class "C" cement from 2974'-2774' (B.Salt). WOC&TAG.
4. Spot 85sx Class "C" cement 1238'-400' (T.Salt/Shoe). WOC&TAG.
5. Perf and squeeze 110sx Class "C" cement from 350'-surface. (FW/surface). Verify cement to surface.
6. Cut off wellhead. Install dryhole marker.  
Closed loop system to be used on all cement plugs.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE M. Lee Roark TITLE Project Manager DATE 1/29/16

Type or print name M. Lee Roark E-mail address: LRoark@Chevron.com PHONE: (432)-687-7279

**For State Use Only**

APPROVED BY: Mark Whitaker TITLE Petroleum Engr. Specialist DATE 02/01/2016  
 Conditions of Approval (if any):

# R.R. Sims 'A' #2 Wellbore Diagram

API #: 30-25-31538

GL: 3320

KB: 3337

PROPOSED

Perfs 3938' - 4,004'

CIBP @ 4,450' + 35' cmt. on top

Perfs 6485' - 6779'

CIBP @ 7,360' + 52' cmt. on top

7466-71, 77-81, 85-97 [2 jsp/42 holes]

7508-10, 16, 30-34 [2 jsp/14 holes]

Dev.perfs: 7562'-66, 90-98 [2 jsp/24 holes]

Perfand Sqz 350' - surface; 110sx

13.375" 54.5# @ 1150' cmt circ

1238' - 400'; 85sx

2974 - 2774; 25sx

CIBP @ 3,900' + 25sx cmt.

9.625" 40# @ 3750' cmt w/ 1965 sxs

5.5" 17# @ 8780' cmt w/ 2525 sxs

DV @ 7332'

Plug @ 7503' (11-1-93)

PBTD=7545' (Tagged up 10-26-93)

CIBP @ 7554' w/ 5' cmt


PBTD=8755'

CIBP @ 8775' w/ 20' cmt

4 3/4" OH

TOC of 9 5/8" is 1875'  
and then squeezed 400sx  
down 13 3/8" x 9 5/8"

TD=8965'






# R.R. Sims 'A' #2 Wellbore Diagram

CURRENT

API #: 30-25-31538

GL: 3320

KB: 3337



TOC of 9 5/8" is 1875'  
and then squeezed 400sx  
down 13 3/8" x 9 5/8"