State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 5-27-2004

FILE IN TRIPLICATE CEVE DIL CONSERVATION DIVISION	
DISTRICT I 1220 South St. Francis Dr. 1625 N. French Dr., Hobbs, NM 88240/ 10 2010 Santa Fe, NM 87505	WELL API NO. 30-025-37214
DISTRICT II	5. Indicate Type of Lease
1301 W. Grand Ave, Artesia, NHOBBSOCD	STATE FEE X
DISTRICT III 1000 Rio Brazos Rd, Aztec, NM 87410	6. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A	North Hobbs (G/SA) Unit
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (Form C-101) for such proposals.)	Section 31 8 Well No. 632
1. Type of Well: Oil Well Gas Well Other Injector	032
2. Name of Operator Occidental Permian Ltd.	9 OGRID No. 157984
3. Address of Operator	10. Pool name or Wildcat Hobbs (G/SA) ✓
HCR 1 Box 90 Denver City, TX 79323 4. Well Location	
	et From The East Line
Section 31 Township 18-S Range 38-	E NMPM Lea County
11. Elevation (Show whether DF, RKB, RT GR, etc.) 3637' GL	
Pit or Below-grade Tank Application or Closure	
Pit Type Depth of Ground Water Distance from nearest fresh water well Distance from nearest surface water	
Pit Liner Thickness mil Below-Grade Tank: Volume bbls; Construction Material	
Cl. 1 A	Other Date
12. Check Appropriate Box to Indicate Nature of Notice, Report, or NOTICE OF INTENTION TO: SUB	SEQUENT REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	ALTERING CASING
	ALTERING CASING
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF	
	PNS. PLUG & ABANDONMENT
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF	PNS. PLUG & ABANDONMENT
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed 1 Kill well. Pull injection equipment. 2. Clean out to 4210' 3. Pump cement squeeze.	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed 1 Kill well. Pull injection equipment. 2. Clean out to 4210' 3. Pump cement squeeze. 4. Test squeeze.	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed 1 Kill well. Pull injection equipment. 2. Clean out to 4210' 3. Pump cement squeeze.	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed 1 Kill well. Pull injection equipment. 2. Clean out to 4210' 3. Pump cement squeeze. 4. Test squeeze. 5. Clean out to PBTD @4406'. 6. Acid treat well w/1500 gal of 15% PAD acid w/rock salt block. 7. Perform scale squeeze.	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed 1 Kill well. Pull injection equipment. 2. Clean out to 4210' 3. Pump cement squeeze. 4. Test squeeze. 5. Clean out to PBTD @4406'. 6. Acid treat well w/1500 gal of 15% PAD acid w/rock salt block. 7. Perform scale squeeze. 8. Run back in hole with injection equipment.	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed 1 Kill well. Pull injection equipment. 2. Clean out to 4210' 3. Pump cement squeeze. 4. Test squeeze. 5. Clean out to PBTD @4406'. 6. Acid treat well w/1500 gal of 15% PAD acid w/rock salt block. 7. Perform scale squeeze.	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed 1 Kill well. Pull injection equipment. 2. Clean out to 4210' 3. Pump cement squeeze. 4. Test squeeze. 5. Clean out to PBTD @4406'. 6. Acid treat well w/1500 gal of 15% PAD acid w/rock salt block. 7. Perform scale squeeze. 8. Run back in hole with injection equipment. 9. Test casing and chart for the NMOCD. 10. Return well to injection.	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any completion or recompletion.
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed 1 Kill well. Pull injection equipment. 2. Clean out to 4210' 3. Pump cement squeeze . 4. Test squeeze. 5. Clean out to PBTD @4406'. 6. Acid treat well w/1500 gal of 15% PAD acid w/rock salt block. 7. Perform scale squeeze. 8. Run back in hole with injection equipment. 9. Test casing and chart for the NMOCD. 10. Return well to injection. I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify constructed or	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any completion or recompletion.
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed 1 Kill well. Pull injection equipment. 2. Clean out to 4210' 3. Pump cement squeeze. 4. Test squeeze. 5. Clean out to PBTD @4406'. 6. Acid treat well w/1500 gal of 15% PAD acid w/rock salt block. 7. Perform scale squeeze. 8. Run back in hole with injection equipment. 9. Test casing and chart for the NMOCD. 10. Return well to injection.	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any completion or recompletion.
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed 1 Kill well. Pull injection equipment. 2. Clean out to 4210' 3. Pump cement squeeze . 4. Test squeeze. 5. Clean out to PBTD @4406'. 6. Acid treat well w/1500 gal of 15% PAD acid w/rock salt block. 7. Perform scale squeeze. 8. Run back in hole with injection equipment. 9. Test casing and chart for the NMOCD. 10. Return well to injection. I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative	PNS. PLUG & ABANDONMENT NT JOB s, including estimated date of starting any completion or recompletion. that any pit or below-grade tank has been/will be we OCD-approved
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OF PULL OR ALTER CASING Multiple Completion CASING TEST AND CEME OTHER: Squeeze perfs/Acid treat X OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent date proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed 1 Kill well. Pull injection equipment. 2. Clean out to 4210' 3. Pump cement squeeze. 4. Test squeeze. 5. Clean out to PBTD @4406'. 6. Acid treat well w/1500 gal of 15% PAD acid w/rock salt block. 7. Perform scale squeeze. 8. Run back in hole with injection equipment. 9. Test casing and chart for the NMOCD. 10. Return well to injection. 1 hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative plan	PNS. PLUG & ABANDONMENT S, including estimated date of starting any completion or recompletion. PNS. PLUG & ABANDONMENT That JOB That any pit or below-grade tank has been/will be the OCD-approved PASSOCIATE DATE 05/06/2010
TEMPORARILY ABANDON	PNS. PLUG & ABANDONMENT S, including estimated date of starting any completion or recompletion. That any pit or below-grade tank has been/will be we OCD-approved E Associate DATE 05/06/2010 TELEPHONE NO. 806-592-6280
TEMPORARILY ABANDON	PNS. PLUG & ABANDONMENT S, including estimated date of starting any completion or recompletion. PNS. PLUG & ABANDONMENT That JOB That any pit or below-grade tank has been/will be the OCD-approved PASSOCIATE DATE 05/06/2010