

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

Cons. Division

P.O. Box 1980

Albany, NM 88324

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Reliance Operating Company

3. Address and Telephone No.

P O Box 10946, Midland TX 79702

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit P, 660' FSL & 660' FEL of Section 31, T9S, R36E

5. Lease Designation and Serial No.

NMLC065249

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Federal "D" #1

9. API Well No.

30-025-03622

10. Field and Pool, or Exploratory Area

Crossroads Dev West

11. County or Parish, State

Lea County NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other \_\_\_\_\_  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

- 1) Perf approximately 5800' for squeeze
- 2) TIH w/cmt retainer on tbg to 5700'
- 3) Squeeze 100 sx Class "C" thru retainer, leaving 20' cmt on top of retainer
- 4) Set 15 sk plug 4042-4142' in 5 1/2" csg across 8 5/8" csg shoe @ 4092'
- 5) Set 25 sk plug 3738-3838' across top of 5 1/2" liner @ 3838'
- 6) Set 35 sk plug 1900-2000'
- 7) Set 35 sk plug 277-377' in 8 5/8" csg across 11 3/4" shoe @ 327'
- 8) Set 35 sk plug 3-13'
- 9) Cut off csg, set dry hole marker

Above procedure as per David Glass on 7-16-98 w/Carlton Wheeler.

14. I hereby certify that the foregoing is true and correct

Signed Carlton Wheeler

Title Petroleum Engineer

Date 7-16-98

(This space for Federal or State office use)

Approved by (ORIG. SGD.) DAVID R. GLASS

Title PETROLEUM ENGINEER

Date JUL 21 1998

Conditions of approval, if any:

**SEE ATTACHED FOR**

Title 18 U.S.C., Section 1001, makes it a crime to knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\*See Instruction on Reverse Side