

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☐ gas well ☒ other ☐
2. NAME OF OPERATOR Mobil Producing TX. & N.M. Inc.
3. ADDRESS OF OPERATOR Nine Greenway Plaza,
Suite 2700, Houston, Texas 77046
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17
below.)
AT SURFACE: 990' FNL & 1650' FEL Sec. 30, T9S, R38E
AT TOP PROD. INTERVAL: Same as surface
AT TOTAL DEPTH: Same as surface

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE,
REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF	<input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>	<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>	<input type="checkbox"/>
(other)		

5. LEASE NM-0659
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME Ohio Federal
9. WELL NO. 1
10. FIELD OR WILDCAT NAME Sawyer San Andres
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 30, T-9S, R-38E
12. COUNTY OR PARISH Lea 13. STATE New Mexico
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- (1) Set a C.I.B.P. at 4850' and cap with 45 sacks cement, top of cement at 4800'.
- (2) Perf 4 holes at 2500', place a balanced plug of 25 sacks Class C cement inside and outside the 4-1/2" casing from 2500' to 2400'.
- (3) Perf 4 holes at 2280', place a balanced plug of 25 sacks Class C cement inside and outside the 4-1/2" casing from 2280' to 2180'.
- (4) Perf 4 holes at 410', circulate cement 110 sacks Class C cement inside and outside the 4-1/2" casing from 410' to the surface.
- (5) Erect a P&A marker and clean the location.

PROCEDURE WAS DISCUSSED WITH BOB PITSCHKE, B.L.M., CARLSBAD, NM.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Paula A. Collins TITLE Authorized Agent DATE 08/06/84

(This space for Federal or State office use)

APPROVED BY _____ TITLE CARLSBAD REGIONAL DATE 8-21-84
CONDITIONS OF APPROVAL, IF ANY: