

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ gas ☒ other ☐
well well

2. NAME OF OPERATOR

Dyco Petroleum

3. ADDRESS OF OPERATOR

420 NBT Bldg., 320 S. Boston, Tulsa, OK 73104

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.) 1980' FM & 660' FEL Sec. 31-T9S-R38E

AT SURFACE: Unit H

AT TOP PROD. INTERVAL:

AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

CHANGE ZONES ☐

ABANDON* ☒

(other)

5. LEASE

~~General~~ LC-063623

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Union Federal

9. WELL NO.

3

10. FIELD OR WILDCAT NAME

Sawyer

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 31, T9S, R38E

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

14. API NO.

LC 063623

15. ELEVATIONS (SHOW DF, KDB, AND WD)

DF 3929

WD 4961

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Fill hole with plugging mud and pull tubing out of hole.
- 2) Set CIBP @ 4850' and cap with 35' cement using a dump bailer.
- 3) Determine free point of casing and cut casing above free point.
- 4) Spot 100' cement at cut in casing (50' in and out of cut).
- 5) Pull casing to 2,500' and spot 100' cement from 2,400-2,500' (top of salt).
- 6) Pull casing to 363' and spot 100' cement across base of surface casing from 263-363' (50' in and out of casing).
- 7) Pull remainder of casing out of hole and set 50' cement surface plug.
- 8) Weld on cap and mark well as per regulations.
- 9) Clean and restore location to original condition or as per field inspector's requests.

Estimated start date: Upon approval

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED _____ TITLE Engineer DATE April 28, 1983

APPROVED

(This space for Federal or State office use)

APPROVED BY (Orig. Sgd.) PETER W. CHESTER TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

MAY 6 1983