

STATE OF NEW MEXICO.
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> For <input type="checkbox"/>
5. State Oil & Gas Lease No. LG 2728
7. Unit Agreement Name
8. Firm or Lease Name Cone ABZ State
9. Well No. 1
10. Field and Pool, or Wildcat East Echols Devonian
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input type="checkbox"/> GAS <input type="checkbox"/> OTHER- P&A
2. Name of Operator Yates Petroleum Corporation
3. Address of Operator 207 South 4th St., Artesia, New Mexico 88210
4. Location of Well UNIT LETTER F 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 16 TOWNSHIP 11S RANGE 38E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3902' GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well as follows:

Spot 25 sack cement plug @5900'.
Spot 20 sack cement plug inside 5½" casing at 8-5/8" casing shoe depth of 4445'.
Cut & pull 5½" casing from approximately 3500' (cement top behind 5½" casing is approx. 3540').
Spot 35 sack cement plug across 5½" stub.
Spot 50 sack cement plug inside 8-5/8" casing across salt @2000'.
Spot 50' cement plug at surface.

Plugs will be spotted through tubing and plug at 5900' will be tagged.

Verbal approval for this procedure given by Jerry Sexton, NMOCD, Hobbs, 42-3-85.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Juanita Goodlett TITLE Production Supervisor DATE 4-25-85
APPROVED BY _____ TITLE _____ DATE APR 30 1985