

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions on
reverse side)

Form approved.
Budget Bureau No. 42-R1424.
LEASE DESIGNATION AND SERIAL NO.

NM-25418✓

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR
Petroleum Production Management, Inc.

3. ADDRESS OF OPERATOR
Suite 200/Sutton Place Bldg. Wichita, Kansas 67202

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface
660' FSL and 660' FWL, Sec. 8, T-9-S, R-36-E
Lea County, New Mexico.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)
4099' KB ✓

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME
LOE
SRS

8. FARM OR LEASE NAME
KGS 686 Ltd. ✓

9. WELL NO.
1 ✓

10. FIELD AND POOL, OR WILDCAT
Vada Penn ✓

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA
Sec. 8, T-9-S, R-36-E ✓

12. COUNTY OR PARISH
Lea

13. STATE
N.M.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF	<input type="checkbox"/>	PULL OR ALTER CASING	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	MULTIPLE COMPLETE	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	ABANDON*	<input checked="" type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	CHANGE PLANS	<input type="checkbox"/>
(Other)	<input type="checkbox"/>		

SUBSEQUENT REPORT OF:

WATER SHUT-OFF	<input type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
FRACTURE TREATMENT	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
SHOOTING OR ACIDIZING	<input type="checkbox"/>	ABANDONMENT*	<input type="checkbox"/>
(Other)	<input type="checkbox"/>		

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

- Set CIBP at 8892' above Wolfcamp perforations at 8992'-9010' and cap with 35' cement. ✓
- Load casing with salt gel mud. ✓
- Spot 200' cement plug at 7850' to straddle top of Abo at 7750'. ✓
- Spot 200' cement plug at 5326' to straddle 9 5/8" casing shoe at 5226'. Tag top of cement.
- Salvage 4 1/2" casing below casing bowl at 3550' depth.
- Spot 100' cement plug from 50' below top of 4 1/2" casing stub. Tag top of cement.
- Spot 100' cement plug at 2100' across top of salt section.
- Spot 100' cement plug at 410' across 13 3/8" casing shoe at 360' depth. Tag top of cement.
- Spot 100' cement plug at 314' across top of 7" casing at 264' depth. Tag top of cement.
- Spot 50' cement plug in top of 13 3/8" casing.
- Erect dry hole marker.
- Clean and level location.

18. I hereby certify that the foregoing is true and correct

SIGNED Wm. B. Grossbeck TITLE District Engineer

DATE 10-5-88

(This space for Federal or State office use)

APPROVED BY Wm. B. Grossbeck TITLE District Engineer

CONDITIONS OF APPROVAL, IF ANY:

DATE

NOTIFY BLM AT (505) 373-5612 PRIOR TO COMMENCING PLUGGING.

*See Instructions on Reverse Side