

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <b>K.K.A. Corporation</b>		8. Farm or Lease Name <b>Humble State</b>
3. Address of Operator <b>1 400 Wall Towers West - Midland, Texas 79701</b>		9. Well No.
4. Location of Well UNIT LETTER <b>E</b> , <b>2086</b> FEET FROM THE <b>North</b> LINE AND <b>766</b> FEET FROM THE <b>West</b> LINE, SECTION <b>26</b> TOWNSHIP <b>10-S</b> RANGE <b>23-E</b> NMPM.		10. Field and Pool, or Wildcat <b>Inbe Pennsylvanian</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4195 G.I.</b>		12. County <b>Isa</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

### Plugging Procedure:

9-25-72

- Set 25 Sk. @ 9700' - Perf. 9751-53. Fill hole with mud Laden Fluid
- Top of cement behind 4-1/2" csg. @ 7000'.
- Cut off 4 1/2" csg. & pull csg.
- Set 25 sk. cement plug @ Top of 4 1/2" stub.
- Set 25 sk. cement plug @ 5300' on top of Glorieta
- Set 25 sk. cement plug @ 3925' in and out bottom of 8-5/8" csg.
- Pull 8-5/8" csg. from 1200' set 25 sk. plug @ stub.
- Set 25 sk. plug @ base of surface csg. @ 345'
- Set 10 sk. plug in top of 13-3/8" csg. set marker and clean up location.

25 sks 6 1/2 / 100 bbls

100' plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED James L. Harbison TITLE Geologist DATE Sept. 25, 1972

APPROVED BY Joe D. Ramey TITLE Dist. I, Supv. DATE SEP 27 1972  
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

SEP 26 1972

OIL CONSERVATION COMM.  
HOBBS, N. M.

SEP 27 1972