

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
-	
7. Unit Agreement Name	
-	
8. Farm or Lease Name	
J. D. Guye	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Inbe (Permo-Penn.)	
12. County	
Lea	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator
Southland Royalty Company
3. Address of Operator
1405 Wilco Bldg., Midland, Texas 79701
4. Location of Well
UNIT LETTER <u>H</u> , <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>12</u> TOWNSHIP <u>11-S</u> RANGE <u>33-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)
4199.3' GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Set 13 3/8" casing at 363' with 350 sacks cement - circulated. Set 9 5/8" casing at 4000' with 250 sacks Pozmix 6% gel + 150 sacks reg. T/cement @ 3275'. Set 5 1/2" casing at 9796' with 350 sacks Pozmix w/4% gel + 40 sacks Latex. T/cement @ 7800'. Bough "C" perf 9739-59'. Model "D" set at 9630' w/DR plug. Bridge plug @ 9454' and @ 9420'. Wolfcamp perf 9241-47', 9378-87'. Propose to plug and abandon:

Set wire line bridge plug @ 9200'. Place 2 sacks cement on top of BP. 25 sacks cement over stub of 5 1/2" at approximately 7700'. 25 sacks cement @ top of Glorieta @ 5355'. 25 sacks cement across 9 5/8" shoe @ 4000'. 25 sacks cement @ stub of 9 5/8" stub estimated @ 1500'. 25 sacks cement across 13 3/8" shoe @ 363'. 10 sacks cement @ top of 13 3/8" casing.

Checked above procedure by telephone w/Mr. Joe Ramey of NMOCC.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. H. Can TITLE District Engineer DATE 3-10-70  
APPROVED BY Joe Ramey TITLE District Engineer DATE 3-10-70  
CONDITIONS OF APPROVAL, IF ANY: