

7. Run 2 3/8" tbg. to top of 8 5/8" csg. stub and circulate 100'. Plug in 11" hole (estimate 100 sx).
8. Run 2 3/8" tbg. to 420' (50' below 13 3/8" csg.) and circulate 100'. Plug to 50' above 13 3/8" csg. shoe at 367' (estimate 100 sx.).
9. Place 10 sx plug in top of 13 3/8" csg. with a 2" pipe 4' above ground level with proper identification in accordance with New Mexico Oil Conservation Commission requirements.