

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

3a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
3. State Oil & Gas Lease No. NM 058102	
7. Unit Agreement Name Flying "M" (SA) Unit	
8. Farm or Lease Name Tract 16	
9. Well No. 4	
10. Field and Pool, or Wildcat San Andres	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- WIW	
2. Name of Operator Coastal Oil & Gas Corporation	
3. Address of Operator P. O. Box 235 Midland, Texas 79702	
4. Location of Well UNIT LETTER <u>H</u> <u>1904.3</u> FEET FROM THE <u>North</u> LINE AND <u>845.9</u> FEET FROM THE <u>East</u> LINE, SECTION <u>21</u> TOWNSHIP <u>9-S</u> RANGE <u>33-E</u> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.) 4355' GR	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☐  
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☒

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1-29-85 MIRU well servicing unit. Pick up workstring and TIH.. Tag plug at 4132'. Pick up 8' and SDFN.

1-30-85 Circulate hole with 9.5 PPG 35 Vis mud. POOH. RU WL truck and GIH with perf gun. Shot 4 holes at 2582', 1985', and 310'. PU cement retainer and TIH. Set retainer at 2480' and squeeze perfs with 50 sacks Class "C". POOH. PU cement retainer and TIH. Set retainer at 1880' and squeeze perfs at 1985' with 50 sacks Class "C". POOH. Cut off well head and weld swage on to 4 1/2" casing. Mix and pump 125 sacks Class "C" thru perfs at 310'. Cmt circulated to surface. Install P & A marker, clean and level location. Well P & A'd 1/30/85.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Bobby L. Smith/spb Bobby L. Smith TITLE Petroleum Engineer

DATE January 31, 1985

APPROVED BY Jack Griffin

OIL & GAS INSPECTOR

DATE JAN 26 1988

RECEIVED

FEB -4 1985

INTELLIGENCE OFFICE