

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-9669
7. Unit Agreement Name --
8. Farm or Lease Name New Mexico "CC" St.
9. Well No. 1
10. Field and Pool, or Wildcat The Permo Pennsylvanian
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator KKA Corporation
3. Address of Operator 405 Wall Towers East	4. Location of Well UNIT LETTER <u>O</u> <u>554</u> FEET FROM THE <u>South</u> LINE AND <u>1874</u> FEET FROM THE <u>East</u> LINE, SECTION <u>27</u> TOWNSHIP <u>10-S</u> RANGE <u>33-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4203 DF	16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>		SUBSEQUENT REPORT OF: REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>	
---	--	---	--

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plugging Procedure:

1. Set 25sk. plug @ 9650' - Perf. 9687-9700. Fill hole w/ mud laden fluid.
2. Top of cement behind 4-1/2" csg. @ 7600'.
3. Cut off 4-1/2" csg. & pull csg.
4. Set 30sk. cement plug @ top of 4-1/2" stub (100' plug).
5. Set 30 sk. cement plug @ 5300' on top of Glorieta. (100' plug).
6. Set 30sk. cement plug @ 4064' in & out bottom of 8-5/8" csg. (100' plug).
7. Pull 8-5/8" csg. from 1200'; set 55sk plug @ stub (100' plug).
8. Set 55sk. plug @ base of surface csg. @ 350'. (100' plug).
9. Set 10sk. plug in top of 13-3/8" csg.; set marker & clean location.

24 hr. notice

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Karin Hodwin TITLE Agent DATE 8-06-73

APPROVED BY [Signature] TITLE [Signature] DATE [Signature]

CONDITIONS OF APPROVAL, IF ANY: