

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <u>TA'd</u>		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR <u>Amerada Hess Corporation</u>		8. FARM OR LEASE NAME <u>Federal "B"</u>	
3. ADDRESS OF OPERATOR <u>Drawer D, Monument, New Mexico 88265</u>		9. WELL NO. <u>1</u>	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface <u>1538' FEL & 1983' FNL <i>unit G</i></u>		10. FIELD AND POOL, OR WILDCAT <u>Bronco Wolfcamp</u>	
14. PERMIT NO.		15. ELEVATIONS (Show whether DF, RT, GR, etc.) <u>3810' DF</u>	
		12. COUNTY OR PARISH <u>Lea</u>	13. STATE <u>N.M.</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL
(Other)

PULL OR ALTER CASING
MULTIPLE COMPLETE
ABANDON*
CHANGE PLANS

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other)

REPAIRING WELL
ALTERING CASING
ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plan to MIRU pulling & plugging eqpt. Remove well head & install BOP. TIH w/tbg. to 11,000'. TIH & circ. hole w/438 bbls. 9.5# MLF. Spot 45 sks. cement fr. 11,000' - 10,800'. TIH w/gauge ring & junk basket to 9454' & TOH. TIH w/7" CIBP set at 9454'. Spot 45 sks. cement on top of CIBP fr. 9454' - 9259'. Weld on 7" pull nipple. Determine frepoint from stretch & jet cut 7" csg. at frepoint. TOH w/7" csg. Spot 75 sks. cement fr. 6750' - 6583'. Spot 65 sks. cement fr. 4545' - 4399'. TIH & perf. csg. at 2500'. TIH w/9.625 pkr. set at 2300'. Displace cement 100' below pkr. w/950 sks. cement. Release pkr. & TOH. Spot 5 sks. cement at surface. Remove BOP & RDPU & plugging unit. Cut well head 3' below surface & install dry hole marker. Cut off dead man anchors & clean location.

RECEIVED
 MAY 4 8 42 AM '92
 OFFICE OF THE DIRECTOR
 BUREAU OF LAND MANAGEMENT

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE Supv. Adm. Svc. DATE 4-29-92

(This space for Federal or State office use)

APPROVED BY [Signature] TITLE _____ DATE 5-6-92
CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side