

**DISTRICT I**

P. O. Box 1980, Hobbs, NM 88240

**OIL CONSERVATION DIVISION**

2040 South Pacheco  
Santa Fe, New Mexico 86595

**DISTRICT II**

P. O. Drawer DD, Artesia, NM 88210

**DISTRICT III**

1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.  
30-025-20670

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

E-9697

**SUNDRY NOTICES AND REPORTS ON WELLS**

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT  
(FORM C-101) FOR SUCH PROPOSALS)

1. Type of Well:

Oil Well ☒ Gas Well ☐ OTHER

2. Name of Operator

TMBR/Sharp Drilling, Inc.

3. Address of Operator

P. O. Drawer 10970, Midland, TX 79702

4. Well Location

Unit Letter A : 660 Feet From The North Line and 660 Feet From The East

Section 22 Township 14S Range 34E NMPM County Lea

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

4103.9' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

**NOTICE OF INTENTION TO:**

**SUBSEQUENT REPORT OF:**

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

See attached sheet.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*Lonnie Arnold*

TITLE

Production Manager

DATE

05/24/02

TYPE OR PRINT NAME

Lonnie Arnold

TELEPHONE NO.

(915) 699-5050

(This space for State Use)

APPROVED BY

*Bill E. Fisher*

TITLE

COMPLIANCE OFFICER

DATE

AUG 07 2002

CONDITIONS OF APPROVAL, IF ANY:

GW

## High Plains Unit No. 1

### Form C-103 (Continued)

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent estimated date of starting any proposed work) SEE Rig up LE 1103.

- 04/04/02 Rig up Pool Well Service. Nipple down wellhead and nipple up BOP. Notified NMOCD.
- 04/05/02 Rig up wireline and GIH w/gauge ring, stopped at 5020'. Rig down wireline. GIH w/3<sup>7</sup>/<sub>8</sub>" bit and casing scraper, tag at 10,419'. SDFN.
- 04/08/02 Pull casing scraper and bit. Rig up wireline and GIH w/gauge ring and junk basket, stopped at 8799'. Rig down wireline. GIH w/CIBP and tubing, stopped at 3880'. POOH w/CIBP. SDFN.
- 04/09/02 GIH w/casing scraper to 10,405'. Circulate hole clean. POOH w/scraper and GIH w/CIBP on 2<sup>3</sup>/<sub>8</sub>" tubing. SDFN.
- 04/10/02 GIH w/CIBP, stopped at 10,150'. Set w/approval from Mr. Bill Prichard w/NMOCD. Circulate hole with 9# 35 vis mud. POOH w/tubing. Dump bail 35' cement from 10,150' to 10,115'. GIH w/CIBP and 2<sup>3</sup>/<sub>8</sub>" tubing. SDFN.
- 04/11/02 Finish in hole w/CIBP, set @ 9600'. POOH w/tubing. GIH w/dump bailer and spot 35' cement from 9600-9565'. Nipple down BOP and wellhead. Weld on pull nipple to pull 4<sup>1</sup>/<sub>2</sub>" casing. SDFN.
- 04/12/02 Rig up casing jacks. Pull 4<sup>1</sup>/<sub>2</sub>" slips. Rig up wireline and free point casing. Found 4<sup>1</sup>/<sub>2</sub>" casing free at 4810'. Shoot casing. Pull 10'. SDFN.
- 04/15/02 POOH w/153 jts 4<sup>1</sup>/<sub>2</sub>" casing (4810') and lay down same. GIH to 4860'. Spot 40 sx CI "C" Neat plug from 4860' to 4760'. POOH w/tubing. SDFN.
- 04/16/02 GIH w/tubing and tag plug at 4750'. POOH w/tubing. ND BOP and wellhead. Weld lift nipple for 8<sup>5</sup>/<sub>8</sub>" casing. SDFN.
- 04/17/02 Rig up casing jacks. Pull 8<sup>5</sup>/<sub>8</sub>" slips. Rig up wireline and free point 8<sup>5</sup>/<sub>8</sub>" casing. Shot 8<sup>5</sup>/<sub>8</sub>" casing at 850'. RD wireline. LD 850' of 8<sup>5</sup>/<sub>8</sub>" casing. Nipple up wellhead and BOP. GIH to 1960'. Set 35 sx CI "C" Neat plug per NMOCD. Pull tubing to 900'. Set 80 sx CI "C" plug. POOH w/tubing. SDFN.
- 04/18/02 GIH w/tubing, tag plug at 782'. POOH to 420'. Pump 80 sx CI "C" w/2% CaCl<sub>2</sub> plug. Wait 3<sup>1</sup>/<sub>2</sub> hrs. Tag plug at 310'. POOH w/tubing and set 10' surface plug. Cut off wellhead and install dry hole marker. Well P&A'd 04/18/02.