

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator SKELLY OIL COMPANY	8. Farm or Lease Name William Sanders
3. Address of Operator P. O. Box 730 - Hobbs, New Mexico 88240	9. Well No. 2
4. Location of Well UNIT LETTER F , 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 1 TOWNSHIP 14-S RANGE 33-E NMPM.	10. Field and Pool, or Wildcat Lady "J" Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4195' DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was drilled to a total depth of 10.071 in lime with no commercial quantities of oil or gas encountered in any zone. We plan to plug and abandon the well in the following manner:

- Spot cement plugs at the following depths:
9950-9750' - 65 sacks
8850-8760' - 25 sacks
7000-6910' - 25 sacks
5600-5510' - 25 sacks
4200-4110' - 25 sacks
- Run Free Point Indicator.
- Cut and pull 8-5/8" OD casing from approximately 1550'.
- Spot 25 sack cement plug on inside and outside of cut off stub of 8-5/8" OD casing.
- Spot 10 sack cement cap in top of 11-3/4" OD casing and install 4" dry hole marker.
- All intervals not cemented will be filled with heavy mud laden fluid.

Mr. Joe D. Ramsey of the New Mexico Oil Conservation gave verbal approval on October 6, 1967, to plug and abandon this well.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED V. B. Fletcher TITLE District Superintendent DATE October 9, 1967
APPROVED BY Joe D. Ramsey TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: