

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5. LEASE DESIGNATION AND SERIAL NO.
2. NAME OF OPERATOR Continental Oil Company	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P.O. Box 460, Hobbs, New Mexico	7. UNIT AGREEMENT NAME MCA
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See last space 17 below.) At surface: 1980' FSL & 1980' FEL of Section 28, T-17S, R-32E, Lea County, New Mexico, NMPM.	8. FARM OR LEASE NAME MCA Unit <i>Battery</i>
14. PERMIT NO.	9. WELL NO. 178
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3960 DF	10. FIELD AND POOL, OR WILDCAT Baish-Malj-Pearsall Field Maljamar Pool
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA S-28, T-17S, R-32E,
	12. COUNTY OR PARISH Lea
	13. STATE N.M.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(Other) Convert to Water Injection ☒

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

In connection with the MCA Unit Waterflood it is proposed to convert the subject well to water injection using the following procedure:

1. Clean out to 4017'.
2. Set 2-3/8" tubing w/retrievable packer at approx. 3,500'.
3. Connect up for water injection down the tubing.

The USGS office in Roswell has granted approval for this conversion. Your approval to the above work is requested.

18. I hereby certify that the foregoing is true and correct

SIGNED *[Signature]*

TITLE Staff Supervisor

DATE 7-15-65

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

USGS-5, NMOCC-2, LPT PARTNERS -12

*See Instructions on Reverse Side

ACTING DISTRICT ENGINEER