

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-29902
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V-1987
7. Lease Name or Unit Agreement Name Airstrip State "A"
8. Well No. 1
9. Pool name or Wildcat N. Airstrip-Bone Spring

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Morexco, Inc.
3. Address of Operator P. O. Box 481, Artesia, NM 88211-0481
4. Well Location Unit Letter <u>K</u> : <u>1931</u> Feet From The <u>S</u> Line and <u>1980</u> Feet From The <u>W</u> Line Section <u>15</u> Township <u>18S</u> Range <u>34E</u> NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
--

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <u>Plug back</u> <input checked="" type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

MI and RU unit and TOOH w/tubing. Set 5 1/2" CIBP at 5920'. Dump 35' of cement on top of CIBP. Pull up and perforate the Queen from 4460' - 4465'. RIH w/ 5 1/2" packer and spot 200 gals. of 7 1/2% NEFE HCL across perms. Pull packer above perms, set and breakdown. Acidize and ball out w/500 gals. 7 1/2% NEFE HCL. Swab. RU wellhead for forced closure frac and start flowing back. Rig down pulling unit. RU swab unit and swab.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Donald G. Becker, Jr. TITLE Geologist DATE 3-7-94  
TYPE OR PRINT NAME Donald G. Becker, Jr. TELEPHONE NO. 746-6520

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE DISTRICT SUPERVISOR DATE MAR 11 1994  
CONDITIONS OF APPROVAL, IF ANY: