

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

5. Lease Designation and Serial No.

LC 031695B

6. If Indian, Allottee or Tribe Name

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Conoco Inc.

3. Address and Telephone No.

10 Desta Drive West, Midland, TX 79705, (915) 686-6548

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980' FSL & 1980' FEL
Sec. 29, T-20S, R-38E

7. If Unit or CA, Agreement Designation

SEMU McKee

8. Well Name and No.

3

9. API Well No.

300250785200

10. Field and Pool, or Exploratory Area

Warren McKee

11. County or Parish, State

Lea, NM

CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☐ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☒ Other Replace Gravel Pack

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The gravel pack in this well has failed. It is proposed to pull it, clean out the wellbore, and re-gravel pack the well according to the following procedure:

1. Pull existing gravel pack from the hole.
2. RIH with 6" bit, casing scrapper, and workstring to clean out wellbore to 7" casing shoe at 8947'.
3. Set RBP at 8900' and test casing to 1000 psi for 15 minutes.
4. GIH with gravel pack assembly and perform the gravel pack.
5. Clean gravel pack with 1000 gals. 15% HCL and chlorine dioxide.
6. Pump 4000 gals. 15% gelled acid.
7. RIH with electric submersible pump.

A proposed after-workover diagram is attached.

14. I hereby certify that the foregoing is true and correct

Signed Jerry McBoone

Title Regulatory Coordinator

Date 10/5/90

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

Date 10/15/90