

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
ELC	
S.G.S.	
AND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-101
Effective 1-1-65

30-025-22003

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	E-5890

7. Unit Agreement Name	
8. Farm or Lease Name	Leonard State
9. Well No.	1
10. Field and Pool, or Wildcat	Wilson Bone Springs
12. County	Lea

SUNDY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO RE-OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT TO DRILL (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL ☒ GAS WELL ☐ OTHER ☐

Name of Operator
Wilson Oil Company

Address of Operator
P. O. Box 1297 - Santa Fe, New Mexico 87501

Location of Well
UNIT LETTER K 1847 FEET FROM THE West LINE AND 1980 FEET FROM THE south LINE, SECTION 19 TOWNSHIP 21-S RANGE 35-E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
3645 GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

REFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
RE-OPEN OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

April 27, 1967 Halliburton set a drilling cast iron B. P. @ 12,625'
July 6, 1967 Otis set a Production Packer & B. P. @ 12,355'
July 7, 1967 a Baker Model N Retainer Packer was set @ 9,390'

The following procedure was used by Baber Well Servicing Co. to plug & abandon well:

- 1) Tag top of retainer packer @ 9414'. Dump 4 sacks cement on top of retainer.
- 2) Ran a 7" cast iron B. P. to 8900', set and dump 4 sacks cement on top of B. P.
- 3) Set a 25 sack cement plug at 7000'.
- 4) A 120 sack cement plug was set @ 7" stub & 9 5/8" Shoe. (From 6000' to 5500') Tag plug @ 5500'.
- 5) Spotted a 55 sack cement plug @ 630' @ the 9 5/8" stub. Tagged plug @ 500'.
- 6) Spotted a 75 sack cement plug @ 430' @ the 13 3/8" shoe. Tagged plug @ 310'.
- 7) 10 Sacks cement plug was set @ surface.
- 8) Set dry hole marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

BY <u>Robert J. Dwyer</u>	TITLE <u></u>	DATE <u>6-9-81</u>
APPROVED BY <u>W. H. Patterson</u>	TITLE <u>OIL & GAS INSPECTOR</u>	DATE <u></u>
ADDITIONS OF APPROVAL, IF ANY:		