

G.U.L. CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State Fee

5. State Oil & Gas Lease No.
V-746

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL GAS WELL OTHER

7. Unit Agreement Name

8. Farm or Lease Name
Brinninstool

9. Well No.
1

10. Field and Pool, or Wildcat
Wildcat *Atoka*

11. Elevation (Show whether DF, RT, GR, etc.)
3662.5' GL, 3689' K.B.

12. County
Lea

13. Name of Operator
Bettis, Boyle and Stovall

14. Address of Operator
P. O. Box 1240, Graham, Texas 76046

15. Location of Well
UNIT LETTER J 1980 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 16-36 TOWNSHIP 23-S RANGE 32-E NMPM.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The following procedure is proposed to plug and abandon the Brinninstool No. 1 well.

1. Spot 25 sack cement plug at 13,160' K.B. in 7-5/8", 39#/ft., liner, above perforations at 13,164' - 13,180' K.B., WOC and tag plug.
2. Spot 50 sack plug at 8854' K.B., top of Bone Springs.
3. Cut and pull 7-5/8" casing at approximately 7000' K.B.
4. Spot 35 sack cement plug in and out of 7-5/8" stubb.
5. Spot 50 sack plug at 5022', top of Delaware.
6. Spot 50 sack plug at 4780', base of salt.
7. Spot 75 sack plug at 1210', top of salt.
8. Place 10 sack plug at surface with dry hole marker.

The hole will be loaded with 9.5#/gallon mud laden fluid between all plugs and to the surface.

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Bill Boyle TITLE Agent DATE 3/13/89

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE MAR 15 1989

CONDITIONS OF APPROVAL, IF ANY: