

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form 1-103
Supersedes Old
C-102 and C-103
Effective 1-1-61

5a. Indicate Type of Letter	Letter <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5b. State Oil & Gas Lease No.	NM 10107

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>	
1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	7. Unit Agreement Name
2. Name of Operator Cities Service Oil Company	8. Name of Lease Name State AS Com.
3. Address of Operator Box 1919 - Midland, Texas 79701	9. Well ID 1
4. Location of Well UNIT LETTER <u>F</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>2</u> TOWNSHIP <u>24S</u> RANGE <u>36E</u> N.M.P.M.	10. Field and Pool, or Well Unit Jalmat - Tansill
15. Elevation (Show whether DF, RT, GR, etc.) 3374' DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/> REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>	SUBSEQUENT REPORT OF: ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of completion of any proposed work) SEE RULE 1103.

O.T.D. 3290' Lime PBTD 2981'. We propose to plug and abandon this well in the following manner:

1. MIRU pulling unit, load hole with mud laden fluid, unseat packer @ 2784' and pull tubing and packer.
2. Set a CIBP @ approx. 2815' and dump 5 sacks of cement on top of CIBP @ approx. 2815 - 2765'.
3. Determine free point on 5-1/2" casing @ approx. 2160', shoot off and recover.
4. Spot a 100' cement plug @ approx. 2210 - 2110' (1/2 in and 1/2 out of 5-1/2" casing stub @ approx. 2160').
5. Spot a 100' cement plug @ approx. 1301 - 1201' (1/2 in and 1/2 out of 8-5/8" casing shoe @ 1251').
6. Spot a 50' cement surface plug @ approx. 50 - 0' and install a 4" dry hole marker.
7. Clear location of all equipment and debris.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED E. Spiller TITLE Region Operation Manager Sept. 23, 1975

APPROVED BY _____

TITLE _____

CONDITIONS OF APPROVAL, IF ANY: