

Western Refining Southwest LLC

A subsidiary of Marathon Petroleum Corporation I-40 Exit 39 Jamestown, NM 87347

April 16, 2024

Mr. Ricardo Maestas, Interim Chief New Mexico Environment Department Hazardous Waste Bureau 2905 Rodeo Park Drive East, Building 1 Santa Fe, NM 87505

RE: Response to Second Disapproval OW-63 PFAS Investigation Work Plan [Revised] Western Refining Southwest LLC, Gallup Refinery EPA ID# NMD000333211 HWB-WRG-23-005

Dear Mr. Maestas:

Western Refining Southwest LLC (D/B/A Marathon Gallup Refinery) is submitting this response to disapproval contained in the New Mexico Environment Department (NMED) "Second Disapproval, OW-63 PFAS Investigation Work Plan [Revised]" letter dated February 8, 2024. A timeline of the report is as follows:

- Investigation Work Plan, submitted December 7, 2022
- Disapproval, received May 23, 2023
- Investigation Work Plan [Revised], submitted September 28, 2023
- Second Disapproval, received February 8, 2024

The response to comments is provided in Attachment A. Supporting documents to the response to comments is provided in Attachment B. This submittal includes two hard copies of the revised report (Attachment C) and a CD with an electronic copy of the red-line, strike-out version of the report (Attachment D). The electronic copies will also be submitted by email to NMED.

If you have any questions or comments regarding the information contained herein, please do not hesitate to contact Ms. Kateri Luka at (714) 713-1218.



Western Refining Southwest LLC

A subsidiary of Marathon Petroleum Corporation I-40 Exit 39 Jamestown, NM 87347

Certification

I certify under penalty of law that this document and all attachments were prepared under my direction of supervision according to a system designed to assure that qualified personnel properly gather and evaluate the information submitted. Based on my inquiry of the person or persons who manage the system, or those persons directly responsible for gathering the information, the information submitted is, to the best of my knowledge and belief, true, accurate, and complete. I am aware that there are significant penalties for submitting false information, including the possibility of fine and imprisonment for knowing violations.

Sincerely,

Western Refining Southwest HC, Marathon Gallup Refinery

m

Timothy J. Peterkoski Director of Environment and Climate Strategy Marathon Petroleum Company LP

Enclosures

cc: L. Andress, NMED HWB L. Tsinnajinnie, NMED HWB L. Barr, NMOCD J. Moore, Marathon Gallup Refinery M. Suzuki, NMED HWB L. King, EPA Region 6 K. Luka, Marathon Petroleum Company H. Jones, Trihydro Corporation

ATTACHMENT A

RESPONSE TO COMMENTS

.

NMED Comments	Refinery Responses
Comment 1:	Response 1:
According to the Interstate Technology and Regulatory Council (ITRC) November 8, 2023 <i>Tools for PFAS Site Characterization</i> , the passive sampling method is becoming more essential to the collection of PFAS samples. If site-specific conditions (e.g., hydraulic conductivity) meet criteria for its use, and acceptability is demonstrated (see Disapproval Comment 7), the passive sampling method would be more suitable for PFAS sampling. Propose to demonstrate the acceptability of a passive sampling method in a separate work plan, as applicable. The work plan must be submitted to NMED no later than June 28, 2024 .	 The Refinery respectfully disagrees that a work plan demonstrating the acceptability of passive sampling is necessary for the following reasons: The ITRC neither published guidance nor hosted any training sessions on November 8, 2023. A webinar titled <i>Tools for PFAS Site Characterization</i> was hosted by the National Institute of Environmental Health Sciences Superfund Research Program (SRP) on November 8, 2023. The ITRC is separate from the SRP, and this webinar cannot be considered as ITRC guidance. Current ITRC guidance states that "[1]ow-flow or passive sampling techniques are preferred for collection of groundwater samples for PFAS to keep the turbidity of samples and purge-water volume to a minimum." The ITRC does not recommend one sampling method in favor of the other. NMED's Disapproval Comment 7 of the May 23, 2023 first disapproval, states "[i]f the Permittee chooses to use passive sampling for PFAS analysis, propose to submit a separate work plan that proposes to demonstrate its acceptability [a]Iternatively, if the Permittee chooses to propose an active sampling method (e.g., low-flow sampling), revise the Work Plan accordingly." The Refinery submitted the revised Work Plan that reflected a low-flow sampling method and a separate work plan is not required.

Attachment A. Response to the New Mexico Environment Department (NMED) To Western Refining Southwest LLC (D/B/A Marathon Gallup Refinery [Refinery]) Disapproval Letter for OW-63 PFAS Investigation Work Plan [Revised] (Feb. 8, 2024)

1 of 6

.

NMED Comments	Refinery Responses
	 References: ITRC - Per - and Polyfluoroalkyl Substances 11.7.2 September 2023. NIEHS SRP – Tools for PFAS Site Characterization: Session III- Standards, Passive Sampling, and Modeling of PFAS. November 8, 2023.
Comment 2:	Response 2:
NMED's Disapproval Comments 4 and 5b required the Permittee	This comment has been acknowledged. The Refinery will
to collect PFAS groundwater samples from the air/water	collect PFAS samples as proposed.
interface rather than the bulk water phase. However, the	
Permittee's responses to NMED's Disapproval Comments 4 and	
5b provided sufficient explanation for why sampling at the bulk	
water phase is representative of the formation water and justifies	
the collection of groundwater PFAS samples from the bulk water	
phase. Collect PFAS groundwater samples from the bulk water	
phase and from well OW-14 rather than well OW-55, as	
proposed.	

.

NMED Comments	Refinery Responses
Comment 3:	Response 3:
In the response to NMED's Disapproval Comment 8, the	This comment has been acknowledged. The Refinery will
Permittee states, "the Refinery has chosen to revise the sampling	include a list of the equipment used for PFAS sample collection
method from HydraSleeve [™] to low flow sampling." NMED	in the investigation report. As noted in Response 1, a separate
hereby approves the proposed low flow sampling method for the	investigation work plan will not be provided.
collection of the PFAS samples. All equipment (e.g., tubing,	
components of pump, etc.) used for the sampling method must be	
compatible with PFAS sampling. The equipment used for the	
PFAS sample collection must be discussed in the separate	
investigation work plan (See Comment 1) and the investigation	
report.	

NMED Comments	Refinery Responses
Comment 4:	Response 4:
 In response to NMED's Disapproval Comment 10, the Permittee states, "(t]he Refinery respectfully disagrees that surface soil sampling is necessary at the Historical Fire Training Area. The Historical Fire Training Area has been excavated and subsequently capped. Because the excavation removed soil which may have been impacted by historical PFAS contamination, surface soil would not be representative of historical contamination." Address the following: a) Although the fire training area (SWMU-7) is known to have been investigated in the early 1990s, the infrastructure removed and a soil cap placed, the Permittee did not provide any references to support the statement. NMED must be able to verify whether residual contamination was adequately eliminated. Provide relevant references to support the statement in Section 6.0 (References) of the revised Work Plan. Once the references are provided, NMED will evaluate the necessity to collect additional soil samples directly from the fire training area and provide directions in future correspondence. b) Based on the Permittee's statement, the fire training area has not been used for fire training after the area was capped. If so, identify all of the other areas where fire training was previously conducted in a separate figure and propose to investigate the areas in the revised Work Plan. 	 A. This comment has been acknowledged and addressed. Section 6.0 (References) of the revised Work Plan has been updated to include an additional reference, "No Further Action Report, SWMUs 7, 9, 10, 11, 12, 13." This reference details the removal of contaminated soil and the placement of a soil cap at the Historical Fire Training Area, SWMU-7. The investigation did not include PFAS sampling, as the shallow soil impacts were defined by the presence of TPH. Potential PFAS impacts would occupy the same footprint as the TPH, defined by the boundaries of the fire training area. Therefore, the excavation and capping activities described in the report would mitigate the potential PFAS impacts to the area, both in terms of potential direct exposure to surface soil as well as migration to groundwater. B. The Fire Training Area, the only other area where fire training area, was investigated as part of the demolition of the fire training area. The concrete pad was disassembled, removed, and the subsurface was investigated. A figure identifying the location of the fire training area, laboratory analytical results and a summary table are included in Attachment B. There were no exceedances of applicable 2022 NMED screening levels.

 Attachment A. Response to the New Mexico Environment Department (INNED) To Western Renning Southwest ELC (D/B/A Marathon Gallup Refinery [Refinery]) Disapproval Letter for OW-63 PFAS Investigation Work Plan [Revised] (Feb. 8, 2024)

 NMED Comments
 Refinery Responses

 Comment 5:
 Response 5:

Comment 5:	Response 5:
In the response to NMED's Disapproval Comment 12, the	This comment has been acknowledged and addressed.
Permittee states, "[screening levels have not been added to	Table 2-3 has been revised to include NMED's 2022 RAG
Table 2-3. A laboratory has not been selected for the	screening levels and a note has been added that says "Screening
investigation and screening levels may be changed before the	levels from NMED's 2022 Risk Assessment Guidance have
sampling event occurs." The Permittee's response is not	been included. The most current screening levels will be
acceptable. Applicable screening levels for PFAS in the revised	included in the investigation report."
Work Plan should be based on NMED's 2022 Risk Assessment	
Guidance (RAG). If NMED updates the screening levels for	
PFAS during the course of this investigation, the Permittee must	
utilize the most updated screening levels for risk evaluation at	
that time. Revise Table 2-3 to include the applicable screening	
levels for PFAS based on NMED's 2022 RAG. Include a note	
that Table 2-3 will be updated with the most current screening	
levels if NMED's RAG is updated.	

NMED Comments	Refinery Responses
Comment 6:	Response 6:
the necessity to collect TPH soil samples and provide directions	 Western Refining So Natural Attenuation I Western Refining So Natural Attenuation I Western Refining So
	 Western Refining Southwest LLC - Area of Concern 26 – Process Units and Area of Concern 27 – Boiler and Cooling Unit Area Investigation Report. January 2024 Western Refining Southwest LLC – 2015 through 2022 Annual Monitored Natural Attenuation Report. 2016-2023.

ATTACHMENT B

SUPPORTING DOCUMENTS

JULY 2023 FIRE TRAINING AREA SOIL INVESTIGATION

WESTERN REFINING SOUTHWEST LLC, D/B/A MARATHON GALLUP REFINERY, GALLUP, NEW MEXICO

		NEtFOSAA	NMeFOSAA	PFBS	PFBA	PFDS	
Location	Sample Date	(µg/kg)	(µg/kg)	(µg/kg)	(µg/kg)	(µg/kg)	
SS-5	7/26/23	ND(0.21)	ND(0.21)	0.65	9.3	ND(0.21)	
SS-6	7/26/23	ND(0.22)	ND(0.22)	ND(0.22)	0.46	ND(0.22)	
SS-7	7/26/23	ND(0.22)	ND(0.22)	0.13	8.5	ND(0.22)	
SS-8 Dup	7/26/23	ND(0.2)	ND(0.2)	1.3	63	0.15	
SS-8	7/26/23	ND(0.2)	ND(0.2)	1.4	65	0.12	
2022 Construction	on NMED SSL	NA	NA	80700	NA	NA	
2022 Residential NMED SSL		NA	NA	18500	NA	NA	
2022 Industrial N	IMED SSL	NA	NA	374000	NA	NA	

µg/kg - micrograms per kilogram Dup - blind duplicate NA - Not applicable ND(X) - Not detected at the reporting limit X NEtFOSAA - N-ethyl perf sulf acid NMED - New Mexico Environment Department NMeFOSAA - N-methyl perf sulf acid PFBS - Perfluorobutanesulfonic acid PFBA - Perfluorobutanoic acid PFDS - Perfluorodecanesulfonic acid PFDA - Perfluorodecanoic acid PFDoA - Perfluorododecanoic acid PFHpS - Perfluoroheptanesulfonic Acid PFHpA - Perfluoroheptanoic acid PFHxS - Perfluorohexanesulfonic acid PFHxA - Perfluorohexanoic acid PFNS - Perfluorononanesulfonic acid PFNA - Perfluorononanoic acid FOSA - Perfluorooctane Sulfonamide PFOS - Perfluorooctanesulfonic acid PFOA - Perfluorooctanoic acid PFPeS - Perfluoropentanesulfonic acid PFPA - Perfluoropentanoic acid PFTeA - Perfluorotetradecanoic acid PFTriA - Perfluorotridecanoic Acid PFUnA - Perfluoroundecanoic acid SSL - Soil screening level

Page 11 of 166

Received by OCD: 4/16/2024 4:15:20 PM

JULY 2023 FIRE TRAINING AREA SOIL INVESTIGATION

WESTERN REFINING SOUTHWEST LLC, D/B/A MARATHON GALLUP REFINERY, GALLUP, NEW MEXICO

		PFDA	PFDoA	PFHpS	PFHpA	PFHxS	
Location	Sample Date	(µg/kg)	(µg/kg)	(µg/kg)	(µg/kg)	(µg/kg)	
SS-5	7/26/23	5	2.3	0.97	11	12	
SS-6	7/26/23	2.8	0.064	0.13	0.78	0.63	
SS-7	7/26/23	1.3	ND(0.22)	0.16	16	1.9	
SS-8 Dup	7/26/23	12	9.3	1	58	12	
SS-8	7/26/23	13	11	1.2	59	14	
2022 Constructio	on NMED SSL	NA	NA	NA	NA	5381	
2022 Residential NMED SSL		NA	NA	NA	NA	1233	
2022 Industrial N	IMED SSL	NA	NA	NA	NA	24920	

µg/kg - micrograms per kilogram Dup - blind duplicate NA - Not applicable ND(X) - Not detected at the reporting limit X NEtFOSAA - N-ethyl perf sulf acid NMED - New Mexico Environment Department NMeFOSAA - N-methyl perf sulf acid PFBS - Perfluorobutanesulfonic acid PFBA - Perfluorobutanoic acid PFDS - Perfluorodecanesulfonic acid PFDA - Perfluorodecanoic acid PFDoA - Perfluorododecanoic acid PFHpS - Perfluoroheptanesulfonic Acid PFHpA - Perfluoroheptanoic acid PFHxS - Perfluorohexanesulfonic acid PFHxA - Perfluorohexanoic acid PFNS - Perfluorononanesulfonic acid PFNA - Perfluorononanoic acid FOSA - Perfluorooctane Sulfonamide PFOS - Perfluorooctanesulfonic acid PFOA - Perfluorooctanoic acid PFPeS - Perfluoropentanesulfonic acid PFPA - Perfluoropentanoic acid PFTeA - Perfluorotetradecanoic acid PFTriA - Perfluorotridecanoic Acid PFUnA - Perfluoroundecanoic acid SSL - Soil screening level

ENFLECTION

Released to Imaging: 7/25/2024 3:37:45 PM

JULY 2023 FIRE TRAINING AREA SOIL INVESTIGATION

WESTERN REFINING SOUTHWEST LLC, D/B/A MARATHON GALLUP REFINERY, GALLUP, NEW MEXICO

PFHxA	PFNS	PFNA	FOSA	PFOS	
(µg/kg)	(µg/kg)	(µg/kg)	(µg/kg)	(µg/kg)	
35	0.074	29	0.098	99	
1.1	ND(0.22)	6.7	ND(0.22)	20	
28	ND(0.22)	11	ND(0.22)	33	
120	0.22	24	0.38	160	
140	0.22	26	0.38	150	
NA	NA	807	NA	807	
NA	NA	185	NA	185	
NA	NA	3740	NA	3740	
	140 NA NA	140 0.22 NA NA NA NA	140 0.22 26 NA NA 807 NA NA 185	140 0.22 26 0.38 NA NA 807 NA NA NA 185 NA	1400.22260.38150NANA807NA807NANA185NA185

µg/kg - micrograms per kilogram Dup - blind duplicate NA - Not applicable ND(X) - Not detected at the reporting limit X NEtFOSAA - N-ethyl perf sulf acid NMED - New Mexico Environment Department NMeFOSAA - N-methyl perf sulf acid PFBS - Perfluorobutanesulfonic acid PFBA - Perfluorobutanoic acid PFDS - Perfluorodecanesulfonic acid PFDA - Perfluorodecanoic acid PFDoA - Perfluorododecanoic acid PFHpS - Perfluoroheptanesulfonic Acid PFHpA - Perfluoroheptanoic acid PFHxS - Perfluorohexanesulfonic acid PFHxA - Perfluorohexanoic acid PFNS - Perfluorononanesulfonic acid PFNA - Perfluorononanoic acid FOSA - Perfluorooctane Sulfonamide PFOS - Perfluorooctanesulfonic acid PFOA - Perfluorooctanoic acid PFPeS - Perfluoropentanesulfonic acid PFPA - Perfluoropentanoic acid PFTeA - Perfluorotetradecanoic acid PFTriA - Perfluorotridecanoic Acid PFUnA - Perfluoroundecanoic acid SSL - Soil screening level

Released to Imaging: 7/25/2024 3:37:45 PM

Page 13 of 166

JULY 2023 FIRE TRAINING AREA SOIL INVESTIGATION

WESTERN REFINING SOUTHWEST LLC, D/B/A MARATHON GALLUP REFINERY, GALLUP, NEW MEXICO

		PFOA	PFPeS	PFPA	PFTeA	PFTriA
Location	Sample Date	(µg/kg)	(µg/kg)	(µg/kg)	(µg/kg)	(µg/kg)
SS-5	7/26/23	25	0.72	49	2.9	8.3
SS-6	7/26/23	2.1	0.044	2	0.043	1.5
SS-7	7/26/23	21	0.15	51	ND(0.22)	ND(0.22)
SS-8 Dup	7/26/23	43	1.5	250	8.8	63
SS-8	7/26/23	50	1.7	290	10	75
2022 Construction	on NMED SSL	2691000	NA	NA	NA	NA
2022 Residential NMED SSL		76080	NA	NA	NA	NA
2022 Industrial N	NMED SSL	498400	NA	NA	NA	NA

µg/kg - micrograms per kilogram Dup - blind duplicate

NA - Not applicable

Released to Imaging: 7/25/2024 3:37:45 PM

ND(X) - Not detected at the reporting limit X NEtFOSAA - N-ethyl perf sulf acid NMED - New Mexico Environment Department NMeFOSAA - N-methyl perf sulf acid PFBS - Perfluorobutanesulfonic acid PFBA - Perfluorobutanoic acid PFDS - Perfluorodecanesulfonic acid PFDA - Perfluorodecanoic acid PFDoA - Perfluorododecanoic acid PFHpS - Perfluoroheptanesulfonic Acid PFHpA - Perfluoroheptanoic acid PFHxS - Perfluorohexanesulfonic acid PFHxA - Perfluorohexanoic acid PFNS - Perfluorononanesulfonic acid PFNA - Perfluorononanoic acid FOSA - Perfluorooctane Sulfonamide PFOS - Perfluorooctanesulfonic acid PFOA - Perfluorooctanoic acid PFPeS - Perfluoropentanesulfonic acid PFPA - Perfluoropentanoic acid PFTeA - Perfluorotetradecanoic acid PFTriA - Perfluorotridecanoic Acid PFUnA - Perfluoroundecanoic acid SSL - Soil screening level

JULY 2023 FIRE TRAINING AREA SOIL INVESTIGATION

WESTERN REFINING SOUTHWEST LLC, D/B/A MARATHON GALLUP REFINERY, GALLUP, NEW MEXICO

		PFUnA	
Location	Sample Date	(µg/kg)	
SS-5	7/26/23	17	
SS-6	7/26/23	1.7	
SS-7	7/26/23	ND(0.22)	
SS-8 Dup	7/26/23	66	
SS-8	7/26/23	59	
2022 Construction	NA		
2022 Residential N	NA		
2022 Industrial NM	ED SSL	NA	

µg/kg - micrograms per kilogram Dup - blind duplicate NA - Not applicable ND(X) - Not detected at the reporting limit X NEtFOSAA - N-ethyl perf sulf acid NMED - New Mexico Environment Department NMeFOSAA - N-methyl perf sulf acid PFBS - Perfluorobutanesulfonic acid PFBA - Perfluorobutanoic acid PFDS - Perfluorodecanesulfonic acid PFDA - Perfluorodecanoic acid PFDoA - Perfluorododecanoic acid PFHpS - Perfluoroheptanesulfonic Acid PFHpA - Perfluoroheptanoic acid PFHxS - Perfluorohexanesulfonic acid PFHxA - Perfluorohexanoic acid PFNS - Perfluorononanesulfonic acid PFNA - Perfluorononanoic acid FOSA - Perfluorooctane Sulfonamide PFOS - Perfluorooctanesulfonic acid PFOA - Perfluorooctanoic acid PFPeS - Perfluoropentanesulfonic acid PFPA - Perfluoropentanoic acid PFTeA - Perfluorotetradecanoic acid PFTriA - Perfluorotridecanoic Acid PFUnA - Perfluoroundecanoic acid SSL - Soil screening level

Released to Imaging: 7/25/2024 3:37:45 PM

EXPLANATION

● ^{BW-5B} 6865.82	CHINLE / ALLUVIUM AQUIFER WELL AND DESIGNATION (SHOWING GROUNDWATER ELEVATION IN FEET ABOVE MEAN SEA LEVEL)
- 6860	LINE OF EQUAL ELEVATION OF POTENTIOMETRIC SURFACE (FEET ABOVE MEAN SEA LEVEL, DASHED WHERE INFERRED)
	ESTIMATED GROUNDWATER FLOW DIRECTION
● MKTF-06	SPH MONITORING WELL AND DESIGNATION
⊕ RW-1	RECOVERY WELL
₩ MKTF-17	MONITORING WELL AND DESIGNATION - PLUGGED AND ABANDONED
NM	NOT MEASURED
SPH	SEPARATE-PHASE HYDROCARBON
PFOS	PER- AND POLYFLUOROALKYL SUBSTANCES

NOTES:

- POTENTIOMETRIC SURFACE GENERATED USING 3RD QUARTER 2024 ANNUAL MONITORING EVENT DATA.
 ALL CONCENTRATIONS ARE REPORTED IN NANOGRAMS PER LITER (ng/L)



Image Cite: DigitalGlobe © CNES (2023) Distribution Airbus DS © Microsoft Corporation, BING Imagery

- 1 = EPA IDENTIFIED PFOS COC
- 1 = EPA IDENTIFIED PFOS COC
 2 = NMED IDENTIFIED PFOS COC
 3 = NOT AN EPA/NMED PFOS COC; HOWEVER, HIGH MOBILITY. DATA PROVIDED FOR INFORMATION
 4 = NEW MEXICO ENVIRONMENT DEPARTMENT, RISK ASSESSMENT GUIDANCE FOR SITE INVESTIGATIONS AND REMEDIATION, VOLUME I, SOIL SCREENING GUIDANCE FOR HUMAN HEALTH RISK ASSESSMENTS, APPENDIX E, NOVEMBER 2021
 5 = HTTPS://WWW.EPA.GOV/SYSTEM/FILES/DOCUMENTS/2022/06/PREPUBLICATION-FOR.PFAS-JUNE-2022.PDF
 6 = HTTPS://WWW.TRIHYDRO.COM/NEWS/NEWS-DETAILS//2022/06/15/EPA-ANNOUNCES-NEW-HEALTH-ADVISORY-LEVELS-FOR-PFAS-%241B-IN-FUNDING
 7 = NOT SAMPLED AT GALLUP REFINERY





	FIGURE 1							
D	FIRE TRAINING AREA							
ľ		WESTERN	I REFINING S	OUTHWEST LLC				
)				LLUP REFINERY				
729	GALLUP, NEW MEXICO							
ed E	d By: AW Scale: 1" = 100' Date: 6/20/2023 File: 697_MG-FTA-PS-202306							

Received by OCD: 4/16/2024 4:15:20 PM



Environment Testing

ANALYTICAL REPORT

PREPARED FOR

Attn: Aaron Wiggins Trihydro Corporation 1252 Commerce Drive Laramie, Wyoming 82070 Generated 8/14/2023 10:22:42 PM

JOB DESCRIPTION

FTA- PFAS, Marathon Gallup Refinery, NM

JOB NUMBER

320-102972-1

Eurofins Sacramento 880 Riverside Parkway West Sacramento CA 95605

See page two for job notos and contact information

5 6 7

Eurofins Sacramento

Job Notes

This report may not be reproduced except in full, and with written approval from the laboratory. The results relate only to the samples tested. For questions please contact the Project Manager at the e-mail address or telephone number listed on this page.

The test results in this report relate only to the samples as received by the laboratory and will meet all requirements of the methodology, with any exceptions noted. This report shall not be reproduced except in full, without the express written approval of the laboratory. All questions should be directed to the Eurofins Environment Testing Northern California, LLC Project Manager.

Authorization

Lana

Generated 8/14/2023 10:22:42 PM

Authorized for release by Criselda Caparas, Project Manager I <u>Criselda.Caparas@et.eurofinsus.com</u> (925)484-1919

Eurofins Sacramento is a laboratory within Eurofins Environment Testing Northern California, LLC, a company within Eurofins Environment Testing Group of Companies

Page 19 of 166

Table of Contents

Cover Page	1
Table of Contents	3
Definitions/Glossary	4
Case Narrative	5
Detection Summary	6
Client Sample Results	9
Isotope Dilution Summary	18
QC Sample Results	22
QC Association Summary	28
Lab Chronicle	30
Certification Summary	33
Method Summary	34
Sample Summary	35
Chain of Custody	36
Receipt Checklists	37

Definitions/Glossary

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

Qualifiers

LCMS Qualifier	Qualifier Description
*5+	Isotope dilution analyte is outside acceptance limits, high biased.
I	Value is EMPC (estimated maximum possible concentration).
J	Result is less than the RL but greater than or equal to the MDL and the concentration is an approximate value.

Glossary

Abbreviation	These commonly used abbreviations may or may not be present in this report.
	Listed under the "D" column to designate that the result is reported on a dry weight basis
~ %R	Percent Recovery
CFL	Contains Free Liquid
CFU	Colony Forming Unit
CNF	Contains No Free Liquid
DER	·
DER Dil Fac	Duplicate Error Ratio (normalized absolute difference) Dilution Factor
DIFAC	
	Detection Limit (DoD/DOE)
DL, RA, RE, IN DLC	Indicates a Dilution, Re-analysis, Re-extraction, or additional Initial metals/anion analysis of the sample
	Decision Level Concentration (Radiochemistry)
EDL	Estimated Detection Limit (Dioxin)
LOD	Limit of Detection (DoD/DOE)
LOQ	Limit of Quantitation (DoD/DOE)
MCL	EPA recommended "Maximum Contaminant Level"
MDA	Minimum Detectable Activity (Radiochemistry)
MDC	Minimum Detectable Concentration (Radiochemistry)
MDL	Method Detection Limit
ML	Minimum Level (Dioxin)
MPN	Most Probable Number
MQL	Method Quantitation Limit
NC	Not Calculated
ND	Not Detected at the reporting limit (or MDL or EDL if shown)
NEG	Negative / Absent
POS	Positive / Present
PQL	Practical Quantitation Limit
PRES	Presumptive
QC	Quality Control
RER	Relative Error Ratio (Radiochemistry)
RL	Reporting Limit or Requested Limit (Radiochemistry)
RPD	Relative Percent Difference, a measure of the relative difference between two points
TEF	Toxicity Equivalent Factor (Dioxin)
TEQ	Toxicity Equivalent Quotient (Dioxin)
TNTC	Too Numerous To Count

3

5

Job ID: 320-102972-1

Case Narrative

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

Job ID: 320-102972-1

Laboratory: Eurofins Sacramento

Narrative

Job Narrative 320-102972-1

Comments

No additional comments.

Receipt

The samples were received on 7/27/2023 9:40 AM. Unless otherwise noted below, the samples arrived in good condition, and where required, properly preserved and on ice. The temperature of the cooler at receipt was 3.9° C.

LCMS

Method 537 (modified): The "I" qualifier means the transition mass ratio for the indicated analyte was above the established ratio limits. The qualitative identification of the analyte has some degree of uncertainty, and the reported value may have some high bias. However, analyst judgment was used to positively identify the analyte.

SS-6 (320-102972-2) and SS-8 (320-102972-4)

Method 537 (modified): Isotope Dilution Analyte (IDA) recovery is above the method recommended limit for the following sample: SS-8 (320-102972-4). Quantitation by isotope dilution generally precludes any adverse effect on data quality due to elevated IDA recoveries.

Method 537 (modified): Results for samples SS-5 (320-102972-1), SS-6 (320-102972-2), SS-7 (320-102972-3), SS-8 (320-102972-4) and Dup-1 (320-102972-5) were reported from the analysis of a diluted extract due to high concentration of the target analyte in the analysis of the undiluted extract. The dilution factor was applied to the labeled internal standard area counts and these area counts were within acceptance limits

No additional analytical or quality issues were noted, other than those described above or in the Definitions/Glossary page.

General Chemistry

No analytical or quality issues were noted, other than those described in the Definitions/Glossary page.

Organic Prep

Method 3535: Insufficient sample volume was available to perform a matrix spike/matrix spike duplicate (MS/MSD) associated with preparation batch 320-696655.

No additional analytical or quality issues were noted, other than those described above or in the Definitions/Glossary page.

Job ID: 320-102972-1

Detection Summary

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

Client Sample ID: SS-5

Analyte	Result	Qualifier	RL	MDL	Unit	Dil Fac	D	Method	Prep Type
Perfluorobutanoic acid (PFBA)	9.3		0.21	0.048	ug/Kg	1	☆	537 (modified)	Total/NA
Perfluoroheptanoic acid (PFHpA)	11		0.21	0.040	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorodecanoic acid (PFDA)	5.0		0.21	0.050	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluoroundecanoic acid (PFUnA)	17		0.21	0.044	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorododecanoic acid (PFDoA)	2.3		0.21	0.031	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorotetradecanoic acid (PFTeA)	2.9		0.21	0.038	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorobutanesulfonic acid (PFBS)	0.65		0.21	0.040	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluoropentanesulfonic acid (PFPeS)	0.72		0.21	0.038	ug/Kg	1	¢	537 (modified)	Total/NA
Perfluorohexanesulfonic acid (PFHxS)	12		0.21	0.030	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluoroheptanesulfonic acid (PFHpS)	0.97		0.21	0.051	ug/Kg	1	¢	537 (modified)	Total/NA
Perfluorononanesulfonic acid (PFNS)	0.074	J	0.21	0.030	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorooctanesulfonamide (FOSA)	0.098	J	0.21	0.034	ug/Kg	1	₽	537 (modified)	Total/NA
4:2 FTS	0.11	J	0.21	0.053	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluoropentanoic acid (PFPeA) - DL	49		4.2	0.85	ug/Kg	20	¢	537 (modified)	Total/NA
Perfluorohexanoic acid (PFHxA) - DL	35		4.2	0.64	ug/Kg	20	¢	537 (modified)	Total/NA
Perfluorooctanoic acid (PFOA) - DL	25		4.2	1.1	ug/Kg	20	₽	537 (modified)	Total/NA
Perfluorononanoic acid (PFNA) - DL	29		4.2	0.46	ug/Kg	20	₽	537 (modified)	Total/NA
Perfluorotridecanoic acid (PFTrDA) - DL	8.3		4.2	0.44	ug/Kg	20	¢	537 (modified)	Total/NA
Perfluorooctanesulfonic acid (PFOS) - DL	99		4.2	0.89	ug/Kg	20	¢	537 (modified)	Total/NA
6:2 FTS - DL	190		4.2	0.56	ug/Kg	20	₽	537 (modified)	Total/NA
8:2 FTS - DL	160		4.2	0.73	ug/Kg	20	₽	537 (modified)	Total/NA

Client Sample ID: SS-6

Lab Sample ID: 320-102972-2

Analyte	Result	Qualifier	RL	MDL	Unit	Dil Fac	D	Method	Prep Type
Perfluorobutanoic acid (PFBA)	0.46		0.22	0.051	ug/Kg	1	☆	537 (modified)	Total/NA
Perfluoropentanoic acid (PFPeA)	2.0		0.22	0.045	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorohexanoic acid (PFHxA)	1.1		0.22	0.034	ug/Kg	1	¢	537 (modified)	Total/NA
Perfluoroheptanoic acid (PFHpA)	0.78		0.22	0.042	ug/Kg	1	☆	537 (modified)	Total/NA
Perfluorooctanoic acid (PFOA)	2.1		0.22	0.059	ug/Kg	1	¢	537 (modified)	Total/NA
Perfluorononanoic acid (PFNA)	6.7		0.22	0.024	ug/Kg	1	¢	537 (modified)	Total/NA
Perfluorodecanoic acid (PFDA)	2.8		0.22	0.053	ug/Kg	1	¢	537 (modified)	Total/NA
Perfluoroundecanoic acid (PFUnA)	1.7	I	0.22	0.047	ug/Kg	1	¢	537 (modified)	Total/NA
Perfluorododecanoic acid (PFDoA)	0.064	J	0.22	0.033	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorotridecanoic acid (PFTrDA)	1.5	1	0.22	0.023	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorotetradecanoic acid (PFTeA)	0.043	J	0.22	0.041	ug/Kg	1	¢	537 (modified)	Total/NA
Perfluoropentanesulfonic acid (PFPeS)	0.044	J	0.22	0.041	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorohexanesulfonic acid (PFHxS)	0.63		0.22	0.032	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluoroheptanesulfonic acid (PFHpS)	0.13	J	0.22	0.054	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorooctanesulfonic acid (PFOS)	20		0.22	0.048	ug/Kg	1	¢	537 (modified)	Total/NA
6:2 FTS - DL	15		2.2	0.30	ug/Kg	10	₽	537 (modified)	Total/NA
8:2 FTS - DL	38		2.2	0.39	ug/Kg	10	₽	537 (modified)	Total/NA
Client Sample ID: SS-7						Lab Sa	an	nple ID: 320	-102972-3

Analyte	Result	Qualifier	RL	MDL	Unit	Dil Fac	D	Method	Prep 1	Гуре
Perfluorobutanoic acid (PFBA)	8.5		0.22	0.051	ug/Kg	1	☆	537 (modified)	Total/N	NA A

This Detection Summary does not include radiochemical test results.

Eurofins Sacramento

Perfluoroheptanoic acid (PFHpA) Perfluorooctanoic acid (PFOA) Perfluorononanoic acid (PFNA) Perfluorodecanoic acid (PFDA) Perfluorobutanesulfonic acid (PFBS)

Perfluoropentanesulfonic acid

Perfluorohexanesulfonic acid (PFHxS) Perfluoroheptanesulfonic acid

Analyte

(PFPeS)

(PFHpS)

Detection Summary

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

Re

Client Sample ID: SS-7 (Continued)

Lab Sample ID: 320-102972-3

Result	Qualifier	RL	MDL	Unit	Dil Fac	D	Method	Prep Type	
16		0.22	0.042	ug/Kg	1	¢	537 (modified)	Total/NA	
21		0.22	0.059	ug/Kg	1	¢	537 (modified)	Total/NA	
11		0.22	0.024	ug/Kg	1	¢	537 (modified)	Total/NA	5
1.3		0.22	0.053	ug/Kg	1	¢	537 (modified)	Total/NA	
0.13	J	0.22	0.042	ug/Kg	1	¢	537 (modified)	Total/NA	
0.15	J	0.22	0.041	ug/Kg	1	₽	537 (modified)	Total/NA	
1.9 0.16	J	0.22 0.22		ug/Kg ug/Kg			537 (modified) 537 (modified)	Total/NA Total/NA	7
51		2.2	0.45	ug/Kg	10		537 (modified)	Total/NA	
28		2.2	0.34	ug/Kg	10	₽	537 (modified)	Total/NA	9
33		2.2	0.47	ug/Kg	10	₽	537 (modified)	Total/NA	
78		2.2	0.30	ug/Kg	10	¢	537 (modified)	Total/NA	
30		2.2	0.39	ug/Kg	10	₽	537 (modified)	Total/NA	
					l ah S	am	nlo ID: 320	102972_4	

Lab Sample ID: 320-1029/2-4

Analyte	Result	Qualifier	RL	MDL	Unit	Dil Fac	D	Method	Prep Type
Perfluorodecanoic acid (PFDA)	13		0.20	0.048	ug/Kg	1	¢	537 (modified)	Total/NA
Perfluorododecanoic acid (PFDoA)	11		0.20	0.030	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorotetradecanoic acid (PFTeA)	10	I	0.20	0.037	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorobutanesulfonic acid (PFBS)	1.4		0.20	0.038	ug/Kg	1	¢	537 (modified)	Total/NA
Perfluoropentanesulfonic acid (PFPeS)	1.7		0.20	0.037	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorohexanesulfonic acid (PFHxS)	14		0.20	0.029	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluoroheptanesulfonic acid (PFHpS)	1.2		0.20	0.049	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorononanesulfonic acid (PFNS)	0.22		0.20	0.029	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorodecanesulfonic acid (PFDS)	0.12	J	0.20	0.052	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorooctanesulfonamide (FOSA)	0.38		0.20	0.033	ug/Kg	1	₽	537 (modified)	Total/NA
4:2 FTS	0.17	J	0.20	0.051	ug/Kg	1	₽	537 (modified)	Total/NA
Perfluorobutanoic acid (PFBA) - DL	65		10	2.3	ug/Kg	50	₽	537 (modified)	Total/NA
Perfluoropentanoic acid (PFPeA) - DL	290		10	2.0	ug/Kg	50	₽	537 (modified)	Total/NA
Perfluorohexanoic acid (PFHxA) - DL	140		10	1.5	ug/Kg	50	₽	537 (modified)	Total/NA
Perfluoroheptanoic acid (PFHpA) - DL	59		10	1.9	ug/Kg	50	₽	537 (modified)	Total/NA
Perfluorooctanoic acid (PFOA) - DL	50		10	2.6	ug/Kg	50	₽	537 (modified)	Total/NA
Perfluorononanoic acid (PFNA) - DL	26		10	1.1	ug/Kg	50	₽	537 (modified)	Total/NA
Perfluoroundecanoic acid (PFUnA) - DL	59		10	2.1	ug/Kg	50	₽	537 (modified)	Total/NA
Perfluorotridecanoic acid (PFTrDA) - DL	75		10	1.0	ug/Kg	50	¢	537 (modified)	Total/NA
Perfluorooctanesulfonic acid (PFOS) - DL	150		10	2.1	ug/Kg	50	₽	537 (modified)	Total/NA
6:2 FTS - DL	240		10	1.3	ug/Kg	50	₽	537 (modified)	Total/NA
8:2 FTS - DL	260		10	1.7	ug/Kg	50	₽	537 (modified)	Total/NA

Client Sample ID: Dup-1

Analyte	Result Qualifier	RL	MDL	Unit	Dil Fac	D	Method	Prep Type
Perfluorodecanoic acid (PFDA)	12	0.20	0.049	ug/Kg	1	¢	537 (modified)	Total/NA
Perfluorododecanoic acid (PFDoA)	9.3	0.20	0.030	ug/Kg	1	¢	537 (modified)	Total/NA
Perfluorotetradecanoic acid (PFTeA)	8.8	0.20	0.037	ug/Kg	1	₽	537 (modified)	Total/NA

This Detection Summary does not include radiochemical test results.

Eurofins Sacramento

Lab Sample ID: 320-102972-5

Perfluorobutanesulfonic acid (PFBS)

Perfluorohexanesulfonic acid (PFHxS)

Perfluorononanesulfonic acid (PFNS)

Perfluorodecanesulfonic acid (PFDS)

Perfluorooctanesulfonamide (FOSA)

Perfluorobutanoic acid (PFBA) - DL

Perfluoropentanoic acid (PFPeA) - DL

Perfluorohexanoic acid (PFHxA) - DL

Perfluoroheptanoic acid (PFHpA) - DL

Perfluorooctanoic acid (PFOA) - DL

Perfluorononanoic acid (PFNA) - DL

Perfluoroundecanoic acid (PFUnA) -

Perfluorotridecanoic acid (PFTrDA) -

Perfluorooctanesulfonic acid (PFOS) -

Perfluoropentanesulfonic acid

Perfluoroheptanesulfonic acid

Detection Summary

RL

0.20

0.20

0.20

0.20

0.20

0.20

0.20

0.20

10

10

10

10

10

10

10

10

10

10

10

MDL Unit

0.038 ug/Kg

0.037 ug/Kg

0.029 ug/Kg

0.050 ug/Kg

0.029 ug/Kg

0.053 ug/Kg

0.033 ug/Kg

0.052 ug/Kg

2.1

1.6

1.9

2.7

2.1

2.3 ug/Kg

ug/Kg

ug/Kg

ug/Kg

ug/Kg

ug/Kg

1.1 ug/Kg

1.1 ug/Kg

2.2 ug/Kg

1.4 ug/Kg

1.8 ug/Kg

Result Qualifier

1.3

1.5

12

1.0

0.22

0.15 J

0.38

0.20

63

250

120

58

43

24

66

63

160

200

280

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

Client Sample ID: Dup-1 (Continued)

Prep Type

Total/NA

Lab Sample ID: 320-102972-5

537 (modified)

🌣 537 (modified)

50 🌣 537 (modified)

50 🌣 537 (modified)

Dil Fac D Method

1 ☆

1 🌣

1 ☆

1 ☆

1 ☆

1 ☆

1 ☆

1 ☆

50 🌣

50 🌣

50 🌣

50 🌣

50 🌣

50 🌣

50 🌣

50

50 🌣

5
8
9
13

Lab Sample ID: 320-102972-6

No Detections.

6:2 FTS - DL

8:2 FTS - DL

Analyte

(PFPeS)

(PFHpS)

4:2 FTS

DL

DL

DL

Client Sample ID: FB-1

Client Sample ID: EB-1

Lab Sample ID: 320-102972-7

No Detections.

This Detection Summary does not include radiochemical test results.

Eurofins Sacramento

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

Client Sample ID: SS-5 Date Collected: 07/26/23 10:50 Date Received: 07/27/23 09:40

Analyte		Qualifier	RL		Unit	D	Prepared	Analyzed	Dil Fac
Perfluorobutanoic acid (PFBA)	9.3		0.21		ug/Kg	¢	08/03/23 21:41	08/04/23 23:04	1
Perfluoroheptanoic acid (PFHpA)	11		0.21		ug/Kg	₽	08/03/23 21:41	08/04/23 23:04	1
Perfluorodecanoic acid (PFDA)	5.0		0.21	0.050	ug/Kg	¢	08/03/23 21:41	08/04/23 23:04	1
Perfluoroundecanoic acid (PFUnA)	17		0.21	0.044	ug/Kg	¢	08/03/23 21:41	08/04/23 23:04	1
(PFOIIA) Perfluorododecanoic acid	2.3		0.21	0.031	ug/Kg	÷	08/03/23 21:41	08/04/23 23:04	1
(PFDoA)	2.5		0.21	0.001	ug/itg	ж	00/03/23 21.41	00/04/23 23.04	
Perfluorotetradecanoic acid	2.9		0.21	0.038	ug/Kg	¢	08/03/23 21:41	08/04/23 23:04	1
(PFTeA)									
Perfluorobutanesulfonic acid	0.65		0.21	0.040	ug/Kg	¢	08/03/23 21:41	08/04/23 23:04	1
(PFBS)			<u> </u>	0.000	117		00/00/00 04 55	00/04/02 02 6 5	
Perfluoropentanesulfonic acid (PFPeS)	0.72		0.21	0.038	ug/Kg	¢	08/03/23 21:41	08/04/23 23:04	1
(PFPeS) Perfluorohexanesulfonic acid	12		0.21	0.030	ug/Kg	÷	08/03/23 21.41	08/04/23 23:04	1
(PFHxS)	12		0.21	0.000	-9/119	~	55,00/L0 L1.41	00.0 1120 20.04	
Perfluoroheptanesulfonic acid	0.97		0.21	0.051	ug/Kg	¢	08/03/23 21:41	08/04/23 23:04	1
(PFHpS)									
Perfluorononanesulfonic acid	0.074	J	0.21	0.030	ug/Kg	¢	08/03/23 21:41	08/04/23 23:04	1
(PFNS)			0.04	0.054			00/02/02 04 44	00/04/00 00 01	4
Perfluorodecanesulfonic acid (PFDS)	ND		0.21		ug/Kg		08/03/23 21:41		1
Perfluorooctanesulfonamide (FOSA)	0.098	J	0.21	0.034	ug/Kg	¢	08/03/23 21:41	08/04/23 23:04	1
(FOSA) NMeFOSAA	ND		0.21	0 024	ug/Kg	÷	08/03/23 21:41	08/04/23 23:04	1
NEtFOSAA	ND		0.21		ug/Kg ug/Kg	÷	08/03/23 21:41		1
4:2 FTS	0.11	J	0.21		ug/Kg		08/03/23 21:41		
Isotope Dilution	%Recovery		Limits		.99		Prepared	Analyzed	Dil Fac
13C4 PFBA	71		25 - 150					08/04/23 23:04	1
13C4 PFHpA	78		25 - 150					08/04/23 23:04	1
13C2 PFDA	68		25 - 150					08/04/23 23:04	1
13C2 PFUnA	71		25 - 150					08/04/23 23:04	
13C2 PFDoA	67		25 - 150					08/04/23 23:04	1
13C2 PFTeDA	67		25 - 150					08/04/23 23:04	1
13C3 PFBS	77		25 - 150					08/04/23 23:04	1
1802 PFHxS	75		25 - 150					08/04/23 23:04	1
13C4 PFOS	93		25 - 150					08/04/23 23:04	1
13C8 FOSA	80		25 - 150					08/04/23 23:04	1
d3-NMeFOSAA	29		25 - 150					08/04/23 23:04	1
d5-NEtFOSAA	32		25 - 150					08/04/23 23:04	1
M2-4:2 FTS	64		25 - 150					08/04/23 23:04	1

Analyte	Result Qualifier	RL	MDL	Unit	D	Prepared	Analyzed	Dil Fac
Perfluoropentanoic acid (PFPeA)	49	4.2	0.85	ug/Kg	₽	08/03/23 21:41	08/07/23 23:54	20
Perfluorohexanoic acid (PFHxA)	35	4.2	0.64	ug/Kg	¢	08/03/23 21:41	08/07/23 23:54	20
Perfluorooctanoic acid (PFOA)	25	4.2	1.1	ug/Kg	¢	08/03/23 21:41	08/07/23 23:54	20
Perfluorononanoic acid (PFNA)	29	4.2	0.46	ug/Kg	¢	08/03/23 21:41	08/07/23 23:54	20
Perfluorotridecanoic acid (PFTrDA)	8.3	4.2	0.44	ug/Kg	¢	08/03/23 21:41	08/07/23 23:54	20
Perfluorooctanesulfonic acid (PFOS)	99	4.2	0.89	ug/Kg	¢	08/03/23 21:41	08/07/23 23:54	20
6:2 FTS	190	4.2	0.56	ug/Kg		08/03/23 21:41	08/07/23 23:54	20
8:2 FTS	160	4.2	0.73	ug/Kg	¢	08/03/23 21:41	08/07/23 23:54	20

Eurofins Sacramento

Page 25 of 166

Matrix: Solid

Job ID: 320-102972-1

Percent Solids: 94.4

Lab Sample ID: 320-102972-1

Client Sample ID: SS-5

Isotope Dilution

13C5 PFPeA

13C2 PFHxA

13C4 PFOA

13C5 PFNA

13C2 PFDoA 13C4 PFOS

M2-6:2 FTS

M2-8:2 FTS

Analvte

Analyte

(PFUnA)

(PFDoA)

(PFTrDA)

(PFTeA)

(PFPeS)

(PFHxS)

(PFHpS)

(PFOS)

General Chemistry

Percent Moisture (ASTM D 2216)

Date Collected: 07/26/23 11:05

Date Received: 07/27/23 09:40

Perfluorobutanoic acid (PFBA)

Perfluoropentanoic acid (PFPeA)

Perfluorohexanoic acid (PFHxA)

Perfluoroheptanoic acid (PFHpA)

Perfluorooctanoic acid (PFOA)

Perfluorononanoic acid (PFNA)

Perfluorodecanoic acid (PFDA)

Perfluoroundecanoic acid

Perfluorododecanoic acid

Perfluorotridecanoic acid

Perfluorotetradecanoic acid

Perfluorobutanesulfonic acid (PFBS)

Perfluoropentanesulfonic acid

Perfluorohexanesulfonic acid

Perfluoroheptanesulfonic acid

Perfluorooctanesulfonic acid

Percent Solids (ASTM D 2216)

Client Sample ID: SS-6

Date Collected: 07/26/23 10:50

Date Received: 07/27/23 09:40

Client Sample Results

l imits

25 - 150

25 - 150

25 - 150

25 - 150

25 - 150

25 - 150

25 - 150

25 - 150

RL

0.1

0.1

RL

0.22

0.22

0.22

0.22

0.22

0.22

0.22

0.22

0.22

0.22

0.22

0.22

0.22

0.22

0.22

0.22

RL Unit

0.1 %

0.1 %

MDL Unit

0.051 ug/Kg

0.045 ug/Kg

0.034 ug/Kg

0.042 ug/Kg

0.033 ug/Kg

0.023 ug/Kg

0.041 ug/Kg

0.042 ug/Kg

0.041 ug/Kg

0.032 ug/Kg

0.054 ug/Kg

0.048 ug/Kg

ug/Kg

ug/Kg

ug/Kg

ug/Kg

0.059

0.024

0.053

0.047

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

%Recovery

66

66

65

79

73

89

108

99

5.6

94.4

Method: EPA 537 (modified) - Fluorinated Alkyl Substances

Result Qualifier

Result Qualifier

0.46

2.0

1.1

0.78

2.1

6.7

2.8

0.064 J

0.043 J

ND

0.044 J

0.63

0.13 J

20

1.7

1.5 I

Qualifier

Matrix: Solid

Dil Fac

20

20

20

20

20

20

20

20

1

1

Dil Fac

Dil Fac

1

1

1

1

1

1

1

1

1

1

Dil Fac

Percent Solids: 94.4

Analyzed

08/07/23 23:54

Analyzed

07/28/23 11:10

07/28/23 11:10

Analyzed

Lab Sample ID: 320-102972-1

08/03/23 21:41 08/07/23 23:54

08/03/23 21:41 08/07/23 23:54

08/03/23 21:41 08/07/23 23:54

08/03/23 21:41 08/07/23 23:54

08/03/23 21:41 08/07/23 23:54

08/03/23 21:41 08/07/23 23:54

08/03/23 21:41 08/07/23 23:54

08/03/23 21:41 08/04/23 23:14

Prepared

08/03/23 21:41

Prepared

Prepared

08/03/23 21:41 08/04/23 23:14

08/03/23 21:41 08/04/23 23:14

08/03/23 21:41 08/04/23 23:14

08/03/23 21:41 08/04/23 23:14

08/03/23 21:41 08/04/23 23:14

08/03/23 21:41 08/04/23 23:14

08/03/23 21:41 08/04/23 23:14

08/03/23 21:41 08/04/23 23:14

08/03/23 21:41 08/04/23 23:14

08/03/23 21:41 08/04/23 23:14 08/03/23 21:41 08/04/23 23:14

Prepared

Page 26 of 166

6

Lab Sample ID: 320-102972-2

D

÷

t

Φ

D

Matrix: Solid Percent Solids: 87.0

,	
-	

			-	
₽	08/03/23 21:41	08/04/23 23:14	1	
₽	08/03/23 21:41	08/04/23 23:14	1	
₽	08/03/23 21:41	08/04/23 23:14	1	
₽	08/03/23 21:41	08/04/23 23:14	1	
₽	08/03/23 21:41	08/04/23 23:14	1	
₽	08/03/23 21:41	08/04/23 23:14	1	
₽	08/03/23 21:41	08/04/23 23:14	1	
₽	08/03/23 21:41	08/04/23 23:14	1	
¢	08/03/23 21:41	08/04/23 23:14	1	
₽	08/03/23 21:41	08/04/23 23:14	1	
₽	08/03/23 21:41	08/04/23 23:14	1	
₽	08/03/23 21:41	08/04/23 23:14	1	

Perfluorononanesulfonic acid (PFNS)	ND		0.22	0.032	ug/Kg
Perfluorodecanesulfonic acid (PFDS)	ND		0.22	0.058	ug/Kg
Perfluorooctanesulfonamide (FOSA)	ND		0.22	0.037	ug/Kg
NMeFOSAA	ND		0.22	0.025	ug/Kg
NEtFOSAA	ND		0.22	0.053	ug/Kg
4:2 FTS	ND		0.22	0.056	ug/Kg
Isotope Dilution	%Recovery	Qualifier	Limits		
13C4 PFBA	76		25 - 150		

Eurofins Sacramento

Analyzed

8/14/2023

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

Client Sample ID: SS-6 Date Collected: 07/26/23 11:05 Date Received: 07/27/23 09:40

Job ID: 320-102972-1

Page 27 of 166

5

6

13

Lab Sample ID: 320-102972-2 Matrix: Solid

Percent Solids: 87.0

Isotope Dilution	%Recovery	Qualifier	Limits				Prepared	Analyzed	Dil Fa
13C2 PFHxA	73		25 - 150				08/03/23 21:41	08/04/23 23:14	1
13C4 PFHpA	86		25 - 150				08/03/23 21:41	08/04/23 23:14	1
13C4 PFOA	76		25 - 150				08/03/23 21:41	08/04/23 23:14	1
13C5 PFNA	78		25 - 150				08/03/23 21:41	08/04/23 23:14	1
13C2 PFDA	38		25 - 150				08/03/23 21:41	08/04/23 23:14	1
13C2 PFUnA	71		25 - 150				08/03/23 21:41	08/04/23 23:14	1
13C2 PFDoA	69		25 - 150				08/03/23 21:41	08/04/23 23:14	1
13C2 PFTeDA	73		25 - 150				08/03/23 21:41	08/04/23 23:14	1
13C3 PFBS	73		25 - 150				08/03/23 21:41	08/04/23 23:14	1
1802 PFHxS	80		25 - 150				08/03/23 21:41	08/04/23 23:14	1
13C4 PFOS	83		25 - 150				08/03/23 21:41	08/04/23 23:14	1
13C8 FOSA	83		25 - 150				08/03/23 21:41	08/04/23 23:14	1
d3-NMeFOSAA	42		25 - 150				08/03/23 21:41	08/04/23 23:14	1
d5-NEtFOSAA	43		25 - 150				08/03/23 21:41	08/04/23 23:14	
M2-4:2 FTS	69		25 - 150				08/03/23 21:41	08/04/23 23:14	
		Alkyl Sub Qualifier	RL		Unit	D	Prepared	Analyzed	Dil Fac
Analyte		-		MDL 0.30	ug/Kg	D	Prepared 08/03/23 21:41	Analyzed 08/07/23 23:34	
Analyte 6:2 FTS	Result	-	RL	MDL 0.30			· · · · · · · · · · · · · · · · · · ·	08/07/23 23:34	10
Analyte 6:2 FTS 8:2 FTS	Result 15	Qualifier	RL	MDL 0.30	ug/Kg	<u></u>	08/03/23 21:41	08/07/23 23:34	10 10
Analyte 6:2 FTS 8:2 FTS Isotope Dilution	Result 15 38	Qualifier	RL 2.2 2.2	MDL 0.30	ug/Kg	<u></u>	08/03/23 21:41 08/03/23 21:41	08/07/23 23:34 08/07/23 23:34	10 10 Dil Fa o
Analyte 6:2 FTS 8:2 FTS Isotope Dilution M2-6:2 FTS	Result 15 38 %Recovery	Qualifier	RL 2.2 2.2 <i>Limits</i>	MDL 0.30	ug/Kg	<u></u>	08/03/23 21:41 08/03/23 21:41 Prepared	08/07/23 23:34 08/07/23 23:34 Analyzed 08/07/23 23:34	10 10 Dil Fa 10
Analyte 6:2 FTS 8:2 FTS Isotope Dilution M2-6:2 FTS M2-8:2 FTS	Result 15 38 %Recovery 62	Qualifier	RL 2.2 2.2 Limits 25 - 150	MDL 0.30	ug/Kg	<u></u>	08/03/23 21:41 08/03/23 21:41 Prepared 08/03/23 21:41	08/07/23 23:34 08/07/23 23:34 Analyzed 08/07/23 23:34	10 10 Dil Fac 10
Analyte 6:2 FTS 8:2 FTS Isotope Dilution M2-6:2 FTS M2-8:2 FTS General Chemistry	Result 15 38 %Recovery 62 71	Qualifier	RL 2.2 2.2 Limits 25 - 150	MDL 0.30 0.39	ug/Kg	<u></u>	08/03/23 21:41 08/03/23 21:41 Prepared 08/03/23 21:41	08/07/23 23:34 08/07/23 23:34 Analyzed 08/07/23 23:34	Dil Fac 10 10 10 10 10 10 10
Analyte 6:2 FTS 8:2 FTS Isotope Dilution M2-6:2 FTS M2-8:2 FTS General Chemistry Analyte	Result 15 38 %Recovery 62 71	Qualifier Qualifier	RL 2.2 2.2 Limits 25 - 150 25 - 150	MDL 0.30 0.39	ug/Kg ug/Kg Unit	 \$\$	08/03/23 21:41 08/03/23 21:41 Prepared 08/03/23 21:41 08/03/23 21:41	08/07/23 23:34 08/07/23 23:34 Analyzed 08/07/23 23:34 08/07/23 23:34	10 10 <i>Dil Fac</i> 10 Dil Fac
Analyte 3:2 FTS 3:2	Result 15 38 %Recovery 62 71 Result	Qualifier Qualifier	RL 2.2 2.2 Limits 25 - 150 25 - 150 RL	MDL 0.30 0.39 RL	ug/Kg ug/Kg <u>Unit</u> %	 \$\$	08/03/23 21:41 08/03/23 21:41 Prepared 08/03/23 21:41 08/03/23 21:41	08/07/23 23:34 08/07/23 23:34 Analyzed 08/07/23 23:34 08/07/23 23:34 Analyzed	10 10 10 10 10 10 10
Analyte 6:2 FTS 8:2 FTS Isotope Dilution M2-6:2 FTS M2-8:2 FTS General Chemistry Analyte Percent Moisture (ASTM D 2216) Percent Solids (ASTM D 2216)	Result 15 38 %Recovery 62 71 Result 13.0	Qualifier Qualifier	RL 2.2 2.2 Limits 25 - 150 25 - 150 RL 0.1	MDL 0.30 0.39 RL 0.1	ug/Kg ug/Kg <u>Unit</u> %	☆ ☆ D	08/03/23 21:41 08/03/23 21:41 Prepared 08/03/23 21:41 08/03/23 21:41 08/03/23 21:41 Prepared	08/07/23 23:34 08/07/23 23:34 Analyzed 08/07/23 23:34 08/07/23 23:34 08/07/23 23:34	10 10 Dil Fa 10 10 Dil Fa
Method: EPA 537 (modified) - Analyte 6:2 FTS 8:2 FTS Isotope Dilution M2-6:2 FTS M2-8:2 FTS General Chemistry Analyte Percent Moisture (ASTM D 2216) Percent Solids (ASTM D 2216) Client Sample ID: SS-7 vate Collected: 07/26/23 11:45	Result 15 38 %Recovery 62 71 Result 13.0	Qualifier Qualifier	RL 2.2 2.2 Limits 25 - 150 25 - 150 RL 0.1	MDL 0.30 0.39 RL 0.1	ug/Kg ug/Kg <u>Unit</u> %	☆ ☆ D	08/03/23 21:41 08/03/23 21:41 Prepared 08/03/23 21:41 08/03/23 21:41 08/03/23 21:41 Prepared	08/07/23 23:34 08/07/23 23:34 Analyzed 08/07/23 23:34 08/07/23 23:34 08/07/23 23:34 08/07/23 11:10 07/28/23 11:10 ID: 320-102	10 10 Dil Fa a 10 10 Dil Faa

Analyte Result Qualifier RL MDL Unit Prepared D 0.22 x 08/03/23 21:41 08/04/23 23:24 Perfluorobutanoic acid (PFBA) 8.5 0.051 ug/Kg 0.22 0.042 ug/Kg ☆ 08/03/23 21:41 08/04/23 23:24 Perfluoroheptanoic acid (PFHpA) 16 Perfluorooctanoic acid (PFOA) 0.22 0.059 ug/Kg 21 08/03/23 21:41 08/04/23 23:24
 0.024 ug/Kg ☆ 08/03/23 21·41 08/04/23 23·24 Porfluorononanoio agid (PENA) 0 22

Pertiuorononanoic acid (PENA)	11	0.22	0.024 ug/Kg	Q 08/03/23 21:41 08/04/23 23:24	1
Perfluorodecanoic acid (PFDA)	1.3	0.22	0.053 ug/Kg	08/03/23 21:41 08/04/23 23:24	1
Perfluoroundecanoic acid (PFUnA)	ND	0.22	0.046 ug/Kg	08/03/23 21:41 08/04/23 23:24	1
Perfluorododecanoic acid (PFDoA)	ND	0.22	0.033 ug/Kg	08/03/23 21:41 08/04/23 23:24	1
Perfluorotridecanoic acid (PFTrDA)	ND	0.22	0.023 ug/Kg	08/03/23 21:41 08/04/23 23:24	1
Perfluorotetradecanoic acid (PFTeA)	ND	0.22	0.041 ug/Kg	08/03/23 21:41 08/04/23 23:24	1
Perfluorobutanesulfonic acid (PFBS)	0.13 J	0.22	0.042 ug/Kg		1
Perfluoropentanesulfonic acid (PFPeS)	0.15 J	0.22	0.041 ug/Kg		1
Perfluorohexanesulfonic acid (PFHxS)	1.9	0.22	0.032 ug/Kg		1

Eurofins Sacramento

Released to Imaging: 7/25/2024 3:37:45 PM

Dil Fac

1

1

1

1

Analyzed

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

Method: EPA 537 (modified) - Fluorinated Alkyl Substances (Continued)

Client Sample ID: SS-7 Date Collected: 07/26/23 11:45 Date Received: 07/27/23 09:40

13C3 PFBS

1802 PFHxS

13C4 PFOS

13C8 FOSA

M2-4:2 FTS

d3-NMeFOSAA

d5-NEtFOSAA

Analyte	Result	Qualifier	RL	MDL	Unit	D	Prepared	Analyzed	Dil Fac
Perfluoroheptanesulfonic acid	0.16	J	0.22	0.054	ug/Kg	¢	08/03/23 21:41	08/04/23 23:24	1
(PFHpS)									
Perfluorononanesulfonic acid (PFNS)	ND		0.22	0.032	ug/Kg	¢	08/03/23 21:41	08/04/23 23:24	1
Perfluorodecanesulfonic acid (PFDS)	ND		0.22	0.057	ug/Kg	¢	08/03/23 21:41	08/04/23 23:24	1
Perfluorooctanesulfonamide (FOSA)	ND		0.22	0.036	ug/Kg	¢	08/03/23 21:41	08/04/23 23:24	1
NMeFOSAA	ND		0.22	0.025	ug/Kg	¢	08/03/23 21:41	08/04/23 23:24	1
NEtFOSAA	ND		0.22	0.053	ug/Kg	¢	08/03/23 21:41	08/04/23 23:24	1
4:2 FTS	ND		0.22	0.056	ug/Kg	₽	08/03/23 21:41	08/04/23 23:24	1
Isotope Dilution	%Recovery	Qualifier	Limits				Prepared	Analyzed	Dil Fac
Isotope Dilution 13C4 PFBA	%Recovery 76	Qualifier	Limits				Prepared 08/03/23 21:41	Analyzed 08/04/23 23:24	Dil Fac
		Qualifier					·	08/04/23 23:24	Dil Fac 1 1
13C4 PFBA	76	Qualifier	25 - 150				08/03/23 21:41	08/04/23 23:24 08/04/23 23:24	Dil Fac 1 1 1
13C4 PFBA 13C4 PFHpA	76 81	Qualifier	25 - 150 25 - 150				08/03/23 21:41 08/03/23 21:41	08/04/23 23:24 08/04/23 23:24 08/04/23 23:24	Dil Fac 1 1 1 1
13C4 PFBA 13C4 PFHpA 13C4 PFOA	76 81 77	Qualifier	25 - 150 25 - 150 25 - 150				08/03/23 21:41 08/03/23 21:41 08/03/23 21:41	08/04/23 23:24 08/04/23 23:24 08/04/23 23:24 08/04/23 23:24	Dil Fac 1 1 1 1 1 1
13C4 PFBA 13C4 PFHpA 13C4 PFOA 13C5 PFNA	76 81 77 77	Qualifier	25 - 150 25 - 150 25 - 150 25 - 150				08/03/23 21:41 08/03/23 21:41 08/03/23 21:41 08/03/23 21:41	08/04/23 23:24 08/04/23 23:24 08/04/23 23:24 08/04/23 23:24 08/04/23 23:24	Dil Fac 1 1 1 1 1 1 1
13C4 PFBA 13C4 PFHpA 13C4 PFOA 13C5 PFNA 13C2 PFDA	76 81 77 77 76	Qualifier	25 - 150 25 - 150 25 - 150 25 - 150 25 - 150				08/03/23 21:41 08/03/23 21:41 08/03/23 21:41 08/03/23 21:41 08/03/23 21:41	08/04/23 23:24 08/04/23 23:24 08/04/23 23:24 08/04/23 23:24 08/04/23 23:24 08/04/23 23:24	Dil Fac 1 1 1 1 1 1 1 1 1

25 - 150

25 - 150

25 - 150

25 - 150

25 - 150

25 - 150

25 - 150

-	
Method: EPA 537 (modified) - Fluorinated Alkyl Substances -	DL

76

72

78

84

52

55

65

Analyte	Result	Qualifier	RL	MDL	Unit	D	Prepared	Analyzed	Dil Fac
Perfluoropentanoic acid (PFPeA)	51		2.2	0.45	ug/Kg	☆	08/03/23 21:41	08/07/23 23:44	10
Perfluorohexanoic acid (PFHxA)	28		2.2	0.34	ug/Kg	¢	08/03/23 21:41	08/07/23 23:44	10
Perfluorooctanesulfonic acid (PFOS)	33		2.2	0.47	ug/Kg	¢	08/03/23 21:41	08/07/23 23:44	10
6:2 FTS	78		2.2	0.30	ug/Kg	☆	08/03/23 21:41	08/07/23 23:44	10
8:2 FTS	30		2.2	0.39	ug/Kg	₽	08/03/23 21:41	08/07/23 23:44	10
Isotope Dilution	%Recovery	Qualifier	Limits				Prepared	Analyzed	Dil Fac
13C5 PFPeA	79		25 - 150				08/03/23 21:41	08/07/23 23:44	10
13C2 PFHxA	78		25 - 150				08/03/23 21:41	08/07/23 23:44	10
13C4 PFOS	82		25 - 150				08/03/23 21:41	08/07/23 23:44	10
M2-6:2 FTS	69		25 - 150				08/03/23 21:41	08/07/23 23:44	10
M2-8:2 FTS	69		25 - 150				08/03/23 21:41	08/07/23 23:44	10
General Chemistry									
Analyte	Result	Qualifier	RL	RL	Unit	D	Prepared	Analyzed	Dil Fac
Percent Moisture (ASTM D 2216)	11.2		0.1	0.1	%			07/28/23 11:10	1
Percent Solids (ASTM D 2216)	88.8		0.1	0.1	%			07/28/23 11:10	1

Eurofins Sacramento

Page 28 of 166

Job ID: 320-102972-1

Percent Solids: 88.8

Matrix: Solid

6

1

1

1

1

1

1

1

8/14/2023

Lab Sample ID: 320-102972-3

08/03/23 21:41 08/04/23 23:24

08/03/23 21:41 08/04/23 23:24

08/03/23 21:41 08/04/23 23:24

08/03/23 21:41 08/04/23 23:24

08/03/23 21:41 08/04/23 23:24

08/03/23 21:41 08/04/23 23:24

08/03/23 21:41 08/04/23 23:24

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

Client Sample ID: SS-8 Date Collected: 07/26/23 12:05 Date Received: 07/27/23 09:40

(PFDoA)

13C8 FOSA

M2-4:2 FTS

d3-NMeFOSAA

d5-NEtFOSAA

Date Collected: 07/26/23 12:05				Matrix	: Solid				
Date Received: 07/27/23 09:40					Percent Solid				
Method: EPA 537 (modified) - F									
Analyte	Result	Qualifier	RL	MDL	Unit	D	Prepared	Analyzed	Dil Fac
Perfluorodecanoic acid (PFDA)	13		0.20	0.048	ug/Kg	☆	08/03/23 21:41	08/04/23 23:34	1
Perfluorododecanoic acid (PFDoA)	11		0.20	0.030	ug/Kg	¢	08/03/23 21:41	08/04/23 23:34	1

(FFDUA)								
Perfluorotetradecanoic acid	10	1	0.20	0.037 ug/Kg	☆	08/03/23 21:41	08/04/23 23:34	1
(PFTeA)								
Perfluorobutanesulfonic acid	1.4		0.20	0.038 ug/Kg	÷.	08/03/23 21:41	08/04/23 23:34	1
(PFBS) Perfluoropentanesulfonic acid	1.7		0.20	0.037 ug/Kg	÷.	08/03/23 21.41	08/04/23 23:34	1
(PFPeS)	1.7		0.20	0.007 ug/Ng	74	00/03/23 21.41	00/04/23 23.34	I
Perfluorohexanesulfonic acid	14		0.20	0.029 ug/Kg	÷Ċ	08/03/23 21:41	08/04/23 23:34	1
(PFHxS)								
Perfluoroheptanesulfonic acid	1.2		0.20	0.049 ug/Kg	☆	08/03/23 21:41	08/04/23 23:34	1
(PFHpS)								
Perfluorononanesulfonic acid	0.22		0.20	0.029 ug/Kg	¢	08/03/23 21:41	08/04/23 23:34	1
(PFNS)			0.00	0.050 ///				
Perfluorodecanesulfonic acid	0.12	J	0.20	0.052 ug/Kg	¢	08/03/23 21:41	08/04/23 23:34	1
(PFDS) Perfluorooctanesulfonamide	0.38		0.20	0.033 ug/Kg	÷	08/03/23 21.41	08/04/23 23:34	
(FOSA)	0.50		0.20	0.000 ug/ng	*	00/00/20 21.41	00/04/20 20:04	1
NMeFOSAA	ND		0.20	0.023 ug/Kg	¢	08/03/23 21:41	08/04/23 23:34	1
NEtFOSAA	ND		0.20	0.048 ug/Kg	¢	08/03/23 21:41	08/04/23 23:34	1
4:2 FTS	0.17	J	0.20	0.051 ug/Kg	¢	08/03/23 21:41	08/04/23 23:34	1
Isotope Dilution	%Recovery	Qualifier	Limits			Prepared	Analyzed	Dil Fac
13C2 PFDA	63		25 - 150			08/03/23 21:41	08/04/23 23:34	1
13C2 PFDoA	52		25 - 150			08/03/23 21:41	08/04/23 23:34	1
13C2 PFTeDA	66		25 - 150			08/03/23 21:41	08/04/23 23:34	1
13C3 PFBS	78		25 - 150			08/03/23 21:41	08/04/23 23:34	1
18O2 PFHxS	83		25 - 150			08/03/23 21:41	08/04/23 23:34	1
13C4 PFOS	98		25 - 150			08/03/23 21.41	08/04/23 23:34	1

25 - 150

25 - 150

25 - 150	08/03/23 21:41	08/04/23 23:34
25 - 150	08/03/23 21:41	08/04/23 23:34

Method: EPA 537 (modified) - Fluorinated Alkyl Substances - DL

72

27

25

60

Analyte	Result	Qualifier	RL	MDL	Unit	D	Prepared	Analyzed	Dil Fac
Perfluorobutanoic acid (PFBA)	65		10	2.3	ug/Kg	<u></u>	08/03/23 21:41	08/08/23 00:05	50
Perfluoropentanoic acid (PFPeA)	290		10	2.0	ug/Kg	☆	08/03/23 21:41	08/08/23 00:05	50
Perfluorohexanoic acid (PFHxA)	140		10	1.5	ug/Kg	☆	08/03/23 21:41	08/08/23 00:05	50
Perfluoroheptanoic acid (PFHpA)	59		10	1.9	ug/Kg	☆	08/03/23 21:41	08/08/23 00:05	50
Perfluorooctanoic acid (PFOA)	50		10	2.6	ug/Kg	☆	08/03/23 21:41	08/08/23 00:05	50
Perfluorononanoic acid (PFNA)	26		10	1.1	ug/Kg	☆	08/03/23 21:41	08/08/23 00:05	50
Perfluoroundecanoic acid (PFUnA)	59		10	2.1	ug/Kg	¢	08/03/23 21:41	08/08/23 00:05	50
Perfluorotridecanoic acid (PFTrDA)	75		10	1.0	ug/Kg	¢	08/03/23 21:41	08/08/23 00:05	50
Perfluorooctanesulfonic acid (PFOS)	150		10	2.1	ug/Kg	¢	08/03/23 21:41	08/08/23 00:05	50
6:2 FTS	240		10	1.3	ug/Kg	¢	08/03/23 21:41	08/08/23 00:05	50
8:2 FTS	260		10	1.7	ug/Kg	¢	08/03/23 21:41	08/08/23 00:05	50
Isotope Dilution	%Recovery	Qualifier	Limits				Prepared	Analyzed	Dil Fac
13C4 PFBA	64		25 - 150				08/03/23 21:41	08/08/23 00:05	50

1

1

1

1

6

Job ID: 320-102972-1

Lab Sample ID: 320-102972-4

08/03/23 21:41 08/04/23 23:34

08/03/23 21:41 08/04/23 23:34

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

Job ID: 320-102972-1

Lab Sample ID: 320-102972-4 Matrix: Solid Percent Solids: 97.5

Client Sample ID: SS-8 Date Collected: 07/26/23 12:05 Date Received: 07/27/23 09:40

Isotope Dilution	%Recovery	Qualifier	Limits				Prepared	Analyzed	Dil Fac
13C5 PFPeA	68		25 - 150				08/03/23 21:41	08/08/23 00:05	50
13C2 PFHxA	58		25 - 150				08/03/23 21:41	08/08/23 00:05	50
13C4 PFHpA	62		25 - 150				08/03/23 21:41	08/08/23 00:05	50
13C4 PFOA	65		25 - 150				08/03/23 21:41	08/08/23 00:05	50
13C5 PFNA	73		25 - 150				08/03/23 21:41	08/08/23 00:05	50
13C2 PFUnA	85		25 - 150				08/03/23 21:41	08/08/23 00:05	50
13C2 PFDoA	64		25 - 150				08/03/23 21:41	08/08/23 00:05	50
13C4 PFOS	88		25 - 150				08/03/23 21:41	08/08/23 00:05	50
M2-6:2 FTS	128		25 - 150				08/03/23 21:41	08/08/23 00:05	50
M2-8:2 FTS	167	*5+	25 - 150				08/03/23 21:41	08/08/23 00:05	50
General Chemistry									
Analyte	Result	Qualifier	RL	RL	Unit	D	Prepared	Analyzed	Dil Fac
Percent Moisture (ASTM D 2216)	2.5		0.1	0.1	%			07/28/23 11:10	1
Percent Solids (ASTM D 2216)	97.5		0.1	0.1	%			07/28/23 11:10	1

Client Sample ID: Dup-1 Date Collected: 07/26/23 00:00 Date Received: 07/27/23 09:40

07/28/23 11:10

Lab Sample ID: 320-102972-5 Matrix: Solid

Percent Solids: 97.1

Analyte	Result	Qualifier	RL	MDL	Unit	D	Prepared	Analyzed	Dil Fac
Perfluorodecanoic acid (PFDA)	12		0.20	0.049	ug/Kg	<u></u>	08/03/23 21:41	08/04/23 23:45	1
Perfluorododecanoic acid (PFDoA)	9.3		0.20	0.030	ug/Kg	¢	08/03/23 21:41	08/04/23 23:45	1
Perfluorotetradecanoic acid (PFTeA)	8.8		0.20	0.037	ug/Kg	₽	08/03/23 21:41	08/04/23 23:45	1
Perfluorobutanesulfonic acid (PFBS)	1.3		0.20	0.038	ug/Kg	₽	08/03/23 21:41	08/04/23 23:45	1
Perfluoropentanesulfonic acid (PFPeS)	1.5		0.20	0.037	ug/Kg	₽	08/03/23 21:41	08/04/23 23:45	1
Perfluorohexanesulfonic acid (PFHxS)	12		0.20	0.029	ug/Kg	¢	08/03/23 21:41	08/04/23 23:45	1
Perfluoroheptanesulfonic acid (PFHpS)	1.0		0.20	0.050	ug/Kg	¢	08/03/23 21:41	08/04/23 23:45	1
Perfluorononanesulfonic acid (PFNS)	0.22		0.20	0.029	ug/Kg	₽	08/03/23 21:41	08/04/23 23:45	1
Perfluorodecanesulfonic acid (PFDS)	0.15	J	0.20	0.053	ug/Kg	₽	08/03/23 21:41	08/04/23 23:45	1
Perfluorooctanesulfonamide (FOSA)	0.38		0.20	0.033	ug/Kg	¢	08/03/23 21:41	08/04/23 23:45	1
NMeFOSAA	ND		0.20	0.023	ug/Kg	¢	08/03/23 21:41	08/04/23 23:45	1
NEtFOSAA	ND		0.20	0.049	ug/Kg	¢	08/03/23 21:41	08/04/23 23:45	1
4:2 FTS	0.20		0.20	0.052	ug/Kg	¢	08/03/23 21:41	08/04/23 23:45	1
Isotope Dilution	%Recovery	Qualifier	Limits				Prepared	Analyzed	Dil Fac
13C2 PFDA	64		25 - 150				08/03/23 21:41	08/04/23 23:45	1
13C2 PFUnA	70		25 - 150				08/03/23 21:41	08/04/23 23:45	1
13C2 PFDoA	55		25 - 150				08/03/23 21:41	08/04/23 23:45	1
13C2 PFTeDA	68		25 - 150				08/03/23 21:41	08/04/23 23:45	1
13C3 PFBS	79		25 - 150				08/03/23 21:41	08/04/23 23:45	1
18O2 PFHxS	81		25 - 150				08/03/23 21:41	08/04/23 23:45	1
13C4 PFOS	94		25 - 150				08/03/23 21:41	08/04/23 23:45	1

Eurofins Sacramento

5

Client Sample ID: Dup-1 Date Collected: 07/26/23 00:00 Date Received: 07/27/23 09:40

Released to Imaging: 7/25/2024 3:37:45 PM
--

Date Received: 07/27/23 09:40

Perfluorobutanoic acid (PFBA)

Perfluoropentanoic acid (PFPeA)

Perfluorohexanoic acid (PFHxA)

Perfluoroheptanoic acid (PFHpA)

Perfluorooctanoic acid (PFOA)

Perfluorononanoic acid (PFNA)

Analyte

Client: Trihydro Corporation	
Project/Site: FTA- PFAS,Marathon Gallup Refinery	,NM

Page 31 of 166

5

6

Lab Sample ID: 320-102972-5 Matrix: Solid 1

P	erc	ent	So	lids:	97.'

Isotope Dilution	%Recovery	Qualifier	Limits				Prepared	Analyzed	Dil Fa
13C8 FOSA	75		25 - 150				08/03/23 21:41	08/04/23 23:45	
d3-NMeFOSAA	31		25 - 150				08/03/23 21:41	08/04/23 23:45	
d5-NEtFOSAA	30		25 - 150				08/03/23 21:41	08/04/23 23:45	
M2-4:2 FTS	51		25 - 150				08/03/23 21:41	08/04/23 23:45	
Method: EPA 537 (modified) -	Fluorinated	Alkyl Sub	stances - DL						
Analyte	Result	Qualifier	RL	MDL	Unit	D	Prepared	Analyzed	Dil Fa
Perfluorobutanoic acid (PFBA)	63		10	2.3	ug/Kg	<u>¤</u>	08/03/23 21:41	08/08/23 00:25	5
Perfluoropentanoic acid (PFPeA)	250		10	2.1	ug/Kg	¢	08/03/23 21:41	08/08/23 00:25	5
Perfluorohexanoic acid (PFHxA)	120		10	1.6	ug/Kg	₽	08/03/23 21:41	08/08/23 00:25	5
Perfluoroheptanoic acid (PFHpA)	58		10	1.9	ug/Kg	¢	08/03/23 21:41	08/08/23 00:25	5
Perfluorooctanoic acid (PFOA)	43		10	2.7	ug/Kg	₽	08/03/23 21:41	08/08/23 00:25	5
Perfluorononanoic acid (PFNA)	24		10	1.1	ug/Kg	¢	08/03/23 21:41	08/08/23 00:25	5
Perfluoroundecanoic acid (PFUnA)	66		10	2.1	ug/Kg	¢	08/03/23 21:41	08/08/23 00:25	5
Perfluorotridecanoic acid (PFTrDA)	63		10	1.1	ug/Kg	¢	08/03/23 21:41	08/08/23 00:25	5
Perfluorooctanesulfonic acid PFOS)	160		10	2.2	ug/Kg	¢	08/03/23 21:41	08/08/23 00:25	ţ
6:2 FTS	200		10	1.4	ug/Kg	¢	08/03/23 21:41	08/08/23 00:25	Ę
B:2 FTS	280		10	1.8	ug/Kg	¢	08/03/23 21:41	08/08/23 00:25	5
sotope Dilution	%Recovery	Qualifier	Limits				Prepared	Analyzed	Dil Fa
13C4 PFBA	61		25 - 150				08/03/23 21:41	08/08/23 00:25	5
13C5 PFPeA	73		25 - 150				08/03/23 21:41	08/08/23 00:25	5
13C2 PFHxA	65		25 - 150				08/03/23 21:41	08/08/23 00:25	5
13C4 PFHpA	63		25 - 150				08/03/23 21:41	08/08/23 00:25	5
13C4 PFOA	61		25 - 150				08/03/23 21:41	08/08/23 00:25	5
13C5 PFNA	66		25 - 150				08/03/23 21:41	08/08/23 00:25	5
13C2 PFUnA	66		25 - 150				08/03/23 21:41	08/08/23 00:25	5
13C2 PFDoA	73		25 - 150				08/03/23 21:41	08/08/23 00:25	5
13C4 PFOS	72		25 - 150				08/03/23 21:41	08/08/23 00:25	5
M2-6:2 FTS	96		25 - 150				08/03/23 21:41	08/08/23 00:25	5
M2-8:2 FTS	138		25 - 150					08/08/23 00:25	5
General Chemistry									
Analyte	Result	Qualifier	RL	RL	Unit	D	Prepared	Analyzed	Dil Fa
Percent Moisture (ASTM D 2216)	2.9		0.1	0.1	%			07/28/23 11:10	
Percent Solids (ASTM D 2216)	97.1		0.1	0.1	%			07/28/23 11:10	
lient Sample ID: EB-1							h Sample	ID: 320-102	972-

Method: EPA 537 (modified) - Fluorinated Alkyl Substances Result Qualifier MDL Unit RL D Prepared Analyzed ND 4.8 2.3 ng/L 08/07/23 05:27 08/09/23 01:43 ND 1.9 0.47 ng/L 08/07/23 05:27 08/09/23 01:43 ND 1.9 0.55 ng/L 08/07/23 05:27 08/09/23 01:43 ND 08/07/23 05:27 08/09/23 01:43 1.9 0.24 ng/L

0.81 ng/L

0.26 ng/L

Eurofins Sacramento

08/07/23 05:27 08/09/23 01:43

08/07/23 05:27 08/09/23 01:43

1.9

1.9

ND

ND

Dil Fac

1

1

1

1

1

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

Client Sample ID: EB-1 Date Collected: 07/26/23 10:35 Date Received: 07/27/23 09:40

Lab Sample ID: 320-102972-6 **Matrix: Water**

Page 32 of 166

Analyte	Result	Qualifier	RL	MDL	Unit	D	Prepared	Analyzed	Dil Fac
Perfluorodecanoic acid (PFDA)	ND		1.9	0.30	ng/L		08/07/23 05:27	08/09/23 01:43	1
Perfluoroundecanoic acid (PFUnA)	ND		1.9	1.0	ng/L		08/07/23 05:27	08/09/23 01:43	1
Perfluorododecanoic acid (PFDoA)	ND		1.9	0.52	ng/L		08/07/23 05:27	08/09/23 01:43	1
Perfluorotridecanoic acid (PFTrDA)	ND		1.9	1.2	ng/L		08/07/23 05:27	08/09/23 01:43	1
Perfluorotetradecanoic acid (PFTeA)	ND		1.9	0.70	ng/L		08/07/23 05:27	08/09/23 01:43	1
Perfluorobutanesulfonic acid (PFBS)	ND		1.9	0.19	ng/L		08/07/23 05:27	08/09/23 01:43	1
Perfluoropentanesulfonic acid (PFPeS)	ND		1.9	0.29	ng/L		08/07/23 05:27	08/09/23 01:43	1
Perfluorohexanesulfonic acid (PFHxS)	ND		1.9	0.54	ng/L		08/07/23 05:27	08/09/23 01:43	1
Perfluoroheptanesulfonic acid (PFHpS)	ND		1.9	0.18	ng/L		08/07/23 05:27	08/09/23 01:43	1
Perfluorooctanesulfonic acid (PFOS)	ND		1.9	0.52	ng/L		08/07/23 05:27	08/09/23 01:43	1
Perfluorononanesulfonic acid (PFNS)	ND		1.9	0.35	ng/L		08/07/23 05:27	08/09/23 01:43	1
Perfluorodecanesulfonic acid (PFDS)	ND		1.9	0.31	ng/L		08/07/23 05:27	08/09/23 01:43	1
Perfluorooctanesulfonamide (FOSA)	ND		1.9	0.93	ng/L		08/07/23 05:27	08/09/23 01:43	1
NMeFOSAA	ND		4.8	1.1	ng/L		08/07/23 05:27	08/09/23 01:43	1
NEtFOSAA	ND		4.8	1.2	ng/L		08/07/23 05:27	08/09/23 01:43	1
1:2 FTS	ND		1.9	0.23	ng/L		08/07/23 05:27	08/09/23 01:43	
2 FTS	ND		4.8	2.4	ng/L		08/07/23 05:27	08/09/23 01:43	
3:2 FTS	ND		1.9	0.44	ng/L		08/07/23 05:27	08/09/23 01:43	
sotope Dilution	%Recovery	Qualifier	Limits				Prepared	Analyzed	Dil Fa
13C4 PFBA	95		25 - 150				08/07/23 05:27	08/09/23 01:43	
13C5 PFPeA	98		25 - 150				08/07/23 05:27	08/09/23 01:43	
13C2 PFHxA	98		25 - 150				08/07/23 05:27	08/09/23 01:43	-
13C4 PFHpA	106		25 - 150				08/07/23 05:27	08/09/23 01:43	
13C4 PFOA	102		25 - 150				08/07/23 05:27	08/09/23 01:43	-
13C5 PFNA	108		25 - 150				08/07/23 05:27	08/09/23 01:43	-
13C2 PFDA	113		25 - 150				08/07/23 05:27	08/09/23 01:43	
13C2 PFUnA	109		25 - 150				08/07/23 05:27	08/09/23 01:43	1
13C2 PFDoA	109		25 - 150				08/07/23 05:27	08/09/23 01:43	1
13C2 PFTeDA	87		25 - 150				08/07/23 05:27	08/09/23 01:43	
13C3 PFBS	95		25 - 150				08/07/23 05:27	08/09/23 01:43	1
18O2 PFHxS	108		25 - 150				08/07/23 05:27	08/09/23 01:43	÷
13C4 PFOS	103		25 - 150				08/07/23 05:27	08/09/23 01:43	1
13C8 FOSA	109		25 - 150				08/07/23 05:27	08/09/23 01:43	1
d3-NMeFOSAA	102		25 - 150				08/07/23 05:27	08/09/23 01:43	1
d5-NEtFOSAA	109		25 - 150				08/07/23 05:27	08/09/23 01:43	
M2-6:2 FTS	116		25 - 150				08/07/23 05:27	08/09/23 01:43	÷
	137		25 - 150				08/07/23 05:27	08/09/23 01:43	-
W2-8:2 FTS									

Client Sample ID: FB-1 Date Collected: 07/26/23 10:30 Date Received: 07/27/23 09:40

Lab Sample ID: 320-102972-7 **Matrix: Water**

Method: EPA 537 (modified) - Fluorinated Alkyl Substances Posult Qualifior Analyta МП ы

Analyte	Result Qualifier	RL	MDL	Unit	D	Prepared	Analyzed	Dil Fac
Perfluorobutanoic acid (PFBA)	ND	4.8	2.3	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluoropentanoic acid (PFPeA)	ND	1.9	0.47	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorohexanoic acid (PFHxA)	ND	1.9	0.56	ng/L		08/07/23 05:27	08/09/23 01:54	1

Eurofins Sacramento

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

Client Sample ID: FB-1 Date Collected: 07/26/23 10:30 Date Received: 07/27/23 09:40

Job ID: 320-102972-1

Lab Sample ID: 320-102972-7 Matrix: Water

Page 33 of 166

nalyte	Result	Qualifier	RL	MDL		D	Prepared	Analyzed	Dil Fac
Perfluoroheptanoic acid (PFHpA)	ND		1.9	0.24	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorooctanoic acid (PFOA)	ND		1.9	0.81	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorononanoic acid (PFNA)	ND		1.9	0.26	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorodecanoic acid (PFDA)	ND		1.9	0.30	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluoroundecanoic acid (PFUnA)	ND		1.9	1.1	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorododecanoic acid (PFDoA)	ND		1.9	0.53	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorotridecanoic acid (PFTrDA)	ND		1.9	1.2	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorotetradecanoic acid (PFTeA)	ND		1.9	0.70	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorobutanesulfonic acid (PFBS)	ND		1.9	0.19	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluoropentanesulfonic acid (PFPeS)	ND		1.9	0.29	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorohexanesulfonic acid (PFHxS)	ND		1.9	0.55	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluoroheptanesulfonic acid (PFHpS)	ND		1.9	0.18	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorooctanesulfonic acid (PFOS)	ND		1.9	0.52	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorononanesulfonic acid (PFNS)	ND		1.9	0.35	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorodecanesulfonic acid (PFDS)	ND		1.9	0.31	ng/L		08/07/23 05:27	08/09/23 01:54	1
Perfluorooctanesulfonamide (FOSA)	ND		1.9	0.94	ng/L		08/07/23 05:27	08/09/23 01:54	1
NMeFOSAA	ND		4.8	1.2	ng/L		08/07/23 05:27	08/09/23 01:54	1
NEtFOSAA	ND		4.8	1.2	ng/L		08/07/23 05:27	08/09/23 01:54	1
4:2 FTS	ND		1.9	0.23	ng/L		08/07/23 05:27	08/09/23 01:54	1
6:2 FTS	ND		4.8	2.4	ng/L		08/07/23 05:27	08/09/23 01:54	1
8:2 FTS	ND		1.9	0.44	ng/L		08/07/23 05:27	08/09/23 01:54	1
sotope Dilution	%Recovery	Qualifier	Limits				Prepared	Analyzed	Dil Fac
13C4 PFBA	95		25 - 150				08/07/23 05:27	08/09/23 01:54	1
13C5 PFPeA	102		25 - 150				08/07/23 05:27	08/09/23 01:54	1
13C2 PFHxA	99		25 - 150				08/07/23 05:27	08/09/23 01:54	1
13C4 PFHpA	102		25 - 150				08/07/23 05:27	08/09/23 01:54	1
13C4 PFOA	101		25 - 150				08/07/23 05:27	08/09/23 01:54	1
13C5 PFNA	107		25 - 150				08/07/23 05:27	08/09/23 01:54	1
13C2 PFDA	112		25 - 150				08/07/23 05:27	08/09/23 01:54	1
13C2 PFUnA	107		25 - 150				08/07/23 05:27	08/09/23 01:54	1
13C2 PFDoA	105		25 - 150				08/07/23 05:27	08/09/23 01:54	1
13C2 PFTeDA	87		25 - 150				08/07/23 05:27	08/09/23 01:54	1
13C3 PFBS	100		25 - 150				08/07/23 05:27	08/09/23 01:54	1
1802 PFHxS	110		25 - 150				08/07/23 05:27	08/09/23 01:54	1
13C4 PFOS	105		25 - 150				08/07/23 05:27	08/09/23 01:54	1
13C8 FOSA	109		25 - 150				08/07/23 05:27	08/09/23 01:54	1
d3-NMeFOSAA	109		25 - 150				08/07/23 05:27	08/09/23 01:54	1
d5-NEtFOSAA	119		25 - 150				08/07/23 05:27	08/09/23 01:54	1
M2-6:2 FTS	121		25 - 150				08/07/23 05:27	08/09/23 01:54	1
M2-8:2 FTS	134		25 - 150					08/09/23 01:54	1
-									

Isotope Dilution Summary

PFPeA

(25-150)

PFHxA

(25-150)

C4PFHA

(25-150)

PFOA

(25-150)

PFNA

(25-150)

PFBA

(25-150)

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

Method: 537 (modified) - Fluorinated Alkyl Substances

Client Sample ID

Matrix: Solid

Lab Sample ID

Job ID: 320-102972-1

Prep Type: Total/NA

		(20.00)	(=0.00)	(20.00)	(20.00)	(20.00)	(=0.00)	(100)	(=0.00)
320-102972-1	SS-5	71			78			68	71
320-102972-3	SS-7	76			81	77	77	76	74
320-102972-4	SS-8							63	
320-102972-5	Dup-1							64	70
			Perce	ent Isotope	Dilution Re	coverv (Ac	ceptance L	imits)	
		PFDoA	PFTDA	C3PFBS	PFHxS	PFOS	PFOSA	d3NMFOS	d5NEFOS
Lab Sample ID	Client Sample ID	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)
320-102972-1	SS-5	<u>(10 100)</u> 67	67	77	75	93	80	29	32
320-102972-3	SS-7	66	76	76	72	78	84	52	55
320-102972-4	SS-8	52	66	78	83	98	72	27	25
320-102972-5	Dup-1	55	68	79	81	94	75	31	30
020-102012-0									
		M242FTS	Perce	ent Isotope	Dilution Re	covery (Ac	ceptance L	lmits)	
Lab Sample ID	Client Sample ID	(25-150)							
320-102972-1	SS-5 SS-7	64 65							
320-102972-3 320-102972-4	SS-8	60							
320-102972-4									
320-102972-5	Dup-1	51							
Surrogate Legend									
PFBA = 13C4 PFBA									
C4PFHA = 13C4 PFHpA	١								
PFOA = 13C4 PFOA									
PFNA = 13C5 PFNA									
PFDA = 13C2 PFDA									
PFUnA = 13C2 PFUnA									
PFDoA = 13C2 PFDoA									
PFTDA = 13C2 PFTeDA									
C3PFBS = 13C3 PFBS									
PFHxS = 18O2 PFHxS									
PFOS = 13C4 PFOS									
PFOSA = 13C8 FOSA									
d3NMFOS = d3-NMeFO	SAA								
d5NEFOS = d5-NEtFOS	5AA								

Method: 537 (modified) - Fluorinated Alkyl Substances Matrix: Solid

Percent Isotope Dilution Recovery (Acceptance Limits) PFPeA **PFHxA** PFOA PFNA PFDoA PFOS M262FTS M282FTS (25-150) Lab Sample ID **Client Sample ID** (25-150) (25-150) (25-150) (25-150) (25-150) (25-150) (25-150) 320-102972-1 - DL SS-5 66 66 65 79 73 89 108 99 Surrogate Legend PFPeA = 13C5 PFPeA PFHxA = 13C2 PFHxA PFOA = 13C4 PFOA PFNA = 13C5 PFNA PFDoA = 13C2 PFDoA

Eurofins Sacramento

Prep Type: Total/NA

Released to Imaging: 7/25/2024 3:37:45 PM

Isotope Dilution Summary

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM PFOS = 13C4 PFOS M262FTS = M2-6:2 FTS M282FTS = M2-8:2 FTS

Method: 537 (modified) - Fluorinated Alkyl Substances Matrix: Solid

latrix: Solid							Pr	ep Type:	Total/NA	
-		Percent Isotope Dilution Recovery (Acceptance Limits)								
		PFBA	PFPeA	PFHxA	C4PFHA	PFOA	PFNA	PFDA	PFUnA	
Lab Sample ID	Client Sample ID	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	
320-102972-2	SS-6	76	76	73	86	76	78	38	71	
LCS 320-696123/2-A	Lab Control Sample	73	87	99	104	93	99	99	95	
MB 320-696123/1-A	Method Blank	63	88	88	88	88	93	98	94	
			Perce	ent Isotope	Dilution Re	coverv (Ac	ceptance L	imits)		
		PFDoA	PFTDA	C3PFBS	PFHxS	PFOS	PFOSA	d3NMFOS	d5NEFOS	
Lab Sample ID	Client Sample ID	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	
320-102972-2	SS-6	$\frac{(20,100)}{69}$	73	73	80	83	83	42	43	
LCS 320-696123/2-A	Lab Control Sample	101	86	89	93	98	107	107	93	
MB 320-696123/1-A	Method Blank	95	85	83	83	97	100	101	95	
					Dilution Re					
		M262FTS	Covery (AC	ceptance L	innis)					
Lab Sample ID	Client Semple ID	(25-150)	(25-150)	(25-150)						
320-102972-2	Client Sample ID SS-6	(23-130)	(23-130)	69						
LCS 320-696123/2-A	Lab Control Sample	88	87	103						
MB 320-696123/1-A	Method Blank	86	84	97						
MD 320-030123/1-A		00	04	97						
Surrogate Legend										
PFBA = 13C4 PFBA										
PFPeA = 13C5 PFPeA										
PFHxA = 13C2 PFHxA										
C4PFHA = 13C4 PFHpA										
PFOA = 13C4 PFOA										
PFNA = 13C5 PFNA										
PFDA = 13C2 PFDA										
PFUnA = 13C2 PFUnA										
PFDoA = 13C2 PFDoA										
PFTDA = 13C2 PFTeDA										
C3PFBS = 13C3 PFBS										
PFHxS = 18O2 PFHxS										
PFOS = 13C4 PFOS										
PFOSA = 13C8 FOSA										
d3NMFOS = d3-NMeFOS	SAA									
d5NEFOS = d5-NEtFOSA	A									
M262FTS = M2-6:2 FTS										
M282FTS = M2-8:2 FTS										

Method: 537 (modified) - Fluorinated Alkyl Substances Matrix: Solid

_		Percent Isotope Dilution Recovery (Acceptance Limits)							
		M262FTS	M282FTS						
Lab Sample ID	Client Sample ID	(25-150)	(25-150)						
320-102972-2 - DL	SS-6	62	71						

M262FTS = M2-6:2 FTS

2 3 4 Prep Type: Total/NA 5

7

Page 35 of 166

Eurofins Sacramento

Prep Type: Total/NA

Released to Imaging: 7/25/2024 3:37:45 PM

Isotope Dilution Summary

PFHxA

(25-150)

78

PFOS

(25-150)

82

PFPeA

(25-150)

79

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM M282FTS = M2-8:2 FTS

SS-7

Job ID: 320-102972-1

Prep Type: Total/NA

Prep Type: Total/NA

Percent Isotope Dilution Recovery (Acceptance Limits)

M262FTS M282FTS

(25-150)

69

(25-150)

69

1 2 3 4 5 6 7 8 9 10 11 12 13 14

Method: 537 (modified) - Fluorinated Alkyl Substances

Method: 537 (modified) - Fluorinated Alkyl Substances

Client Sample ID

Matrix: Solid

Matrix: Solid

Lab Sample ID

320-102972-3 - DL

Surrogate Legend

PFPeA = 13C5 PFPeA PFHxA = 13C2 PFHxA PFOS = 13C4 PFOS M262FTS = M2-6:2 FTS M282FTS = M2-8:2 FTS

		Percent Isotope Dilution Recovery (Acceptance Limits)								
		PFBA	PFPeA	PFHxA	C4PFHA	PFOA	PFNA	PFUnA	PFDoA	
Lab Sample ID	Client Sample ID	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	
320-102972-4 - DL	SS-8	64	68	58	62	65	73	85	64	
320-102972-5 - DL	Dup-1	61	73	65	63	61	66	66	73	
			Perce	ent Isotope	Dilution Re	covery (Ac	ceptance L	imits)		
		PFOS	M262FTS	M282FTS						
Lab Sample ID	Client Sample ID	(25-150)	(25-150)	(25-150)						
320-102972-4 - DL	SS-8	88	128	167 *5+						
320-102972-5 - DL	Dup-1	72	96	138						
Surrogate Legend										
PFBA = 13C4 PFBA										
PFPeA = 13C5 PFPeA										
PFHxA = 13C2 PFHxA										
C4PFHA = 13C4 PFHpA										
PFOA = 13C4 PFOA										
PFNA = 13C5 PFNA										
PFUnA = 13C2 PFUnA										
PFDoA = 13C2 PFDoA										
PFOS = 13C4 PFOS										
M262FTS = M2-6:2 FTS										
M282FTS = M2-8:2 FTS										

Method: 537 (modified) - Fluorinated Alkyl Substances Matrix: Water

Percent Isotope Dilution Recovery (Acceptance Limits) PFBA C4PFHA PFPeA PFHxA PFOA PFNA PFDA **PFUnA** (25-150) (25-150) (25-150) (25-150) (25 - 150)(25 - 150)(25-150) (25-150) Lab Sample ID **Client Sample ID** 320-102972-6 EB-1 95 98 98 106 102 108 113 109 320-102972-7 FB-1 95 102 99 102 107 101 107 112 LCS 320-696655/2-A Lab Control Sample 89 89 92 92 93 100 103 95 102 LCSD 320-696655/3-A Lab Control Sample Dup 90 91 95 96 93 101 101 MB 320-696655/1-A Method Blank 92 94 99 97 95 103 107 103

Eurofins Sacramento

Prep Type: Total/NA

-102972-1
Isotope Dilution Summary

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

Method: 537 (modified) - Fluorinated Alkyl Substances (Continued)

PFOA = 13C4 PFOA PFNA = 13C5 PFNA PFDA = 13C2 PFDA PFUnA = 13C2 PFUnA PFDoA = 13C2 PFUnA PFDoA = 13C2 PFTeDA C3PFBS = 13C2 PFTeDA C3PFBS = 13C3 PFBS PFHxS = 18O2 PFHxS PFOS = 13C4 PFOS PFOSA = 13C8 FOSA d3NMFOS = d3-NMeFOSAA d5NEFOS = d5-NEtFOSAA M262FTS = M2-6:2 FTS M282FTS = M2-8:2 FTS M242FTS = M2-4:2 FTS 5

7

13

Job ID: 320-102972-1

Prep Type: Total/NA

		Percent Isotope Dilution Recovery (Acceptance Limits)							
		PFDoA	PFTDA	C3PFBS	PFHxS	PFOS	PFOSA	d3NMFOS	d5NEFOS
Lab Sample ID	Client Sample ID	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)	(25-150)
320-102972-6	EB-1	109	87	95	108	103	109	102	109
320-102972-7	FB-1	105	87	100	110	105	109	109	119
LCS 320-696655/2-A	Lab Control Sample	103	86	92	102	98	107	103	106
LCSD 320-696655/3-A	Lab Control Sample Dup	104	97	94	106	102	112	108	114
MB 320-696655/1-A	Method Blank	107	88	90	108	104	110	107	108
			Perce	ent Isotope	Dilution Re	covery (Ac	ceptance L	imits)	
		M262FTS	M282FTS	M242FTS					
Lab Sample ID	Client Sample ID	(25-150)	(25-150)	(25-150)					
320-102972-6	EB-1	116	137	117					
320-102972-7	FB-1	121	134	120					
LCS 320-696655/2-A	Lab Control Sample	116	119	110					
LCSD 320-696655/3-A	Lab Control Sample Dup	113	126	116					
MB 320-696655/1-A	Method Blank	121	129	117					
Surrogate Legend									
PFBA = 13C4 PFBA									
PFPeA = 13C5 PFPeA									
PFHxA = 13C2 PFHxA									
C4PFHA = 13C4 PFHpA									

Eurofins Sacramento

Pag

QC Sample Results

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

Method: 537 (modified) - Fluorinated Alkyl Substances

Lab Sample ID: MB 320-696123/1-A Matrix: Solid Analysis Batch: 696509

Analysis Batch: 696509	МВ	МВ					Prep Batch: 6961		
Analyte		Qualifier	RL	MDL	Unit	D	Prepared	Analyzed	Dil Fac
Perfluorobutanoic acid (PFBA)	ND		0.20	0.046	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluoropentanoic acid (PFPeA)	ND		0.20	0.041	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorohexanoic acid (PFHxA)	ND		0.20	0.031	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluoroheptanoic acid (PFHpA)	ND		0.20	0.038	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorooctanoic acid (PFOA)	ND		0.20	0.053	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorononanoic acid (PFNA)	ND		0.20	0.022	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorodecanoic acid (PFDA)	ND		0.20	0.048	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluoroundecanoic acid (PFUnA)	ND		0.20	0.042	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorododecanoic acid (PFDoA)	ND		0.20	0.030	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorotridecanoic acid (PFTrDA)	ND		0.20	0.021	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorotetradecanoic acid (PFTeA)	ND		0.20	0.037	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorobutanesulfonic acid (PFBS)	ND		0.20	0.038	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluoropentanesulfonic acid (PFPeS)	ND		0.20		ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorohexanesulfonic acid (PFHxS)	ND		0.20	0.029	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluoroheptanesulfonic acid (PFHpS)	ND		0.20	0.049	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorooctanesulfonic acid (PFOS)	ND		0.20	0.043	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorononanesulfonic acid (PFNS)	ND		0.20	0.029	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorodecanesulfonic acid (PFDS)	ND		0.20	0.052	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
Perfluorooctanesulfonamide (FOSA)	ND		0.20		ug/Kg		08/03/23 21:41	08/04/23 22:43	
NMeFOSAA	ND		0.20	0.023			08/03/23 21:41	08/04/23 22:43	1
NEtFOSAA	ND		0.20	0.048	ug/Kg		08/03/23 21:41	08/04/23 22:43	1
4:2 FTS	ND		0.20	0.051			08/03/23 21:41	08/04/23 22:43	1
6:2 FTS	ND		0.20	0.027	0 0			08/04/23 22:43	1
8:2 FTS	ND		0.20		ug/Kg		08/03/23 21:41	08/04/23 22:43	1
	MB	МВ			0 0				
Isotope Dilution	%Recovery		Limits				Prepared	Analyzed	Dil Fac
13C4 PFBA	63		25 - 150				08/03/23 21:41	08/04/23 22:43	1
13C5 PFPeA	88		25 - 150				08/03/23 21:41	08/04/23 22:43	1
13C2 PFHxA	88		25 - 150				08/03/23 21:41	08/04/23 22:43	1
13C4 PFHpA	88		25 - 150				08/03/23 21:41	08/04/23 22:43	1
13C4 PFOA	88		25 - 150				08/03/23 21:41	08/04/23 22:43	1
13C5 PFNA	93		25 - 150				08/03/23 21:41	08/04/23 22:43	1
13C2 PFDA	98		25 - 150				08/03/23 21:41	08/04/23 22:43	1
13C2 PFUnA	94		25 - 150				08/03/23 21:41	08/04/23 22:43	1
13C2 PFDoA	95		25 - 150				08/03/23 21:41	08/04/23 22:43	1
13C2 PFTeDA	85		25 - 150				08/03/23 21:41	08/04/23 22:43	1
13C3 PFBS	83		25 - 150				08/03/23 21:41	08/04/23 22:43	1
18O2 PFHxS	83		25 - 150				08/03/23 21:41	08/04/23 22:43	1
13C4 PFOS	97		25 - 150				08/03/23 21:41	08/04/23 22:43	1
13C8 FOSA	100		25 - 150				08/03/23 21:41	08/04/23 22:43	1
d3-NMeFOSAA	101		25 - 150				08/03/23 21:41	08/04/23 22:43	1
d5-NEtFOSAA	95		25 - 150				08/03/23 21:41	08/04/23 22:43	1
M2-6:2 FTS	86		25 - 150				08/03/23 21:41	08/04/23 22:43	1
M2-8:2 FTS	84		25 - 150					08/04/23 22:43	1
M2-4:2 FTS	97		25 - 150					08/04/23 22:43	1
									-

Page 38 of 166

5 6

8 9

Job ID: 320-102972-1

Prep Type: Total/NA

Prep Batch: 696123

Client Sample ID: Method Blank

QC Sample Results

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

Method: 537 (modified) - Fluorinated Alkyl Substances (Continued)

Lab Sample ID: LCS 320-6 Matrix: Solid	3012JIZ-A					Cile	ni odi		: Lab Control Sampl Prep Type: Total/N
Analysis Batch: 696509			0						Prep Batch: 69612
Analyta			Spike Added		LCS	Unit	п	% Boo	%Rec Limits
Analyte					Qualifier	Unit	D	%Rec	
Perfluorobutanoic acid (PFBA)			2.00	1.85		ug/Kg		92	76 - 136
Perfluoropentanoic acid (PFPeA)			2.00	1.96		ug/Kg		98 05	69 - 129
Perfluorohexanoic acid (PFHxA)			2.00	1.89		ug/Kg		95	71 - 131
Perfluoroheptanoic acid (PFHpA)			2.00	1.80		ug/Kg		90	71 - 131
Perfluorooctanoic acid (PFOA)			2.00	2.02		ug/Kg		101	72 - 132
Perfluorononanoic acid (PFNA)			2.00	1.97		ug/Kg		99	73 - 133
Perfluorodecanoic acid (PFDA)			2.00	2.03		ug/Kg		101	72 - 132
Perfluoroundecanoic acid			2.00	2.10		ug/Kg		105	66 - 126
(PFUnA)			0.00	0.04				101	74 404
Perfluorododecanoic acid			2.00	2.01		ug/Kg		101	71 - 131
(PFDoA) Perfluorotridecanoic acid			2.00	1.72		ug/Kg		86	71 - 131
(PFTrDA)			2.00	1.72		ug/itg		00	71-101
Perfluorotetradecanoic acid			2.00	1.76		ug/Kg		88	67 - 127
(PFTeA)									
Perfluorobutanesulfonic acid			1.78	1.84		ug/Kg		103	69 - 129
(PFBS)									
Perfluoropentanesulfonic acid			1.88	2.00		ug/Kg		106	66 - 126
(PFPeS)									
Perfluorohexanesulfonic acid			1.82	1.77		ug/Kg		97	62 - 122
(PFHxS)									70 (00
Perfluoroheptanesulfonic acid			1.91	1.77		ug/Kg		93	76 - 136
(PFHpS) Perfluorooctanesulfonic acid			1.86	1.93		ua/Ka		104	68 - 141
(PFOS)			1.00	1.93		ug/Kg		104	00 - 141
Perfluorononanesulfonic acid			1.92	1.95		ug/Kg		101	72 - 132
(PFNS)			1.02	1.00		uging		101	12-102
Perfluorodecanesulfonic acid			1.93	1.73		ug/Kg		90	71 - 131
(PFDS)						0 0			
Perfluorooctanesulfonamide			2.00	1.89		ug/Kg		94	77 - 137
(FOSA)									
NMeFOSAA			2.00	1.96		ug/Kg		98	72 - 132
NEtFOSAA			2.00	2.00		ug/Kg		100	72 - 132
4:2 FTS			1.88	1.82		ug/Kg		97	68 - 143
6:2 FTS			1.90	1.90		ug/Kg		100	73 - 139
8:2 FTS			1.92	2.13		ug/Kg		111	75 - 135
	LCS	LCS							
Isotope Dilution	%Recovery		Limits						
13C4 PFBA	73		25 - 150						
13C5 PFPeA	87		25 - 150						
13C2 PFHxA	99		25 - 150 25 - 150						
13C4 PFHpA	104		25 - 150 25 - 150						
13C4 PFOA	93		25 - 150 25 - 150						
13C5 PFNA	99 99		25 - 150 25 - 150						
13C2 PFDA									
	99 05		25 - 150 25 - 150						
13C2 PFUnA	95		25 - 150						
13C2 PFDoA	101		25 - 150						
13C2 PFTeDA	86		25 - 150						

Eurofins Sacramento

5

8

Job ID: 320-102972-1

89

93

98

13C3 PFBS

1802 PFHxS

13C4 PFOS

25 - 150 25 - 150

25 - 150

QC Sample R

24 4:15:20 PM			Page 40 of 1	<u>66</u>
	Q	C Sample Res	ults	1
	Refinery,N	IM	Job ID: 320-102972-1	2
ified) - Fluorin	ated Alky	yl Substances (C	continued)	
			Client Sample ID: Lab Control Sample Prep Type: Total/NA Prep Batch: 696123	
LCS		l imits		5
<u></u>		25 - 150		
107		25 - 150		
93		25 - 150		
88		25 - 150		
87		25 - 150		8
	ified) - Fluorin 320-696123/2-A 509 LCS %Recovery 107 107 93 88	Quation S,Marathon Gallup Refinery,N ified) - Fluorinated Alky 320-696123/2-A 509 LCS LCS %Recovery Qualifier 107 107 93 88	C Sample Residuation S,Marathon Gallup Refinery,NM ified) - Fluorinated Alkyl Substances (C 320-696123/2-A 509 LCS LCS %Recovery Qualifier 107 25 - 150 93 25 - 150 88 25 - 150	QC Sample Results Job ID: 320-102972-1 S,Marathon Gallup Refinery,NM ified) - Fluorinated Alkyl Substances (Continued) 320-696123/2-A Client Sample ID: Lab Control Sample Prep Type: Total/NA 509 LCS LCS ^V /Recovery Qualifier 107 <u>25-150</u> 93 <u>25-150</u> 93 <u>25-150</u> 93 <u>25-150</u> 88 <u>25-150</u>

Client Sample ID: Method Blank

Prep Type: Total/NA Prep Batch: 696655

Lab Sample ID: MB 320-696655/1-A **Matrix: Water** Analysis Batch: 697038

	МВ	MB							
Analyte	Result	Qualifier	RL	MDL	Unit	D	Prepared	Analyzed	Dil Fac
Perfluorobutanoic acid (PFBA)	ND		5.0	2.4	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluoropentanoic acid (PFPeA)	ND		2.0	0.49	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorohexanoic acid (PFHxA)	ND		2.0	0.58	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluoroheptanoic acid (PFHpA)	ND		2.0	0.25	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorooctanoic acid (PFOA)	ND		2.0	0.85	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorononanoic acid (PFNA)	ND		2.0	0.27	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorodecanoic acid (PFDA)	ND		2.0	0.31	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluoroundecanoic acid (PFUnA)	ND		2.0	1.1	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorododecanoic acid (PFDoA)	ND		2.0	0.55	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorotridecanoic acid (PFTrDA)	ND		2.0	1.3	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorotetradecanoic acid (PFTeA)	ND		2.0	0.73	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorobutanesulfonic acid (PFBS)	ND		2.0	0.20	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluoropentanesulfonic acid (PFPeS)	ND		2.0	0.30	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorohexanesulfonic acid (PFHxS)	ND		2.0	0.57	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluoroheptanesulfonic acid (PFHpS)	ND		2.0	0.19	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorooctanesulfonic acid (PFOS)	ND		2.0		ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorononanesulfonic acid (PFNS)	ND		2.0	0.37	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorodecanesulfonic acid (PFDS)	ND		2.0	0.32	ng/L		08/07/23 05:27	08/09/23 00:25	1
Perfluorooctanesulfonamide (FOSA)	ND		2.0	0.98	ng/L		08/07/23 05:27	08/09/23 00:25	1
NMeFOSAA	ND		5.0	1.2	ng/L		08/07/23 05:27	08/09/23 00:25	1
NEtFOSAA	ND		5.0	1.3	ng/L		08/07/23 05:27	08/09/23 00:25	1
4:2 FTS	ND		2.0	0.24	ng/L		08/07/23 05:27	08/09/23 00:25	1
6:2 FTS	ND		5.0	2.5	ng/L		08/07/23 05:27	08/09/23 00:25	1
8:2 FTS	ND		2.0	0.46	ng/L		08/07/23 05:27	08/09/23 00:25	1
	MB	MB							
Isotope Dilution	%Recovery	Qualifier	Limits				Prepared	Analyzed	Dil Fac
13C4 PFBA	92		25 - 150				08/07/23 05:27	08/09/23 00:25	1
13C5 PFPeA	94		25 - 150				08/07/23 05:27	08/09/23 00:25	1
13C2 PFHxA	99		25 - 150				08/07/23 05:27	08/09/23 00:25	1
13C4 PFHpA	97		25 - 150				08/07/23 05:27	08/09/23 00:25	1
13C4 PFOA	95		25 - 150				08/07/23 05:27	08/09/23 00:25	1
13C5 PFNA	103		25 - 150				08/07/23 05:27	08/09/23 00:25	1
13C2 PFDA	107		25 - 150				08/07/23 05:27	08/09/23 00:25	1
13C2 PFUnA	103		25 - 150				08/07/23 05:27	08/09/23 00:25	1
13C2 PFDoA	107		25 - 150				08/07/23 05:27	08/09/23 00:25	1

QC Sample Results

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

Method: 537 (modified) - Fluorinated Alkyl Substances (Continued)

Lab Sample ID: MB 320-696655/1-A Matrix: Water Analysis Batch: 697038

	MB	MB				
Isotope Dilution	%Recovery	Qualifier	Limits	Prepared	Analyzed	Dil Fac
13C2 PFTeDA	88		25 - 150	08/07/23 05:27	08/09/23 00:25	1
13C3 PFBS	90		25 - 150	08/07/23 05:27	08/09/23 00:25	1
18O2 PFHxS	108		25 - 150	08/07/23 05:27	08/09/23 00:25	1
13C4 PFOS	104		25 - 150	08/07/23 05:27	08/09/23 00:25	1
13C8 FOSA	110		25 - 150	08/07/23 05:27	08/09/23 00:25	1
d3-NMeFOSAA	107		25 - 150	08/07/23 05:27	08/09/23 00:25	1
d5-NEtFOSAA	108		25 - 150	08/07/23 05:27	08/09/23 00:25	1
M2-6:2 FTS	121		25 - 150	08/07/23 05:27	08/09/23 00:25	1
M2-8:2 FTS	129		25 - 150	08/07/23 05:27	08/09/23 00:25	1
M2-4:2 FTS	117		25 - 150	08/07/23 05:27	08/09/23 00:25	1

Lab Sample ID: LCS 320-696655/2-A Matrix: Water Analysis Batch: 697038

Client Sample ID: Lab Control Sample Prep Type: Total/NA Prep Batch: 696655

Analysis Batch: 697038	Spike	LCS	LCS				%Rec
Analyte	Added		Qualifier	Unit	D	%Rec	Limits
Perfluorobutanoic acid (PFBA)	40.0	42.1		ng/L		105	76 - 136
Perfluoropentanoic acid (PFPeA)	40.0	39.2		ng/L		98	71 - 131
Perfluorohexanoic acid (PFHxA)	40.0	41.1		ng/L		103	73 - 133
Perfluoroheptanoic acid (PFHpA)	40.0	42.1		ng/L		105	72 - 132
Perfluorooctanoic acid (PFOA)	40.0	39.2		ng/L		98	70 - 130
Perfluorononanoic acid (PFNA)	40.0	43.6		ng/L		109	75 - 135
Perfluorodecanoic acid (PFDA)	40.0	40.8		ng/L		102	76 - 136
Perfluoroundecanoic acid (PFUnA)	40.0	45.4		ng/L		114	68 - 128
Perfluorododecanoic acid (PFDoA)	40.0	43.7		ng/L		109	71 - 131
Perfluorotridecanoic acid (PFTrDA)	40.0	39.5		ng/L		99	71 - 131
Perfluorotetradecanoic acid (PFTeA)	40.0	41.2		ng/L		103	70 - 130
Perfluorobutanesulfonic acid (PFBS)	35.5	36.1		ng/L		102	67 - 127
Perfluoropentanesulfonic acid (PFPeS)	37.6	40.3		ng/L		107	66 - 126
Perfluorohexanesulfonic acid (PFHxS)	36.5	34.2		ng/L		94	59 - 119
Perfluoroheptanesulfonic acid (PFHpS)	38.2	37.7		ng/L		99	76 - 136
Perfluorooctanesulfonic acid (PFOS)	37.2	39.0		ng/L		105	70 - 130
Perfluorononanesulfonic acid (PFNS)	38.5	40.2		ng/L		104	75 - 135
Perfluorodecanesulfonic acid (PFDS)	38.6	39.6		ng/L		103	71 - 131
Perfluorooctanesulfonamide (FOSA)	40.0	36.7		ng/L		92	73 - 133
NMeFOSAA	40.0	41.1		ng/L		103	76 - 136
NEtFOSAA	40.0	43.1		ng/L		108	76 - 136
4:2 FTS	37.5	37.5		ng/L		100	79 - 139
6:2 FTS	38.1	37.6		ng/L		99	59 - 175
8:2 FTS	38.4	42.9		ng/L		112	75 - 135

Eurofins Sacramento

Job ID: 320-102972-1

Prep Type: Total/NA

Prep Batch: 696655

Client Sample ID: Method Blank

Isotope Dilution

13C4 PFBA

13C5 PFPeA

13C2 PFHxA

13C4 PFHpA

13C4 PFOA

M2-4:2 FTS

QC Sample Results

Limits

25 - 150

25 - 150

25 - 150

25 - 150

25 - 150

25 - 150

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

110

Method: 537 (modified) - Fluorinated Alkyl Substances (Continued) LCS LCS %Recovery Qualifier

89

89

92

92

93

100

13C5 PFNA 25 - 150 13C2 PFDA 103 25 - 150 13C2 PFUnA 25 - 150 95 13C2 PFDoA 103 25 - 150 13C2 PFTeDA 86 25 - 150 13C3 PFBS 92 25 - 150 18O2 PFHxS 102 25 - 150 13C4 PFOS 25 - 150 98 13C8 FOSA 107 25 - 150 d3-NMeFOSAA 103 25 - 150 d5-NEtFOSAA 106 25 - 150 25 - 150 M2-6:2 FTS 116 M2-8:2 FTS 119 25 - 150

Lab Sample ID: LCSD 320-696655/3-A Matrix: Water Analysis Batch: 697038

·	Spike	LCSD	LCSD		%Rec		RPD
Analyte	Added	Result	Qualifier Unit	D %Rec	Limits	RPD	Limit
Perfluorobutanoic acid (PFBA)	40.0	46.6	ng/L		76 - 136	10	30
Perfluoropentanoic acid (PFPeA)	40.0	40.9	ng/L	102	71_131	4	30
Perfluorohexanoic acid (PFHxA)	40.0	42.6	ng/L	106	73 - 133	4	30
Perfluoroheptanoic acid (PFHpA)	40.0	39.9	ng/L	100	72 - 132	5	30
Perfluorooctanoic acid (PFOA)	40.0	41.9	ng/L	105	70 - 130	7	30
Perfluorononanoic acid (PFNA)	40.0	45.1	ng/L	113	75 - 135	3	30
Perfluorodecanoic acid (PFDA)	40.0	42.3	ng/L	106	76 - 136	4	30
Perfluoroundecanoic acid (PFUnA)	40.0	44.3	ng/L	111	68 - 128	3	30
Perfluorododecanoic acid (PFDoA)	40.0	43.8	ng/L	110	71 - 131	0	30
Perfluorotridecanoic acid (PFTrDA)	40.0	42.1	ng/L	105	71 - 131	6	30
Perfluorotetradecanoic acid (PFTeA)	40.0	38.7	ng/L	97	70 - 130	6	30
Perfluorobutanesulfonic acid (PFBS)	35.5	37.3	ng/L	105	67 - 127	3	30
Perfluoropentanesulfonic acid (PFPeS)	37.6	42.8	ng/L	114	66 - 126	6	30
Perfluorohexanesulfonic acid (PFHxS)	36.5	36.1	ng/L	99	59 - 119	6	30
Perfluoroheptanesulfonic acid (PFHpS)	38.2	37.6	ng/L	98	76 - 136	0	30
Perfluorooctanesulfonic acid (PFOS)	37.2	37.7	ng/L	101	70 - 130	4	30
Perfluorononanesulfonic acid (PFNS)	38.5	39.2	ng/L	102	75 - 135	2	30
Perfluorodecanesulfonic acid (PFDS)	38.6	41.2	ng/L	107	71 - 131	4	30

Eurofins Sacramento

8/14/2023

Page 42 of 166

	1
Job ID: 320-102972-1	2
	3
	4
	5
	6
	7
	8
	9
	10
	11
	12
	13

Prep Type: Total/NA

Prep Batch: 696655

Client Sample ID: Lab Control Sample Dup

Released to Imaging: 7/25/2024 3:37:45 PM

QC Sample Results

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

126

116

Job ID: 320-102972-1

Method: 537 (modified) - Fluorinated Alkyl Substances (Continued) Lab Sample ID: LCSD 320-696655/3-A Client Sample ID: Lab Control Sample Dup **Matrix: Water** Prep Type: Total/NA Analysis Batch: 697038 Prep Batch: 696655 Spike LCSD LCSD %Rec Analyte Added **Result Qualifier** Unit D %Rec Limits RPD 40.0 37.7 94 73 - 133 3 Perfluorooctanesulfonamide ng/L (FOSA) **NMeFOSAA** 40.0 42.6 ng/L 107 76 - 136 4 **NEtFOSAA** 40.0 103 76 - 136 41.4 ng/L 4 4:2 FTS 40.6 37.5 ng/L 108 79 - 139 8 6:2 FTS 38.1 39.5 ng/L 104 59 - 175 5 8:2 FTS 38.4 40.9 ng/L 107 75 - 135 5 LCSD LCSD %Recovery Isotope Dilution Qualifier Limits 25 - 150 13C4 PFBA 90 13C5 PFPeA 91 25 - 150 13C2 PFHxA 95 25 - 150 13C4 PFHpA 96 25 - 150 13C4 PFOA 93 25 - 150 13C5 PFNA 101 25 - 150 13C2 PFDA 102 25 - 150 13C2 PFUnA 101 25 - 150 13C2 PFDoA 104 25 - 150 13C2 PFTeDA 97 25 - 150 13C3 PFBS 94 25 - 150 1802 PFHxS 106 25 - 150 13C4 PFOS 102 25 - 150 13C8 FOSA 25 - 150 112 d3-NMeFOSAA 108 25 - 150 d5-NEtFOSAA 25 - 150 114 M2-6:2 FTS 113 25 - 150

25 - 150

25 - 150

Eurofins Sacramento

RPD

Limit

30

30

30

30

30

30

8

M2-8:2 FTS

M2-4:2 FTS

QC Association Summary

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

LCMS

Prep Batch: 696123

Lab Sample ID	Client Sample ID	Ргер Туре	Matrix	Method	Prep Batch
320-102972-1 - DL	SS-5	Total/NA	Solid	SHAKE	
320-102972-1	SS-5	Total/NA	Solid	SHAKE	
320-102972-2 - DL	SS-6	Total/NA	Solid	SHAKE	
320-102972-2	SS-6	Total/NA	Solid	SHAKE	
320-102972-3 - DL	SS-7	Total/NA	Solid	SHAKE	
320-102972-3	SS-7	Total/NA	Solid	SHAKE	
320-102972-4 - DL	SS-8	Total/NA	Solid	SHAKE	
320-102972-4	SS-8	Total/NA	Solid	SHAKE	
320-102972-5 - DL	Dup-1	Total/NA	Solid	SHAKE	
320-102972-5	Dup-1	Total/NA	Solid	SHAKE	
MB 320-696123/1-A	Method Blank	Total/NA	Solid	SHAKE	
LCS 320-696123/2-A	Lab Control Sample	Total/NA	Solid	SHAKE	

Analysis Batch: 696509

Lab Sample ID	Client Sample ID	Prep Type	Matrix	Method	Prep Batch	
320-102972-1	SS-5	Total/NA	Solid	537 (modified)	696123	
320-102972-2	SS-6	Total/NA	Solid	537 (modified)	696123	
320-102972-3	SS-7	Total/NA	Solid	537 (modified)	696123	
320-102972-4	SS-8	Total/NA	Solid	537 (modified)	696123	
320-102972-5	Dup-1	Total/NA	Solid	537 (modified)	696123	
MB 320-696123/1-A	Method Blank	Total/NA	Solid	537 (modified)	696123	
LCS 320-696123/2-A	Lab Control Sample	Total/NA	Solid	537 (modified)	696123	

Prep Batch: 696655

Lab Sample ID 320-102972-6	Client Sample ID EB-1	Prep Type Total/NA	Matrix Water	Method 3535	Prep Batch
320-102972-7	FB-1	Total/NA	Water	3535	
MB 320-696655/1-A	Method Blank	Total/NA	Water	3535	
LCS 320-696655/2-A	Lab Control Sample	Total/NA	Water	3535	
LCSD 320-696655/3-A	Lab Control Sample Dup	Total/NA	Water	3535	

Analysis Batch: 696800

Lab Sample ID 320-102972-1 - DL	Client Sample ID SS-5	Prep Type Total/NA	Matrix Solid	Method 537 (modified)	Prep Batch 696123
320-102972-2 - DL	SS-6	Total/NA	Solid	537 (modified)	696123
320-102972-3 - DL	SS-7	Total/NA	Solid	537 (modified)	696123
320-102972-4 - DL	SS-8	Total/NA	Solid	537 (modified)	696123
320-102972-5 - DL	Dup-1	Total/NA	Solid	537 (modified)	696123

Analysis Batch: 697038

Lab Sample ID 320-102972-6	Client Sample ID EB-1	Prep Type Total/NA	Matrix Water	Method 537 (modified)	Prep Batch 696655
320-102972-7	FB-1	Total/NA	Water	537 (modified)	696655
MB 320-696655/1-A	Method Blank	Total/NA	Water	537 (modified)	696655
LCS 320-696655/2-A	Lab Control Sample	Total/NA	Water	537 (modified)	696655
LCSD 320-696655/3-A	Lab Control Sample Dup	Total/NA	Water	537 (modified)	696655

9

Job ID: 320-102972-1

QC Association Summary

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

General Chemistry

Analysis Batch: 694536

Lab Sample ID 320-102972-1	Client Sample ID	Prep Type Total/NA	Matrix Solid	Method D 2216	Prep Batch
320-102972-2	SS-6	Total/NA	Solid	D 2216	
320-102972-3	SS-7	Total/NA	Solid	D 2216	
320-102972-4	SS-8	Total/NA	Solid	D 2216	
320-102972-5	Dup-1	Total/NA	Solid	D 2216	

Page 45 of 166

Job ID: 320-102972-1

Client Sample ID: SS-5 Date Collected: 07/26/23 10:50

Client Sample ID: SS-5

Date Collected: 07/26/23 10:50

Date Received: 07/27/23 09:40

Prep Type

Prep Type

Total/NA

Total/NA

Total/NA

Total/NA

Total/NA

Date Received: 07/27/23 09:40

Batch

Type

Analysis

Batch

Type

Prep

Prep

Analysis

Analysis

Lab Chronicle

Initial

Amount

Initial

Amount

5.09 g

1 mL

5.09 g

1 mL

Dil

1

Dil

20

1

Factor

Factor

Run

Run

DL

DL

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

Batch

Method

D 2216

Batch

Method

SHAKE

SHAKE

537 (modified)

537 (modified)

Job ID: 320-102972-1

Matrix: Solid

Lab

EET SAC

Matrix: Solid

Lab

EET SAC

EET SAC

EET SAC

Percent Solids: 94.4

Lab Sample ID: 320-102972-1

Analyst

Analyst

ΡV

Lab Sample ID: 320-102972-2

JCB

Lab Sample ID: 320-102972-1

Prepared

or Analyzed

07/28/23 11:10

Prepared

or Analyzed

08/03/23 21:41

08/07/23 23:54 K1S

08/03/23 21:41 PV

08/04/23 23:04 K1S

10

EET SAC Lab Sample ID: 320-102972-2

Matrix: Solid

Matrix: Solid

Percent Solids: 87.0

	Batch	Batch		Dil	Initial	Final	Batch	Prepared			
Prep Type	Туре	Method	Run	Factor	Amount	Amount	Number	or Analyzed	Analyst	Lab	
Total/NA	Analysis	D 2216		1			694536	07/28/23 11:10	JCB	EET SAC	

Client Sample ID: SS-6 Date Collected: 07/26/23 11:05 Date Received: 07/27/23 09:40

Client Sample ID: SS-6

Date Collected: 07/26/23 11:05

Date Received: 07/27/23 09:40

Batch Batch Dil Initial Batch Prepared Final Method Run Prep Type Туре Factor Amount Number or Analyzed Amount Analyst Lab EET SAC Total/NA Prep SHAKE DL 5.19 g 10.0 mL 696123 08/03/23 21:41 PV Total/NA Analysis 537 (modified) DL 10 1 mL 696800 08/07/23 23:34 K1S EET SAC 1 ml Total/NA Prep SHAKE 5.19 g 10.0 mL 696123 08/03/23 21:41 PV EET SAC EET SAC Total/NA 537 (modified) 696509 08/04/23 23:14 K1S Analysis 1 mL 1 mL 1

Client Sample ID: SS-7

Date Collected: 07/26/23 11:45

Date Received: 07/27/23 09:40

	Batch	Batch		Dil	Initial	Final	Batch	Prepared		
Prep Type	Туре	Method	Run	Factor	Amount	Amount	Number	or Analyzed	Analyst	Lab
Total/NA	Analysis	D 2216		1			694536	07/28/23 11:10	JCB	EET SAC
Client Som		7						h Somolo II	220	402072.2

Client Sample ID: SS-7 Date Collected: 07/26/23 11:45 Date Received: 07/27/23 09:40

_	Batch	Batch		Dil	Initial	Final	Batch	Prepared		
Prep Туре	Туре	Method	Run	Factor	Amount	Amount	Number	or Analyzed	Analyst	Lab
Total/NA	Prep	SHAKE	DL		5.10 g	10.0 mL	696123	08/03/23 21:41	PV	EET SAC
Total/NA	Analysis	537 (modified)	DL	10	1 mL	1 mL	696800	08/07/23 23:44	K1S	EET SAC
Total/NA	Prep	SHAKE			5.10 g	10.0 mL	696123	08/03/23 21:41	PV	EET SAC
Total/NA	Analysis	537 (modified)		1	1 mL	1 mL	696509	08/04/23 23:24	K1S	EET SAC

Eurofins Sacramento

Batch

Number

694536

Batch

Number

696123

696800

696123

696509

Final

Amount

Final

Amount

10.0 mL

1 mL

10.0 mL

1 mL

Lab Sample ID: 320-102972-3 Matrix: Solid



Client Sample ID: SS-8 Date Collected: 07/26/23 12:05

Client Sample ID: SS-8

Date Collected: 07/26/23 12:05

Date Received: 07/27/23 09:40

Client Sample ID: Dup-1

Date Collected: 07/26/23 00:00

Date Received: 07/27/23 09:40

Client Sample ID: Dup-1

Date Collected: 07/26/23 00:00

Date Received: 07/27/23 09:40

Prep Type

Prep Type

Total/NA

Total/NA

Total/NA

Total/NA

Prep Type

Total/NA

Total/NA

Date Received: 07/27/23 09:40

Batch

Type

Batch

Type

Prep

Prep

Analysis

Analysis

Batch

Туре

Analysis

Analysis

Initial

Amount

Initial

Amount

5.14 g

1 mL

5.14 g

1 mL

Initial

Amount

Dil

1

Dil

50

1

Dil

1

Factor

Factor

Factor

Run

Run

DL

DL

Run

Client: Trihydro Corporation Project/Site: FTA- PFAS, Marathon Gallup Refinery, NM

Batch

Method

D 2216

Batch

Method

SHAKE

SHAKE

Batch

Method

D 2216

537 (modified)

537 (modified)

Job ID: 320-102972-1

Matrix: Solid

Lab

EET SAC

Matrix: Solid

Lab

Lab

Matrix: Water

Matrix: Water

EET SAC

EET SAC

EET SAC

EET SAC

Percent Solids: 97.5

Lab Sample ID: 320-102972-4

Analyst

Analyst

ΡV

K1S

JCB

Lab Sample ID: 320-102972-4

Prepared

or Analyzed

07/28/23 11:10

Prepared

or Analyzed

08/03/23 21:41

08/08/23 00:05

Prepared

or Analyzed

07/28/23 11:10

08/03/23 21:41 PV

08/04/23 23:34 K1S

Batch

Number

694536

Batch

Number

696123

696800

696123

696509

Batch

Number

694536

Final

Amount

Final

Amount

10.0 mL

1 mL

10.0 mL

1 ml

Final

Amount

10

EET SAC Lab Sample ID: 320-102972-5

Matrix: Solid

	3

Lab Sample ID: 320-102972-5 Matrix: Solid Percent Solids: 97.1

Lab Sample ID: 320-102972-6

Lab Sample ID: 320-102972-7

JCB

Analyst

Batch Batch Dil Initial Batch Prepared Final Method Prep Type Run Factor Amount Number or Analyzed Lab Туре Amount Analyst EET SAC Total/NA Prep SHAKE DL 5.09 g 10.0 mL 696123 08/03/23 21:41 PV Total/NA Analysis 537 (modified) DL 50 1 mL 696800 08/08/23 00:25 K1S EET SAC 1 mL Total/NA Prep SHAKE 5.09 g 10.0 mL 696123 08/03/23 21:41 PV EET SAC Total/NA 537 (modified) 696509 08/04/23 23:45 K1S Analysis 1 mL 1 mL EET SAC 1

Client Sample ID: EB-1

Date Collected: 07/26/23 10:35

Date Received: 07/27/23 09:40

	Batch	Batch		Dil	Initial	Final	Batch	Prepared		
Prep Type	Туре	Method	Run	Factor	Amount	Amount	Number	or Analyzed	Analyst	Lab
Total/NA	Prep	3535			262.1 mL	10.0 mL	696655	08/07/23 05:27	RLT	EET SAC
Total/NA	Analysis	537 (modified)		1	1 mL	1 mL	697038	08/09/23 01:43	RS1	EET SAC

Client Sample ID: FB-1 Date Collected: 07/26/23 10:30 Date Received: 07/27/23 09:40

		Batch	Batch		Dil	Initial	Final	Batch	Prepared		
Pi	rep Туре	Туре	Method	Run	Factor	Amount	Amount	Number	or Analyzed	Analyst	Lab
To	otal/NA	Prep	3535			260.8 mL	10.0 mL	696655	08/07/23 05:27	RLT	EET SAC
To	otal/NA	Analysis	537 (modified)		1	1 mL	1 mL	697038	08/09/23 01:54	RS1	EET SAC

Lab Chronicle

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

Laboratory References:

EET SAC = Eurofins Sacramento, 880 Riverside Parkway, West Sacramento, CA 95605, TEL (916)373-5600

Job ID: 320-102972-1

Accreditation/Certification Summary

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

non Galiup Reinery, Nim

Laboratory: Eurofins Sacramento

Unless otherwise noted, all analytes for this laboratory were covered under each accreditation/certification below.

Authority	Pre	ogram	Identification Number	Expiration Date
Oregon	NE	ELAP	4040	01-29-24
the agency does not o		rt, but the laboratory is r	not certified by the governing authority.	I his list may include analytes for whic
0,		rt, but the laboratory is r Matrix	ot certified by the governing authority. Analyte	This list may include analytes for whic
the agency does not o	offer certification.		, , , , , ,	I his list may include analytes for whic

Job ID: 320-102972-1

Method Summary

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

lethod	Method Description	Protocol	Laboratory
537 (modified)	Fluorinated Alkyl Substances	EPA	EET SAC
2216	Percent Moisture	ASTM	EET SAC
535	Solid-Phase Extraction (SPE)	SW846	EET SAC
SHAKE	Shake Extraction with Ultrasonic Bath Extraction	SW846	EET SAC

Protocol References:

ASTM = ASTM International

EPA = US Environmental Protection Agency

SW846 = "Test Methods For Evaluating Solid Waste, Physical/Chemical Methods", Third Edition, November 1986 And Its Updates.

Laboratory References:

EET SAC = Eurofins Sacramento, 880 Riverside Parkway, West Sacramento, CA 95605, TEL (916)373-5600

Eurofins Sacramento

Page 50 of 166

Released to Imaging: 7/25/2024 3:37:45 PM

Sample Summary

Client: Trihydro Corporation Project/Site: FTA- PFAS,Marathon Gallup Refinery,NM

lah	יחו	220 102072 1
JOD	ID:	320-102972-1

Lab Sample ID	Client Sample ID	Matrix	Collected	Received
320-102972-1	SS-5	Solid	07/26/23 10:50	07/27/23 09:40
320-102972-2	SS-6	Solid	07/26/23 11:05	07/27/23 09:40
320-102972-3	SS-7	Solid	07/26/23 11:45	07/27/23 09:40
320-102972-4	SS-8	Solid	07/26/23 12:05	07/27/23 09:40
320-102972-5	Dup-1	Solid	07/26/23 00:00	07/27/23 09:40
320-102972-6	EB-1	Water	07/26/23 10:35	07/27/23 09:40
320-102972-7	FB-1	Water	07/26/23 10:30	07/27/23 09:40

5

) 🐝 CUrofins Environment Testing America	TAL-8210 COC No ⁻ of / COCs	Sampler For Lab Use Only Walk-in Client:	Lab Sampling. Job / SDG No	Sample Specific Notes.									Sample Disposal (A fee may be assessed if samples are retained longer than 1 month)	Archive for Months	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	J Therm ID No Vo V	a pajetime.	Date/Time	Date/Time
cord 703730	Date Carrier										320-102972 Chain of Custody		e may be assessed if samples	Disposal by Lab	なせ	(°C): Obs'd	Company Company	Company	oy ⁻ Company ⁻
of Cust	ES CRCRA Cother Site Contact: Lab Contact:	(N	SKIG VO	1	MXX W	XX	X				320-10		1	Return to Client	c	// Rooter Temp	Joph Received by U	Received by	Received in Laboratory by
	Regulatory Program Dw Dw Nepes ject Manager Aw A A A A A A A A A A A A A A A A A A	Analysis Turnaround Time ENDAR DAYS UWORKING DAYS AT If different from Below	2 weeks 1 week 2 days 1 dav	Sample Sample Type (c=comp, for the control of the control of the case of the control of the con	10:50 F 50.1	Il I I I	54:1	1/1/1/	>>>>>	N M)(her	Please List any EPA Waste Codes for the sample in the	Unknown				Date/Time:	Date/Time
	Project N Tel/Emai	57347 KCALE		Sample Sa Date T	01 [2]92/2	7/26/23 11.			x 2/00/1			 3= H2SO4; 4=HNO3; 5=NaOH, 6= Other	aste? Please List any EPA sample	Skin Irritant [] Poison B	ments		2	_	Company.
Address.	y Name	ress 91 State/Zip: Jw	Fax Project Name: FTA Site: (テレ) レのハハ P0# ドイフ-105- 002	8 01	SS-S	55-6	١	25	1-10-1 FR-1	FB-1		HCI,	Possible Hazard Identification Are any samples from a listed EPA Hazardous Waste? Comments Section if the lab is to dispose of the sample	X Non-Hazard C Flammable C	Special Instructions/QC Requirements & Comments	Custody Seals Intact:	Relinquished by Ast POA W 40125	-	Relinquished by

Received by OCD: 4/16/2024 4:15:20 PM

Page 52 of 166

•

Login Sample Receipt Checklist

Client: Trihydro Corporation

Login Number: 102972 List Number: 1 Creator: Medeiros, Ryan M

Question	Answer	Comment
Radioactivity wasn't checked or is = background as measured by a survey meter.</td <td>True</td> <td></td>	True	
The cooler's custody seal, if present, is intact.	True	2100137
Sample custody seals, if present, are intact.	N/A	
The cooler or samples do not appear to have been compromised or tampered with.	True	
Samples were received on ice.	True	
Cooler Temperature is acceptable.	True	
Cooler Temperature is recorded.	True	
COC is present.	True	
COC is filled out in ink and legible.	True	
COC is filled out with all pertinent information.	True	
Is the Field Sampler's name present on COC?	False	
There are no discrepancies between the containers received and the COC.	True	
Samples are received within Holding Time (excluding tests with immediate HTs)	True	
Sample containers have legible labels.	True	
Containers are not broken or leaking.	True	
Sample collection date/times are provided.	True	
Appropriate sample containers are used.	True	
Sample bottles are completely filled.	True	
Sample Preservation Verified.	N/A	
There is sufficient vol. for all requested analyses, incl. any requested MS/MSDs	True	
Containers requiring zero headspace have no headspace or bubble is <6mm (1/4").	True	
Multiphasic samples are not present.	True	
Samples do not require splitting or compositing.	True	
Residual Chlorine Checked.	N/A	

Job Number: 320-102972-1

List Source: Eurofins Sacramento

ATTACHMENT C

REVISED REPORT

OW-63 PFAS Investigation Work Plan



Western Refining Southwest LLC Gallup Refinery Gallup, New Mexico

EPA ID# NMD000333211

December 31, 2022 Revised April 16, 2024



Table of Contents

1.0	INTR	ODUCTION	4
	1.1	Background	4
	1.2	Hydrogeology	5
	1.3	PFAS-Containing Materials at the Refinery	5
2.0	FIELD	INVESTIGATION ACTIVITIES	7
	2.1	Phase 1: Groundwater Sampling at Existing Monitoring Wells	8
	2.2	Phase 2: Soil Sampling and Temporary Well Installation	9
	2.3	Phase 3: Groundwater Sampling at Temporary Wells	
	2.4	Investigation Derived Waste	11
	2.5	Equipment Decontamination	
3.0	ANAI	LYTICAL METHODS	13
4.0	QUA	LITY ASSURANCE AND QUALITY CONTROL	14
	4.1	Field Quality Assurance and Quality Control Samples	14
	4.2	Laboratory Assurance and Quality Control Samples	15
	4.3	Data Validation	15
5.0	SCHE	DULE AND REPORTING	17
6.0	REFE	RENCES	18

.



List of Figures

- 1-1. Groundwater and Soil Sampling Location Map, OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico
- 1-2. Potentiometric Surface Map (December 2021), OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico
- 1-3. Potentiometric Surface Map (March 2022), OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico
- 1-4. Potentiometric Surface Map (June 2022), OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico
- 1-5. Potentiometric Surface Map (September 2022), OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico

List of Tables

- 2-1. Summary of PFAS Soil and Groundwater Sample Identification, Sample Methods, and Analytical Methods, OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico
- 2-2. Summary of Existing Wells, OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico
- 2-3. Proposed Groundwater and Soil Sample Constituent List, OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico

List of Appendices

- A. OW-63 PFAS Sampling Results
- B. PFAS Sampling Standard Operating Procedure
- C. Standard Operating Procedure: Low Flow Groundwater Sampling
- D. Example Logs

Printed on April 16, 2024



List of Acronyms

AFFF	aqueous film forming foams
CLP	Contract Laboratory Program
COC	chain of custody
DP	direct push
EDD	electronic data deliverables
ft/day	foot/feet per day
HDPE	high-density polyethylene
I-40	Interstate 40
IDW	investigation derived waste
LCS/LCSD	laboratory control samples/laboratory control sample duplicates
MS/MSD	matrix spike/matrix spike duplicates
NM	New Mexico
NMED	New Mexico Environment Department
PE	polyethylene
PFAS	per- and polyfluoroalkyl substances
PFBS	perfluorobutane sulfonate
PFOA	perfluorooctanoic acid
PFOS	perfluorooctane sulfonate
PID	photoionization detector
PPE	personal protective equipment
PVC	polyvinyl chloride
QA/QC	quality assurance and quality control
QSM	Quality System Manual
SOP	standard operating procedure
SPH	separate phase hydrocarbons
USEPA	United States Environmental Protection Agency
VOC	volatile organic compound

Printed on April 16, 2024

.



1.0 Introduction

Trihydro Corporation (Trihydro) has prepared this per- and polyfluoroalkyl substances (PFAS) Investigation Work Plan (Work Plan) to conduct PFAS sampling in soil and groundwater near monitoring well OW-63 at the Gallup Refinery (Refinery). Figure 1-1 shows the site location and the area surrounding OW-63. This Work Plan was developed per New Mexico Environment Department's (NMED) request in Comment 12 of the "Approval with Modifications 2021 Annual Groundwater Monitoring Report" (NMED 2022), dated August 23, 2022: "...a PFAS plume may be present in the vicinity of OW-63. Submit a work plan to investigate the extent of the PFAS contamination no later than December 31, 2022".

The following objectives were developed to address NMED's comment:

- Identify PFAS-containing materials near OW-63.
- Identify areas where potential PFAS-containing materials have been potentially stored and/or used near OW-63.
- Describe a proposed sampling and analysis plan for various environmental matrices that delineates the extent of PFAS contamination near OW-63.

1.1 Background

Built in the 1950s, the Refinery is located within a rural and sparsely populated area east of Gallup, New Mexico (NM). The nearest population centers are the Pilot Flying J Travel Center refueling plaza, the Interstate 40 (I-40) corridor, and a small cluster of residential homes located on the south side of I-40 approximately 2 miles southwest of the Refinery (Jamestown, NM).

The Refinery was indefinitely idled on October 9, 2020. During operation, the Refinery was a crude oil refining and petroleum products manufacturing facility. There were no organic chemicals, plastics, or synthetic fibers manufactured that contributed to the process flow of wastewater. The Refinery did not manufacturer lubricating oils. As a result of the processing steps, the Refinery produced a wide range of petroleum products including propane, butane, unleaded gasoline, diesel, residual fuel, and commercial products of fertilizer and solid elemental sulfur.

Historically, the Refinery primarily received crude oil via two 6-inch diameter pipelines, which entered the Refinery property from the north (Four Corners Area). In addition, the Refinery also received natural gasoline feedstock via a 4-inch diameter pipeline that came in from the west along the I-40 corridor from the Western Refining Southwest LLC Wingate Plant, which is also indefinitely idled. Crude oil and other products also arrived at the Refinery via railroad cars. These feed stocks were then stored in tanks until refined into products.

Trihydro conducts groundwater sampling for PFAS at OW-63 on a quarterly basis. PFAS sampling in OW-63 began with NMED's request in Comment 30 in the "Disapproval Annual Groundwater Monitoring Report Gallup Refinery – 2019" (NMED, 2020) dated November 23, 2020: "...Well OW-63 is appropriately located to evaluate

Printed on April 16, 2024



for the presence of PFAS in the vicinity of the training area. Propose to conduct PFAS analysis for the groundwater samples collected from well OW-63 in the 2021 Facility-wide Groundwater Monitoring Work Plan." These results are included in the annual groundwater monitoring reports and in Appendix A. Currently, no other wells at the Refinery are sampled for PFAS.

The sections below describe site hydrogeology and PFAS-containing materials likely used at the refinery. More information regarding site background and hydrology can be found in the annual groundwater work plans and reports.

1.2 Hydrogeology

Groundwater flow within the shallow alluvium and the upper Chinle Formation is highly variable due to the presence of complex and irregular stratigraphy including sand stringers, cobble beds, and dense clay layers. Hydraulic conductivity ranges from 30 feet per day (ft/day) for gravel-like sands immediately overlying the Petrified Forest Formation to 3×10^{-5} ft/day in the clay soils located near the surface. Groundwater flow within the Lower Chinle Formation is extremely slow and typically averages less than 2.83 x 10^{-7} ft/day (i.e., less than 0.01 ft per year).

Water level data are collected routinely at the Refinery. Wells at the Refinery have been categorized based on the hydrogeologic unit in which they are screened, including the alluvial/fluvial upper sand aquifer, the Chinle/alluvium aquifer, and the Sonsela Sandstone aquifer. The alluvial/fluvial upper sand aquifer has a limited lateral extent, existing only on the western margin of the Refinery. Groundwater occurrence in this aquifer is sporadic and limited.

Most of the wells monitored lie within the shallow weathered sediments that comprise the Chinle/alluvium aquifer. Within the Chinle/alluvium aquifer, shallow groundwater located under the Refinery property generally flows along the upper contact of the Chinle Formation. The prevailing flow is from the southeast to the northwest, although localized areas may have varying flow directions based on the subsurface geology.

Groundwater within the Sonsela aquifer flows southeast to northwest. Hydraulic heads measured within the Sonsela are generally lower than those observed within the shallow aquifer near the topographic high on which the Refinery process area and tank farm are situated, and higher than those observed within the shallow aquifer in topographically low areas to the west and northwest, near the evaporation ponds. The higher head in the Sonsela in low areas is due to confining pressure from lower permeability Chinle Formation bedrock between the shallow Chinle/alluvium aquifer and the Sonsela Sandstone bed at depth, which makes the Sonsela Sandstone aquifer artesian. Figures 1-2, 1-3, 1-4, and 1-5 show quarterly potentiometric surface maps for the investigation area.

1.3 PFAS-Containing Materials at the Refinery

Since the 1950s, PFAS have been incorporated into many consumer and industrial products. One of the many historical uses is in firefighting foams ("Aqueous Film Forming Foams," or AFFF). AFFF products may be used for fire suppression at facilities where Class B fires (i.e., those involving flammable liquids and gases) may be a

Printed on April 16, 2024



concern, including airports, firefighting training areas, and other facilities where flammable hydrocarbons are present. AFFF formulations include hundreds to thousands of individual fluorinated and non-fluorinated surfactant compounds. Perfluorooctanoic acid (PFOA), perfluorooctane sulfonate (PFOS), and perfluorohexane sulfonate (PFHxS) are potential PFAS constituents in AFFF products, particularly in those produced between the 1960s and 1990s (ITRC 2022a). Modern AFFF products contain little to no PFOA or PFOS but may contain shortchain PFAS compounds such as perfluorobutane sulfonate (PFBS).

Firefighting is a component of petroleum refinery management. AFFF has been stored and historically used for fire suppression at the Refinery. Located to the northwest of OW-63 is the former Fire Training Area, where PFAS-containing foam was confirmed to be used. OW-63 is located downgradient of the Tank Farm and cross gradient of the former Fire Training Area. There are no known applications of PFAS-containing foam in the Tank Farm area immediately adjacent to OW-63. All firefighting foams have been removed from the Refinery.



2.0 Field Investigation Activities

Many PFAS compounds are potentially mobile in groundwater and are prone to accumulate at air/water and oil/water interfaces (Brusseau 2018, ITRC 2022b). The sampling program described herein has been developed to account for these aspects, with sampling designed to identify potentially mobile PFAS within the bulk water phase (i.e., avoiding interfaces) associated with shallow groundwater. The sections below describe the sampling locations, field methods for groundwater sampling and soil sampling, and details of temporary well installation.

This field investigation will be completed in a three-phase plan:

- Phase 1: Groundwater sampling at four existing groundwater monitoring wells (OW-12, OW-14, OW-57, OW-63, and OW-70). These wells are located cross gradient and down gradient of OW-63 (Figure 1-1).
- Phase 2: Soil sampling at five surface locations and three soil boring locations. The three soil boring locations will be constructed as temporary groundwater monitoring wells. Exact locations for the surface sample locations and temporary monitoring wells will be chosen based on groundwater analytical results from Phase 1.
- Phase 3: Groundwater sampling at the three temporary well locations.

Phase 1 of the investigation will be implemented so analytical results from existing groundwater monitoring wells can be used to determine the most beneficial locations for the temporary groundwater monitoring wells. Groundwater samples will be obtained from existing groundwater monitoring wells during Phase 1. After the Phase 1 investigation is complete, the Refinery will schedule a meeting with NMED to discuss and agree upon proposed Phase 2 sample locations.

The Phase 2 soil sampling and temporary groundwater monitoring well installations will occur during the same field event after Phase 1 analytical data are received. Soil sampling will involve surface sample collection and the drilling of boreholes using direct push drilling techniques. Phase 3 of the investigation is for the collection of groundwater samples, which will occur after the temporary groundwater monitoring wells have been installed for a minimum of seven days. Supporting activities include utility location, boring abandonment, waste management, and equipment decontamination. A handheld global positioning system unit will be used to log location coordinates for utilities, soil sampling locations, and the temporary monitoring wells. Table 2-1 presents a summary of the proposed soil and groundwater sample identifications, sample methods, sample type, constituents, and analytical methods.

Sampling will be conducted by experienced PFAS sampling personnel who will review and be familiar with the prohibited material list, in terms of clothing, personal protective equipment (PPE), sunscreens, insect repellent, rain-repellent gear, and other sampling equipment that are prohibited when sampling for PFAS as to prevent cross-contamination. Care will be taken to ensure that any materials contacting sample containers, from the time of removal from laboratory-supplied coolers through completion of sampling, comply with Table 1 of



Trihydro's PFAS Standard Operating Procedure (SOP) (Appendix B). A fresh pair of powderless nitrile gloves will be worn at each location, and gloves will be changed immediately before collecting each sample, in accordance with the SOP. Additional hand washing before donning of the new pair of gloves is necessary if the old pair was compromised or ungloved hands touched items that may contain PFAS. Sampling procedures will be reviewed prior to field activities to identify potential conflicts between site PPE requirements and PFAS-compatible materials. If conflicts are identified, procedures will be developed to minimize PFAS cross-contamination risks without compromising the Refinery's health and safety procedures.

2.1 Phase 1: Groundwater Sampling at Existing Monitoring Wells

The former Fire Training Area was identified as a potential PFAS-containing foam application area at the Refinery. Based on this identification, five existing groundwater wells are selected for PFAS sampling. Figure 1-1 provides the sample well locations. Additional information for OW-12, OW-14, OW-63, OW-57, and OW-70, including the screened interval, depth to groundwater, and total measured depth of well, is shown in Table 2-2. Groundwater samples will be analyzed for the PFAS parameters listed in Table 2-3. The reporting limits for the analytes on Table 2-3 will be dependent upon the lab selected for PFAS analysis. Reporting limits will be evaluated against NMED PFAS screening levels once a lab has been selected.

2.1.1 Fluid Level Monitoring

Fluid levels will be monitored in all wells prior to sampling using an interface probe. Fluid level monitoring will be conducted to evaluate for the presence of separate phase hydrocarbons (SPH) in wells and measure depth to groundwater. Historically, the wells selected for groundwater sampling have not had SPH in them. The interface probe will only be used to measure the fluid surface and SPH thickness (total depth will not be measured as part of the PFAS sampling event) to limit cross-contamination by minimizing contact between groundwater and the interface probe. Any well with detectable SPH will be removed from the monitoring list for this event and, if possible, an alternative well will be selected. The interface probe will be decontaminated prior to first use, and between each monitoring well, using PFAS-compatible methods in accordance with Appendix B.

2.1.2 Groundwater Sample Collection

Groundwater samples will be collected from monitoring wells OW-12, OW-14, OW-63, OW-57, and OW-70 using low flow sampling techniques and analyzed for PFAS compounds (Table 2-3). Low-flow or no-purge sampling approaches are generally preferred for PFAS sampling. PFAS may be associated with suspended solids, droplets of SPH, or entrained gas bubbles, any of which may be mobilized via high-volume purging sampling methods. Low flow sampling involves collecting groundwater directly from the screened interval without disturbing stagnant water above the screen. This is accomplished by pumping the well at low enough flow rates to maintain minimal drawdown of the water column.

Printed on April 16, 2024

Page 64 of 166



Western Refining Southwest LLC Gallup Refinery OW-63 PFAS Investigation Work Plan

Groundwater sampling for PFAS compounds will be conducted using low flow sampling methods in general accordance with the following guidance documents:

- Trihydro's PFAS SOP, included in Appendix B
- Trihydro's SOP for low flow sampling, included in Appendix C

Since this method is not based upon the removal of well volumes, it requires in-line monitoring of water-quality parameters (i.e., pH, specific conductivity, temperature, dissolved oxygen, redox potential) to determine when the groundwater to be sampled has stabilized. Stabilization occurs when three consecutive readings of water-quality parameters are within 10 percent. The sample is then collected, using the same pump, directly from the discharge tubing. Wells with dedicated pumps (i.e., OW-12 and OW-63) will be noted on the field logs and will use existing equipment in place.

Prior to placing the discharge line of the pump into the well, the sampler will verify the screened interval of the well to determine the length of discharge line to be placed in the well. The target sampling depth for each of the wells is the mid-point of the screened interval. This information is used to ensure that the samples are collected within the screened interval, and that water samples are representative of the formation. They will also verify the recharge capacity of the well to determine what flow the pump will be set at so that draw down is not occurring.

Sample containers will be filled immediately from the pump discharge line. Bottles will be filled in accordance with the low flow SOP and laboratory instructions. After being filled, sample containers will be placed in a cooler with double-bagged water-based ice (i.e., Blue Ice[™] or similar substitute materials are prohibited) for shipment.

To the extent practical, disposable sampling equipment will be used at each location to minimize the potential disturbance of formation groundwater and to reduce the risk of cross-contamination. Furthermore, all downhole monitoring or sampling equipment will not contain or be coated with Teflon[®] or other PFAS-incompatible materials (Appendix B). If reusable equipment is required, decontamination will occur as described in Section 2.5.

Equipment to be used during field sampling will be examined to certify that it is in operating condition. This includes checking the manufacturer's operating manual, as well as the instructions for each instrument, to ensure that maintenance requirements are being observed. Sample coolers will be shipped to an analytical laboratory via overnight delivery under chain of custody (COC) protocol.

2.2 Phase 2: Soil Sampling and Temporary Well Installation

Surface soil samples will be collected at five locations within the OW-63 area based on Phase 1 groundwater data and site topography, as identified on Figure 1-1. In addition, surface and subsurface soil samples will be collected from the three proposed temporary groundwater monitoring well boreholes that will be installed within the OW-63 area based on Phase 1 groundwater data, as identified on Figure 1-1. All soil samples will be analyzed for the PFAS parameters listed in Table 2-3.

Printed on April 16, 2024



2.2.1 Surface Soil Sampling

Surface soil samples will be collected from 0 to 1 ft below ground surface (ft bgs). Soil samples will be collected using a PFAS-free disposable hand trowel. At each location, a new hand trowel will be used. Sampling information will be recorded on an example log provided in Appendix D-1.

2.2.2 Subsurface Soil Sampling

Subsurface soil sampling will be conducted using a direct-push (DP) drilling rig capable of advancing continuous soil sample barrels. DP soil sampling will be conducted at three locations to be determined based on analytical results from Phase 1 of the investigation. Soil samples will be collected from the borings at two intervals: the surface (0 to 1 ft bgs) and 1 ft above the water table (approximately 17 to 34 ft-bgs).

Soil sample barrels will be decontaminated prior to each boring. Samples will be collected in an acetate liner or approved equivalent. The acetate sleeve containing the sample interval will be split in half and samples will be transferred directly from the sleeve to a lab-provided sample jar. For these locations, Trihydro field staff will prepare continuous boring logs of soil samples to the water table, recording lithology and appearance of the boring, and performing field screening of the soil cores using a photoionization detector (PID). An example boring log is shown in Appendix D-2.

2.2.3 Temporary Well Installation

Three proposed temporary wells will be completed in the soil borings installed as described in Section 2.2.2. The locations will be determined based on the analytical results from the groundwater sampling in the existing monitoring wells. Temporary wells will be completed with schedule 40 polyvinyl chloride (PVC). Slotted (0.01 inch) PVC well screen will be placed at the bottom of soil borings completed as a temporary well completion. The screen will extend 10 to 15 ft to ensure that the well is screened across the water table. A 10/20 sand filter pack will be installed to 2 ft above the top of the well screen. The well will be completed to the surface with bentonite chips.

2.3 Phase 3: Groundwater Sampling at Temporary Wells

After temporary well completion, the wells will be left to stand for a minimum of 7 days to allow for the possible entry of SPH into the well, if present. After a minimum of 7 days, the temporary wells will be gauged and sampled using the same methods described in Sections 2.1.1 and 2.1.2.

After groundwater samples are collected from the temporary wells, the PVC casing and well screen will be pulled and all borings will be abandoned with bentonite chips, pellets, or grout, from the bottom of the boring to the ground surface. Bentonite chips or pellets placed above the water table will be hydrated with at least 1 gallon of water per 5 feet of boring.



2.4 Investigation Derived Waste

Investigation derived waste (IDW) will include solid IDW (drill cuttings and excess direct-push soil), liquid phase IDW (purged water), and debris (used acetate liners, nitrile gloves, etc.). IDW will be labeled appropriately to identify the generator, contents, date of generation, and provide contact information.

Solid phase IDW will be stored in a lined roll-off container or in sealed Department of Transportation-rated drums at a location to be determined at the site, pending waste characterization. Solid phase IDW is not expected to be characteristically hazardous but may contain PFAS or volatile organic compounds (VOCs) at concentrations requiring disposal at an appropriately licensed solid waste facility. After all solid phase IDW is accumulated, Trihydro will collect a composite sample for waste characterization. Analytical requirements will depend on the receiving solid waste facility and will be determined prior to disposal. IDW will be transported to the disposal facility by a licensed waste hauler.

Liquid phase IDW will be stored in drums at a location to be determined at the site pending characterization for disposal. Liquid phase IDW is not expected to be characteristically hazardous but may contain PFAS or VOCs at concentrations requiring disposal at an appropriately licensed facility. After all liquid phase IDW is accumulated, Trihydro will collect a composite sample for waste characterization. Analytical requirements will depend on the receiving facility and will be determined prior to disposal. IDW will be transported to the disposal facility by a licensed waste hauler.

Investigation debris will be disposed of as non-hazardous municipal waste at a local landfill.

2.5 Equipment Decontamination

Reusable sampling and drilling equipment will be decontaminated between samples using Alconox or a pressure washer, followed by rinsing with PFAS-free potable water. When not in use, cleaned reusable sample equipment will be stored in HDPE plastic bags or sheeting to minimize the potential for cross-contamination.

PFAS tend to adhere to sampling equipment and have been noted in certain detergents. To the extent practical, disposable equipment will be used for each monitoring/temporary well. Reusable sampling components will be decontaminated, for potential future redeployment in the same well, in accordance with Trihydro's SOP (Attachment A) with the following notes/modifications. Specifically, decontamination will also be required for the interface probe and will be performed between each well to reduce the risk of cross-contamination. Decontamination of the reusable components will consist of three steps:

- 1. Wash in Alconox or Liquinox detergents (Decon 90 is on the prohibited material list and will not be used).
- 2. Triple rinse with distilled water.
- 3. Final triple-rinse with commercially available or laboratory-provided PFAS-free deionized water in an HDPE container.

Printed on April 16, 2024

Received by OCD: 4/16/2024 4:15:20 PM



Western Refining Southwest LLC Gallup Refinery OW-63 PFAS Investigation Work Plan

If necessary, sampling equipment will be scrubbed using a polyethylene (PE) or polyvinyl chloride (PVC) brush to remove particulates prior to completing the decontamination steps listed above.

.



3.0 Analytical Methods

PFAS analysis will be conducted by a laboratory with PFAS-specific experience, using method 537.1 or equivalent that utilizes isotope dilution and is compliant with Quality Systems Manual (QSM) version 5.3 (or later) Table B-15. Promulgated United States Environmental Protection Agency (USEPA) Methods 533 and 537 are both specified as drinking water methods and cannot be applied to the sample matrices collected in this event. There are no promulgated USEPA methods for analyzing PFAS in groundwater (Method 1633 is still in draft form). As such, the analytical results for these media using standardized drinking water methods, or non-standardized laboratory specific methods, must be interpreted with caution. Additional discussion is provided in Appendix B.

The selected laboratory will provide fully documented commercial-type data packages (e.g., equivalent to full USEPA Contract Laboratory Program data packages) for all analytical results and electronic data deliverables (EDDs).



4.0 Quality Assurance And Quality Control

This section addresses the qualitative and quantitative criteria that will be used to evaluate the quality of the field and analytical data collected during the field activities.

4.1 Field Quality Assurance and Quality Control Samples

Five kinds of field quality assurance and quality control samples (QA/QC) will be collected during the sampling event as described below.

- <u>Duplicate Samples</u>. Duplicate samples will be collected to evaluate precision associated with the reproducibility of sampling techniques and the homogeneity of sample matrices. One duplicate sample will be collected per matrix, and at a minimum frequency of 10%, or one for every 10 samples. The duplicate sample will be "blind" to the laboratory; therefore, it will have a coded identity on its label and on the COC. The actual sampling location and identification will be recorded on the sampling log.
- 2. <u>Trip Blanks</u>. Trip blanks are generally not required for PFAS samples but may be helpful to identify sources of contamination, should they occur. A trip blank, comprising PFAS-free water supplied by the laboratory, will accompany each cooler that contains PFAS samples. Experience has shown that cross-contamination at analytical laboratories can lead to spurious PFAS detections. The trip blanks prepared by the laboratory can point to the reagent water used by the laboratory as a source of contamination not related to field sampling procedures.
- 3. <u>Field Blanks</u>. Field blanks will be collected in the vicinity of the project area. Field blanks will be collected by pouring laboratory provided PFAS-free water into the appropriate containers and submitted for PFAS analysis. A field blank will be collected at each separate groundwater well, groundwater, and soil sampling event.
- 4. Equipment Blanks. Equipment blanks will be prepared and submitted for laboratory analysis to assess sampling equipment for potential PFAS impacts and to verify that equipment decontamination procedures are effective. One equipment blank will be collected for groundwater samples from the interface probe to verify that decontamination procedures are effective. Additional equipment blanks will be collected from the trowels to verify that each of the batches received from the manufacturer is PFAS free.
- 5. <u>Matrix Spike/Matrix Spike Duplicates (MS/MSD)</u>. MS/MSDs will be prepared and analyzed by the laboratory for each matrix sampled. The following MS/MSDs will be collected: one from a permanent groundwater well and one from a temporary groundwater well. MS/MSDs are samples in which known quantities of specific PFAS compounds are added before extraction and analyses. The recoveries for spiked compounds can be used to assess how well the method for analysis recovers target compounds.



4.2 Laboratory Assurance and Quality Control Samples

QA/QC samples will be analyzed by the laboratory. The laboratory will follow proper QA/QC procedures, including laboratory blanks, duplicates, and spiked samples for calibration and identification of potential matrix effects. Data from the QC samples are used as a measure of performance and as an indicator of potential sources of cross-contamination. In addition, for PFAS analysis, the laboratory will follow QC procedures compliant with QSM Table B-15 QC. QC data generated by the laboratory are submitted with the results in the fully documented commercial type data packages.

- 1. <u>MS/MSD</u>. MS/MSD will be performed if sufficient sample is recovered and indicated on the COC. If not, lab will perform laboratory control samples (LCS) and laboratory control sample duplicates (LCSD).
- 2. <u>Surrogate Spiking</u>. Surrogate compounds are added before sample preparation for organics to all samples prior to extraction and analysis. The review for surrogate compounds can be used to assess method accuracy for each sample matrix.

4.3 Data Validation

Analytical data received from the laboratory will undergo Trihydro's data validation process. Minimally, data will be evaluated by the Tier I and Tier II data validation process. Trihydro uses the following guidance documents for validation of organic and inorganic data:

- Data for organic analyses are evaluated according to validation criteria set forth in the USEPA Contract Laboratory Program (CLP) National Functional Guidelines for Organic Superfund Methods Data Review, document number EPA-540-R-20-005, November 2020 with additional reference to the USEPA CLP National Functional Guidelines for Organic Data Review, document number EPA 540/R-99/008, October 1999.
- Review of PFAS data will also use criteria set forth in the Department of Defense / Department of Energy QSM for Environmental Laboratories, Version 5.3, 2019. This reference document has specific criteria for review of PFAS data in Appendix C, Table B-15 that are used in conjunction with the National Functional Guidelines.
- Data for inorganic analyses is evaluated according to validation criteria set forth in the USEPA CLP National Functional Guidelines for Inorganic Superfund Methods Data Review, document number EPA-542-R-20-006, November 2020 with additional reference to the USEPA CLP National Functional Guidelines for Inorganic Data Review, document number EPA 540-R-04-004, October 2004.
- Review of field duplicates will be conducted according to the USEPA Region 1 New England Environmental Data Review Supplement for Region 1 Data Review Elements and Superfund Specific Guidance/Procedures, EQADR-Supplement2, September 2020.

Precision, accuracy, method compliance, and completeness of the data packages will be assessed during the data validation process. Precision is determined by evaluating the calculated relative percent difference values

Printed on April 16, 2024



from: laboratory duplicate pairs, MS/MSD pairs, and LCS/LCSD pairs. Laboratory accuracy is established by reviewing the demonstrated percent recoveries of the following items to identify potential biases in the analytical data: MS/MSD samples, LCS/LCSD samples, and organic system monitoring compounds (surrogates). Field accuracy is established by collecting and analyzing field QA/QC samples to monitor for possible ambient or cross-contamination during sampling and transportation. Method compliance is established by reviewing sample integrity, holding times, detection limits, surrogate recoveries, laboratory blanks, initial and continuing calibrations (where applicable), and the LCS/LCSD percent recoveries against method-specific requirements. Completeness is evaluated by determining the overall ratio of the number of samples and analyses planned versus the number of samples with valid analyses. Determination of completeness includes a review of the COC, laboratory analytical methods, and other laboratory and field documents associated with the analytical data set



5.0 Schedule and Reporting

The scheduling of field activities associated with the Work Plan are dependent upon regulatory review and approval. Field coordination will commence upon written approval of the Work Plan by NMED. Trihydro estimates the field portion of the Work Plan will take approximately one to two weeks to complete over several months due to the phased approach. Phase 1 through 3 of the investigation are planned to be completed in 2023, pending written Work Plan approval. Interpretation of results and preparation of documents are planned to be completed in late 2023 or early 2024, pending field investigation.

The final report will include the following:

- 1. A description of the sampling activities performed and deviations from the Work Plan
- 2. A summary table of the analytical results (including QA/QC samples)
- 3. A copy of the COC forms
- 4. A copy of the field sampling logs
- 5. A copy of existing monitoring well construction details and historical survey data for OW-12, OW-14, OW-57, OW-63, and OW-70
- 6. A copy of the site map showing the sampling/monitoring locations
- 7. A copy of laboratory certified analytical results


Western Refining Southwest LLC Gallup Refinery OW-63 PFAS Investigation Work Plan

6.0 References

- Armstrong, M., M.J. Seitz, F. Beetle-Moorcroft, and D.S. Lipson. 2020. No-Purge Groundwater Sampling for PFAS. Groundwater–Vol. 58, No. 6. November-December 2020.
- Brusseau. 2018. Assessing the Potential Contributions of Additional Retention Processes to PFAS Retardation in the Subsurface. Science of the Total Environment 613–614 (2018) pp. 176–185.
- Giant Refining Company-Cinzia Refinery. 2001. No Further Action Report, SWMUs 7, 9, 10, 11, 12, 13. Revision 0.0, Volume II pp. 7-1. August.
- Interstate Technology Regulatory Council (ITRC). 2022a. History and Use of Per- and Polyfluoroalkyl Substances (PFAS) Found in the Environment. Updated July 2022. Available from: <u>https://pfas-1.itrcweb.org/wpcontent/uploads/2022/09/HistoryandUse_PFAS_Fact-Sheet_090722_508.pdf</u>.
- ITRC. 2022b. Fate and Transport of Per- and Polyfluoroalkyl Substances (PFAS). July 2022. Available from: https://pfas-1.itrcweb.org/wp-content/uploads/2022/09/FT_PFAS_Fact_Sheet_083122_508.pdf.
- NMED. 2020. Disapproval Annual Groundwater Monitoring Report Gallup Refinery 2019, Western Refining Southwest LLC, Gallup Refinery, McKinley County, Gallup, New Mexico, EPA ID #NMD000333211, HWB-WRG-20-013. November 23.
- NMED. 2022. Approval with Modifications 2021 Annual Groundwater Monitoring Report, Western Refining
- Southwest LLC, Gallup Refinery, McKinley County, Gallup, New Mexico, EPA ID #NMD000333211, HWB-WRG-22-006. October 18.

Received by OCD: 4/16/2024 4:15:20 PM



Western Refining Southwest LLC Gallup Refinery OW-63 PFAS Investigation Work Plan

Figures

EXPLANATION

• OW-12	CHINLE / ALLUVIUM AQUIFER WELL AND DESIGNATION (WELLS FOR GROUNDWATER SAMPLING DURING PHASE 1)
⊕ RW-5	RECOVERY WELL AND DESIGNATION
	PROPOSED TEMPORARY WELL AND SOIL INVESTIGATION AREA
	(SEE NOTE A)
X	FENCE LINE

PFAS HEALTH ADVISORY LEVELS

CONCENTRATION PARTS PER TRIL	LION	SOURCE
PFOA+PFOS+PFHxS ⁴	70	NMED HEALTH ADVISORY
PFBS ^{5,6}	2000	FINAL HEALTH ADVISORY LIMIT (UPDATED AS OF 6/15/2022)
PFOA ^{5,6}	0.004	2022 INTERIM HAL UPDATED (UPDATED AS OF 6/15/2022)
PFOS ^{5,6}	0.02	2022 INTERIM HAL UPDATED (UPDATED AS OF 6/15/2022)

NOTES:

- A. THREE TEMPORARY WELLS AND FIVE SURFACE SAMPLES WILL BE LOCATED WITHIN THE INVESTIGATION AREA BASED ON EXISTING WELL GROUNDWATER **RESULTS RECEIVED DURING PHASE 1**
- B. ALL CONCENTRATIONS ARE REPORTED IN NANOGRAMS PER LITER (ng/L) WHICH IS EQUIVALENT TO PARTS PER TRILLION (ppt) C. PFAS = PER- AND POLYFLUOROALKYL
- SUBSTANCES
- D. COC = CONSTITUENT OF CONCERN
- E. PFBS = PERFLUOROBUTANE SULFONATE
- F. HAL = HEALTH ADVISORY LEVELS
- G. HFPO = HEXAFLUOROPROPYLENE OXIDE





ANALYTE TABLE EXPLANATION

	WELL DESIGNATION	OW-63		6/	15/21	SAMPLE DATE
	PERFLUOROOCTANOIC ACID	PFOA ^{1,2}	5	0.46	5	
NOTEO	PERFLUOROOCTANE SULFONIC ACID	PFOS ^{1,2}	N/A	2.8	N/A	
NOTES:	PERFLUOROHEXANE SULFONATE	PFHxS ²	5	0.17	3.8	
1. EPA IDENTIFIED PFOS COC	PERFLUOROBUTANOIC ACID	PFBA ³	N/A	0.46	N/A	

1. EP 2. NMED IDENTIFIED PFOS COC

- 3. NOT AN EPA/NMED PFOS COC; HOWEVER, HIGH MOBILITY. DATA PROVIDED FOR INFORMATION.
- 4. NEW MEXICO ENVIRONMENT DEPARTMENT, RISK ASSESSMENT GUIDANCE FOR SITE INVESTIGATIONS AND REMEDIATION, VOLUME I, SOIL SCREENING GUIDANCE FOR HUMAN HEALTH RISK ASSESSMENTS, APPENDIX E, NOVEMBER 2021.
- 5. HAL FOUND AT https://www.epa.gov/system/files/documents/2022-06/prepublication-four-pfas-june-2022.pdf



1 million							
· · · ·							
1 1 1 Con		• OW-70)				
	1 -			Sec.			
• OW-12	PA.	2.0		- 21	23		
15/2				* *	* *		
1 1 2 2	APPRO	XIMATE LOC FIRE TRAIN	ATION OF		17	*	* *
				\rightarrow			
10000			-			/	
ALT AL			24		-1		
200	Thinks .			~ `			191.7
	ALC: N					~ ⁰	₩-63
the second se		OW-63 PFOA PFOS	6/15/21 127 547	123	2/17/21 106 454		
- Contraction	⊕ RW-5	PFOS PFHxS PFBA	547 325 ND(1.95)	516 278 91.2	454 237 153		
THE STATES	⊕ R	W-6	-	Alle			







- 6938 - -

● OW-12

NM

SPH

MKTF-50

ESTIMATED GROUNDWATER FLOW DIRECTION

SONSELLA MONITORING WELL AND DESIGNATION

SPH MONITORING WELL AND DESIGNATION

SEPARATE-PHASE HYDROCARBON

RECOVERY WELL

NOT MEASURED





0

SONSELLA MONITORING WELL AND DESIGNATION

SEPARATE-PHASE HYDROCARBON

RECOVERY WELL

NOT MEASURED

● OW-12

NM

SPH

N							
Λ					FIGURE 1	-3	
				POTENT	IOMETRIC SU	JRFACE MAP	
V	Til				(MARCH 20	22)	
	Trihydro			OW-63 PFAS	INVESTIGAT	ION WORK PLAN	
100' 200'	1252 Commerce	e Drive		WESTERN	REFINING SC	DUTHWEST LLC	
	Laramie, Wyomir www.trihydro	ng 82070		C	GALLUP REFI	NERY	
	(P) 307/745.7474 (F) 3		GALLUP, NEW MEXICO				
	Drawn By: REP	Checked B	y: BB	Scale: 1" = 100'	Date: 11/2/2022	File: 697-PFAS_OW-PS-202203	



0

- ESTIMATED GROUNDWATER FLOW DIRECTION
- MKTF-50 SPH MONITORING WELL AND DESIGNATION
 OW-12 SONSELLA MONITORING WELL AND DESIGNATION
 - 1 RECOVERY WELL
- ⊕ RW−1 NM
- NMNOT MEASUREDSPHSEPARATE-PHASE HYDROCARBON

N							
Λ				FIGURE 1	-4		
			POTENT	IOMETRIC S	URFACE MAP		
V	Til	(JUNE 2022) OW-63 PFAS INVESTIGATION WORK PLAN					
		UU	OW-63 PFAS INVESTIGATION WORK PLAN				
100' 200'	CORPORATION 1252 Commerce	e Drive	WESTERN REFINING SOUTHWEST LLC				
	Laramie, Wyomir		GALLUP REFINERY GALLUP, NEW MEXICO				
	www.trihydro (P) 307/745.7474 (F) 3						
	Drawn By: REP	Checked By: BB	Scale: 1" = 100'	Date: 11/2/2022	File: 697-PFAS_OW-PS-202206		



- MKTF-50 SPH MONITORING WELL AND DESIGNATION
- SONSELLA MONITORING WELL AND DESIGNATION ● OW-12
- 田 RW−1 RECOVERY WELL
- NM
- NOT MEASURED SPH SEPARATE-PHASE HYDROCARBON



Received by OCD: 4/16/2024 4:15:20 PM



Western Refining Southwest LLC Gallup Refinery OW-63 PFAS Investigation Work Plan

Tables

Sampling Media Type	Sample ID	Sampling Method	Sample Type	Constituents	Analytical Method	Extraction Hold Time
	OW-12	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	OW-14	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	OW-57	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	OW-63	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	OW-70	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	TW-1	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	TW-2	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	TW-3	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
Ň	GW Phase 1 Duplicate	low flow sampling	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
Samples	GW Phase 3 Duplicate	low flow sampling	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	GW Phase 1 Field Blank	NA	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
Groundwater	GW Phase 3 Field Blank	NA	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
Gro	GW Phase 1 Equipment Blank (Interface Probe)	NA	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	GW Phase 3 Equipment Blank (Interface Probe)	NA	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	GW Phase 1 Equipment Blank (Reusable equipment)	NA	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	GW Phase 3 Equipment Blank (Reusable equipment)	NA	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	GW Phase 1 Equipment Blank (Swagelock®)	NA	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	GW Phase 3 Equipment Blank (Swagelock®)	NA	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	GW Phase 1 MS/MSD	low flow sampling	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	GW Phase 3 MS/MSD	low flow sampling	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	Trip Blank	NA	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)

2-1-202403_SampleLocations_TBL-2-1.xlsx

Page 81 of 166

1 of 2

TABLE 2-1. SUMMARY OF PFAS SOIL AND GROUNDWATER SAMPLE IDENTIFICATION, SAMPLE METHODS, AND ANALYTICAL METHODS OW-63 PFAS INVESTIGATION WORK PLAN WESTERN REFINING SOUTHWEST LLC, GALLUP REFINERY, GALLUP, NEW MEXICO

Sampling Media Type	Sample ID	Sampling Method	Sample Type	Constituents	Analytical Method	Extraction Hold Time
	SS-1	trowel	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	SS-2	trowel	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	SS-3	trowel	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	SS-4	trowel	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	SS-5	trowel	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	TW-1 (surface)	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
amples	TW-1 (above water table)	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
s	TW-2 (surface)	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
Soil	TW-2 (above water table)	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	TW-3 (surface)	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	TW-3 (above water table)	low flow sampling	grab	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	SS - Duplicate	direct push sleeve or trowel	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	Trip Blank	NA	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	Field Blank	NA	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)
	Equipment Blank 4	NA	QA/QC	See Table 2-3 (PFAS)	Compliant with QSM 5.3, Table B-15 (PFAS)	14 days (PFAS)

Notes: ID - identification

GW - groundwater

QA/QC - quality assurance/quality control

QSM - Department of Defense, Department of Energy, Consolidated Quality Systems Manual (QSM) for Environmental Laboratories, DoD Quality Systems Manual Version 5.3, Appendix B, 2019

SS - surface sample TW - temporary well

NA - not applicable PFAS - per- and polyfluoroalkyl substances

All samples will be cooled to ≤ 6 degrees Celsius (°C)

Page 82 of 166

Received by OCD: 4/16/2024 4:15:20 PM

TABLE 2-2. SUMMARY OF EXISTING WELLS OW-63 PFAS INVESTIGATION WORK PLAN WESTERN REFINING SOUTHWEST LLC, GALLUP REFINERY, GALLUP, NEW MEXICO

Location	Date Measured	Depth to Product (ft-bgs)	Depth to Water (ft-bgs)	Product Thickness (ft)	Water Elevation (ft-msl)	Ground Surface Elevation (ft-msl)	Measuring Point Elevation (ft-msl)	Well Casing Height (ft)	Total Depth (ft-bgs)	Depth Top Screen (ft-bgs)	Depth Bottom Screen (ft-bgs)
OW-12	9/12/2014	ND	47.78	NA	6892.91	6939.57	6940.69	1.12	130.08	117.8	137.8
OW-12	8/13/2015	ND	47.42	NA	6893.27	6939.57	6940.69	1.12	130.08	117.8	137.8
OW-12	9/8/2016	ND	47.23	NA	6893.46	6939.57	6940.69	1.12	130.08	117.8	137.8
OW-12	9/19/2017	ND	46.74	NA	6893.95	6939.57	6940.69	1.12	130.08	117.8	137.8
OW-12	8/15/2018	ND	46.50	NA	6894.19	6939.57	6940.69	1.12	130.08	117.8	137.8
OW-12	6/30/2020	ND	Dry	NA	Dry	6939.57	6940.69	1.12	127.73	117.8	137.8
OW-12	9/14/2020	ND	45.33	NA	6894.24	6939.57	6940.69	1.12	130.08	117.8	137.8
OW-12	11/9/2020	ND	45.37	NA	6894.20	6939.57	6940.69	1.12	130.08	117.8	137.8
OW-12	1/28/2021	ND	45.08	NA	6894.49	6939.57	6940.69	1.12	130.08	117.8	137.8
OW-12	9/28/2021	ND	45.78	NA	6893.79	6939.57	6940.69	1.12	130.08	117.8	137.8
OW-12	12/3/2022	ND	45.93	NA	6893.64	6939.57	6940.69	1.12	130.08	117.8	137.8
OW-14	3/7/2014	ND	22.02	NA	6902.53	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	6/3/2014	ND	22.05	NA	6902.50	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	9/15/2014	ND	22.30	NA	6902.25	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	11/10/2014	ND	22.15	NA	6902.40	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	3/9/2015	ND	21.85	NA	6902.70	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	6/1/2015	ND	21.78	NA	6902.77	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	8/10/2015	ND	21.86	NA	6902.69	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	10/27/2015	ND	21.59	NA	6902.96	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	3/4/2016	ND	21.10	NA	6903.45	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	6/6/2016	ND	21.08	NA	6903.47	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	8/31/2016	ND	21.40	NA	6903.15	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	11/15/2016	ND	21.18	NA	6903.37	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	2/27/2017	ND	20.73	NA	6903.82	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	5/30/2017	ND	21.08	NA	6903.47	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	9/6/2017	ND	20.46	NA	6904.09	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	12/11/2017	ND	20.10	NA	6904.45	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	2/27/2018	ND	19.70	NA	6904.85	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	4/26/2018	ND	19.65	NA	6904.90	6924.55	6926.65	2.10	44.65	35.0	45.0
OW-14	8/14/2018	ND	19.85	NA	6904.70	6924.55	6926.65	2.10	44.68	35.0	45.0
OW-14	11/6/2018	ND	19.72	NA	6904.83	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	2/5/2019	ND	19.54	NA	6905.01	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	5/1/2019	ND	19.35	NA	6905.20	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	12/7/2020	ND	22.30	NA	6902.25	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	6/30/2020	ND	20.65	NA	6903.90	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	2/27/2021	ND	21.22	NA	6903.33	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	6/2/2021	ND	21.55	NA	6903.00	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	9/23/2021	ND	21.63	NA	6902.92	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14	12/29/2021	ND	20.70	NA	6903.85	6924.55	6926.65	2.10	44.42	35.0	45.0
OW-14 OW-14	3/1/2022	ND	20.66	NA	6903.89	6924.55	6926.65	2.10	46.31	35.0	45.0
OW-14 OW-14	6/2/2022	ND	22.19	NA	6902.36	6924.55	6926.65	2.10	45.20	35.0	45.0
OW-14	9/5/2022	ND	22.65	NA	6901.90	6924.55	6926.65	2.10	45.20	35.0	45.0
.	0,0,2022				000.000	00200	0020.00	=		00.0	

2-2-202403_WellBackground_TBL-2-2.xlsx

.

Released to Imaging: 7/25/2024 3:37:45 PM

TABLE 2-2. SUMMARY OF EXISTING WELLS OW-63 PFAS INVESTIGATION WORK PLAN WESTERN REFINING SOUTHWEST LLC, GALLUP REFINERY, GALLUP, NEW MEXICO

Location	Date Measured	Depth to Product (ft-bgs)	Depth to Water (ft-bgs)	Product Thickness (ft)	Water Elevation (ft-msl)	Elevation (ft-msl)	Measuring Point Elevation (ft-msl)	Well Casing Height (ft)	Total Depth (ft-bgs)	Depth Top Screen (ft-bgs)	Depth Bottom Screen (ft-bgs)
OW-57	6/20/2017	ND	18.06	NA	6912.58	6930.64	6933.10	2.46	25.89	15.0	25.0
OW-57	9/19/2017	ND	17.69	NA	6912.95	6930.64	6933.10	2.46	25.89	15.0	25.0
OW-57	12/5/2017	ND	17.65	NA	6912.99	6930.64	6933.10	2.46	25.89	15.0	25.0
OW-57	2/19/2018	ND	17.42	NA	6913.22	6930.64	6933.10	2.46	25.89	15.0	25.0
OW-57	4/25/2018	ND	17.56	NA	6913.08	6930.64	6933.10	2.46	25.60	15.0	25.0
OW-57	8/15/2018	ND	17.70	NA	6912.94	6930.64	6933.10	2.46	25.61	15.0	25.0
OW-57	11/29/2018	ND	17.84	NA	6912.80	6930.64	6933.10	2.46	25.89	15.0	25.0
OW-57	2/19/2019	ND	17.83	NA	6912.81	6930.64	6933.10	2.46	25.64	15.0	25.0
OW-57	5/15/2019	ND	17.56	NA	6913.08	6930.64	6933.10	2.46	25.64	15.0	25.0
OW-57	8/20/2019	ND	17.32	NA	6913.32	6930.64	6933.10	2.46	25.61	15.0	25.0
OW-57	11/4/2019	ND	17.51	NA	6913.13	6930.64	6933.10	2.46	25.89	15.0	25.0
OW-57	3/4/2020	ND	17.51	NA	6913.13	6930.64	6933.10	2.46	25.64	15.0	25.0
OW-57	6/30/2020	ND	17.76	NA	6912.88	6930.64	6933.10	2.46	25.64	15.0	25.0
OW-57	9/14/2020	ND	18.04	NA	6912.60	6930.64	6933.10	2.46	25.63	15.0	25.0
OW-57	11/9/2020	ND	18.07	NA	6912.57	6930.64	6933.10	2.46	25.63	15.0	25.0
OW-57	12/7/2020	ND	18.18	NA	6912.46	6930.64	6933.10	2.46	25.93	15.0	25.0
OW-57	1/28/2021	ND	18.27	NA	6912.37	6930.64	6933.10	2.46	25.93	15.0	25.0
OW-57	2/27/2021	ND	18.27	NA	6912.37	6930.64	6933.10	2.46	25.63	15.0	25.0
OW-57	3/31/2021	ND	18.52	NA	6912.12	6930.64	6933.10	2.46	25.33	15.0	25.0
OW-57	4/26/2021	ND	18.61	NA	6912.03	6930.64	6933.10	2.46	25.03	15.0	25.0
OW-57	5/20/2021	ND	17.42	NA	6913.22	6930.64	6933.10	2.46	24.73	15.0	25.0
OW-57	6/2/2021	ND	18.57	NA	6912.07	6930.64	6933.10	2.46	24.73	15.0	25.0
OW-57	9/9/2021	ND	19.24	NA	6911.40	6930.64	6933.10	2.46	24.73	15.0	25.0
OW-57	12/13/2021	ND	19.29	NA	6911.35	6930.64	6933.10	2.46	24.73	15.0	25.0
OW-57	3/1/2022	ND	19.34	NA	6911.30	6930.64	6933.10	2.46	25.62	15.0	25.0
OW-57	6/2/2022	ND	19.89	NA	6910.75	6930.64	6933.10	2.46	25.92	15.0	25.0
OW-57	9/2/2022	ND	20.19	NA	6910.45	6930.64	6933.10	2.46	25.92	15.0	25.0
OW-63	3/21/2018	ND	17.47	NA	6914.87	6932.34	6935.06	2.72	29.46	9.0	29.0
OW-63	4/24/2018	ND	17.61	NA	6914.73	6932.34	6935.06	2.72	29.46	9.0	29.0
OW-63	8/16/2018	ND	17.88	NA	6914.46	6932.34	6935.06	2.72	29.48	9.0	29.0
OW-63	11/29/2018	ND	18.23	NA	6914.11	6932.34	6935.06	2.72	29.28	9.0	29.0
OW-63	2/19/2019	ND	17.74	NA	6914.32	6932.34	6935.06	3.00	29.00	9.0	29.0
OW-63	5/15/2019	ND	17.35	NA	6914.71	6932.34	6935.06	3.00	29.00	9.0	29.0
OW-63	8/19/2019	ND	17.12	NA	6914.94	6932.34	6935.06	3.00	29.20	9.0	29.0
OW-63	11/18/2019	ND	17.30	NA	6914.76	6932.34	6935.06	3.00	29.00	9.0	29.0
OW-63	3/4/2020	ND	17.41	NA	6914.65	6932.34	6935.06	3.00	29.00	9.0	29.0
OW-63	6/29/2020	ND	17.46	NA	6914.60	6932.34	6935.06	3.00	29.00	9.0	29.0
OW-63	9/14/2020	ND	17.73	NA	6914.33	6932.34	6935.06	3.00	29.05	9.0	29.0
OW-63	11/9/2020	ND	17.85	NA	6914.21	6932.34	6935.06	3.00	29.05	9.0	29.0
OW-63	12/8/2020	ND	17.97	NA	6914.09	6932.34	6935.06	3.00	29.22	9.0	29.0
OW-63	1/28/2021	ND	18.15	NA	6913.91	6932.34	6935.06	3.00	29.22	9.0	29.0
OW-63	2/27/2021	ND	18.13	NA	6913.93	6932.34	6935.06	3.00	29.22	9.0	29.0

2-2-202403_WellBackground_TBL-2-2.xlsx

Released to Imaging: 7/25/2024 3:37:45 PM

TABLE 2-2. SUMMARY OF EXISTING WELLS **OW-63 PFAS INVESTIGATION WORK PLAN** WESTERN REFINING SOUTHWEST LLC, GALLUP REFINERY, GALLUP, NEW MEXICO

Location	Date Measured	Depth to Product (ft-bgs)	Depth to Water (ft-bgs)	Product Thickness (ft)	Water Elevation (ft-msl)	Ground Surface Elevation (ft-msl)	Measuring Point Elevation (ft-msl)	Well Casing Height (ft)	Total Depth (ft-bgs)	Depth Top Screen (ft-bgs)	Depth Bottom Screen (ft-bgs)
OW-63	3/31/2021	ND	18.28	NA	6913.78	6932.34	6935.06	3.00	29.22	9.0	29.0
OW-63	4/26/2021	ND	18.40	NA	6913.66	6932.34	6935.06	3.00	29.22	9.0	29.0
OW-63	5/20/2021	ND	18.52	NA	6913.54	6932.34	6935.06	3.00	29.22	9.0	29.0
OW-63	6/2/2021	ND	18.37	NA	6913.69	6932.34	6935.06	3.00	29.22	9.0	29.0
OW-63	9/28/2021	ND	18.85	NA	6913.21	6932.34	6935.06	3.00	29.22	9.0	29.0
OW-63	12/16/2021	ND	18.93	NA	6913.13	6932.34	6935.06	3.00	29.22	9.0	29.0
OW-63	3/1/2022	ND	18.95	NA	6913.11	6932.34	6935.06	3.00	29.22	9.0	29.0
OW-63	6/1/2022	ND	19.51	NA	6912.55	6932.34	6935.06	3.00	29.22	9.0	29.0
OW-63	9/2/2022	ND	19.25	NA	6912.81	6932.34	6935.06	3.00	29.22	9.0	29.0
OW-70	12/16/2021	ND	28.71	NA	6914.36	6943.07	6945.95	2.88	44.82	25.0	44.7
OW-70	9/8/2021	ND	28.53	NA	6917.42	6943.07	6945.95	2.88	44.82	25.0	44.7
OW-70	3/2/2022	ND	28.76	NA	6914.31	6943.07	6945.95	2.88	44.83	25.0	44.7
OW-70	6/1/2022	ND	29.24	NA	6913.83	6943.07	6945.95	2.88	44.84	25.0	44.7
OW-70	9/7/2022	ND	29.41	NA	6913.66	6943.07	6945.95	2.88	44.84	25.0	44.7

Notes:

Released to Imaging: 7/25/2024 3:37:45 PM

ft feet ft msl feet above mean sea level feet below ground surface ft-bgs

NA not applicable not detected

ND

PFAS per- and polyfluoroalkyl substances

TABLE 2-3. PROPOSED GROUNDWATER AND SOIL SAMPLE CONSTITUENT LIST OW-63 PFAS INVESTIGATION WORK PLAN WESTERN REFINING SOUTHWEST LLC, GALLUP REFINERY, GALLUP, NEW MEXICO

Chemical Name	Abbreviation	Fluorinated Alkane Carbon Chain Length	CAS No.	2022 NMED Residential Soil, Noncancer (mg/kg)	2022 NMED Industrial/Occupational Soil, Noncancer (mg/kg)	2022 NMED Construction Worker Soil, Noncancer (mg/kg)	2022 NMED Cw, DAF 20 (mg/kg)
Perfluoroalkylcarboxylic acids (PFCAs)	•						
Perfluorobutanoic acid	PFBA	C3*	375-22-4				
Perfluoropentanoic acid	PFPeA	C4*	2706-90-3				
Perfluorohexanoic acid	PFHxA	C5*	307-24-4				
Perfluoroheptanoic acid	PFHpA	C6*	375-85-9				
Perfluorooctanoic acid	PFOA	C7*	335-67-1	0.185	3.74	0.807	0.0183
Perfluorononanoic acid	PFNA	C8*	375-95-1	0.185	3.74	0.807	0.00502
Perfluorodecanoic acid	PFDA	C9*	335-76-2				
Perfluoroundecanoic acid	PFUnA	C10*	2058-94-8				
Perfluorododecanoic acid	PFDoA	C11*	307-55-1				
Perfluorotridecanoic acid	PFTriA	C12*	72629-94-8				
Perfluorotetradecanoic acid	PFTeA	C13*	376-06-7				
Perfluorinated sulfonic acids (PFSAs)							
Perfluorobutanesulfonic acid	PFBS	C4	375-73-5	18.5	374	80.7	0.0209
Perfluoropentanesulfonic acid	PFPeS	C5	2706-91-4				
Perfluorohexanesulfonic acid	PFHxS	C6	355-46-4	1.23	24.9	5.38	0.00139
Perfluoroheptanesulfonic acid	PFHpS	C7	375-92-8				
Perfluorooctanesulfonic acid	PFOS	C8	1763-23-1	0.185	3.74	0.807	0.000209
Perfluorononanesulfonic acid	PFNS	C9	68259-12-1				
Perfluorodecanesulfonic acid	PFDS	C10	335-77-3				
Perfluoroocante Sulfonamide and Derivatives (PFOSA, FOS	SEs, FOSAs, and	FOSAAs)					
Perfluoroictabesylfonamide	PFOSA	C8	754-91-6				
2-(N-Methylperfluorooctanesulfonamido) acetic acid	NMeFOSAA	C8 Precursor	2355-31-9				
2-(N-Ethylperfluorooctanesulfonamido) acetic acid	N-EtFOSAA	C8 Precursor	2991-50-6				
Fluorotelomer sulfonates (FTS)							
4:2 Fluorotelomer sulfonic acid	FtS 4:2	C4 Precursor	757124-72-4				
6:2 Fluorotelomer sulfonic acid	FtS 6:2	C6 Precursor	27619-97-2				
8:2 Fluorotelomer sulfonic acid	FtS 8:2	C8 Precursor	39108-34-4				

Notes:

Released to Imaging: 7/25/2024 3:37:45 PM

PFAS - per- and polyfluoroalkyl substances

CAS No. - Chemical Abstracts Service Number

C - carbon

DAF - Dilution Attenuation Factor mg/kg - milligrams per kilogram

NMED - New Mexico Environment Department

Reporting limits will be dependent upon the lab selected for PFAS analysis; they will be evaluated against New Mexico PFAS screening levels once a lab has been selected.

Screening levels from NMED's 2022 Risk Assessment Guidance have been included. The most current screening levels will be included in the investigation report.

* - The fluorinated carbon chain length is shown, although the total carbon chain length for PFCAs is one greater due to presence of a non-fluorinated carboxylic acid (COOH) functional group.

Page 86 of 166



Western Refining Southwest LLC Gallup Refinery OW-63 PFAS Investigation Work Plan

Appendix A – OW-63 PFAS Sampling Results

Location	Sample Date	4:2 Fluorotelomer sulfonic acid (4:2 FTS) (ng/L)	6:2 Fluorotelomer sulfonic acid (6:2 FTS) (ng/L)	8:2 Fluorotelomer sulfonic acid (8:2 FTS) (ng/L)	N-ethyl perf sulf acid (NEtFOSAA) (ng/L)	2-(N-methyl- perfluorooctane sulfonamido) acetic acid (NMeFOSAA) (ng/L)	Perfluorobutanesulfonic acid (PFBS) (ng/L)	Perfluorobutanoic acid (PFBA) (ng/L)	Perfluorodecanesulfonic acid (PFDS) (ng/L)	Perfluorodecanoic acid (PFDA) (ng/L)	Perfluorododecanoic acid (PFDoA) (ng/L)
OW-63	6/15/2021	ND(1.95)	400	46.1	ND(2.56)	ND(1.95)	38.4	ND(1.95)	ND(2.69)	12.8	ND(1.95)
OW-63	9/29/2021	ND(2.04)	494	44.6	ND(2.68)	ND(2.04)	39.2	91.2	ND(2.81)	12.4	ND(2.04)
OW-63	12/17/2021	ND(1.96)	638	51.1	ND(1.96)	ND(1.96)	34.2	153	ND(1.96)	11.5	ND(1.96)
OW-63	3/10/2022	ND(2.09)	679	70.8	ND(2.09)	ND(2.09)	41.9	ND(2.09) R	ND(2.09)	11.2	ND(2.09)
OW-63	6/8/2022	ND(2.08)	712	71.7	ND(2.08)	ND(2.08)	40.2	ND(2.08)	ND(2.08)	13.2	ND(2.08)
OW-63	9/20/2022	ND(2.01) UJ	556 J	71.4 J	ND(2.01) UJ	ND(2.01) UJ	35.1 J	121 J	ND(2.01) UJ	12.3 J	ND(2.01) UJ
OW-63	12/7/2022	ND(2.03)	562	70.1	ND(2.03)	ND(2.03)	34.9	140 J+	ND(2.03)	12.1	ND(2.03)
NME	ED Cleanup Level	NA	NA	NA	NA	NA	6016.48	NA	NA	NA	NA

Notes:

NMED Cleanup Level - New Mexico Environment Department, Risk Assessment Guidance, Table A-1, Tap Water, November 2022

Bolded detections exceed the screening level

J = Estimated concentration

J+ = Estimated concentration, possibly biased high

NA = Not applicable

ND(x) = Not detected, where x = the reporting limit

ng/L = Nanograms per liter

PFAS = Per- and Polyfluoroalkyl Substances

R = Rejected, Data not usable

UJ = Estimated reporting limit

Received by OCD: 4/16/2024 4:15:20 PM

1 of 3

Page 88 of 166

.

APPENDIX A. OW-63 PFAS SAMPLING RESULTS WESTERN REFINING SOUTHWEST LLC, D/B/A MARATHON GALLUP REFINERY GALLUP, NEW MEXICO

					Perfluorohexanoic				
Location	Sample Date	Perfluoroheptanesulfonic acid (PFHpS) (ng/L)	Perfluoroheptanoic acid (PFHpA) (ng/L)	Perfluorohexanesulfonic acid (PFHxS) (ng/L)	acid (PFHxA) (ng/L)		Perfluorononanoic acid (PFNA) (ng/L)	Perfluorooctanesulfonamide (PFOSA) (ng/L)	Perfluorooctanesulfonic acid (PFOS) (ng/L)
OW-63	6/15/2021	12.4	137	325	355	ND(1.95)	522	ND(1.95)	547
OW-63	9/29/2021	11.9	131	278	313	ND(2.04)	494	ND(2.04)	516
OW-63	12/17/2021	9.26	114	237	347	ND(1.96)	508	ND(1.96)	454
OW-63	3/10/2022	9.19	128	263	347	ND(2.09)	523	ND(2.09)	351
OW-63	6/8/2022	13.2	128	232	442	ND(2.08)	604	ND(2.08)	360
OW-63	9/20/2022	8.81 J	134 J	255 J	352 J	ND(2.01) UJ	482 J	ND(2.01) UJ	316 J
OW-63	12/7/2022	7.25	124	258	344	ND(2.03)	479	ND(2.03) UJ	331
NME	D Cleanup Level	NA	NA	401.10	NA	NA	60.16	NA	60.16

Notes:

Released to Imaging: 7/25/2024 3:37:45 PM

NMED Cleanup Level - New Mexico Environment Department, Risk Assessment Guidance, Table A-1, Tap Water, November 2022

Bolded detections exceed the screening level

J = Estimated concentration

J+ = Estimated concentration, possibly biased high

NA = Not applicable

ND(x) = Not detected, where x = the reporting limit

ng/L = Nanograms per liter

PFAS = Per- and Polyfluoroalkyl Substances

R = Rejected, Data not usable

UJ = Estimated reporting limit

APPENDIX A. OW-63 PFAS SAMPLING RESULTS WESTERN REFINING SOUTHWEST LLC, D/B/A MARATHON GALLUP REFINERY GALLUP, NEW MEXICO

Location	Sample Date	Perfluorooctanoic acid (PFOA) (ng/L)	Perfluoropentanesulfonic acid (PFPeS) (ng/L)	Perfluoropentanoic acid (PFPA) (ng/L)	Perfluorotetradecanoic acid (PFTeDA) (ng/L)	Perfluorotridecanoic acid (PFTriA) (ng/L)	Perfluoroundecanoic acid (PFUnA) (ng/L)
OW-63	6/15/2021	127	44.5	352	ND(1.95)	ND(1.95)	82.3
OW-63	9/29/2021	123	37.9	417	ND(2.04)	ND(2.04)	88.2
OW-63	12/17/2021	106	37.4	464	ND(1.96)	ND(1.96)	86.6
OW-63	3/10/2022	124	41.7	486	ND(2.09)	ND(2.09)	ND(2.09)
OW-63	6/8/2022	110	53.3	445	ND(2.08)	ND(2.08)	103
OW-63	9/20/2022	108 J	42.5 J	470 J	ND(2.01) UJ	ND(2.01) UJ	71.7 J
OW-63	12/7/2022	106	34.4	505	ND(2.03)	ND(2.03)	76.8
NMED Cleanup Leve		el 60.16	NA	NA	NA	NA	NA

Notes:

NMED Cleanup Level - New Mexico Environment Department, Risk Assessment Guidance, Table A-1, Tap Water, November 2022

Bolded detections exceed the screening level

J = Estimated concentration

J+ = Estimated concentration, possibly biased high

NA = Not applicable

ND(x) = Not detected, where x = the reporting limit

ng/L = Nanograms per liter

PFAS = Per- and Polyfluoroalkyl Substances

R = Rejected, Data not usable

UJ = Estimated reporting limit

.

3 of 3

Received by OCD: 4/16/2024 4:15:20 PM



Western Refining Southwest LLC Gallup Refinery OW-63 PFAS Investigation Work Plan

Appendix B - Trihydro's PFAS Site Characterization Standard Operation Procedure



memorandum

То:	Trihydro Employees
From:	Mitch Olson
Date:	September 2, 2022
Re:	PFAS Sampling Standard Operating Procedure

1.0 INTRODUCTION

This standard operating procedure (SOP) establishes protocols for Trihydro employees and subcontractors to be followed when collecting samples for per- and polyfluoroalkyl substances (PFAS). This SOP includes general PFAS sampling procedures as well as procedures for specific activities including sampling of drinking water, groundwater, surface water/sediment, soils, and other media.

This PFAS SOP is divided into the following Sections:

- 1.0 Introduction
- 2.0 PFAS Sampling Training Requirements
- 3.0 General PFAS Sampling Procedures
- 4.0 Drinking Water and Supply Well Sampling
- 5.0 Groundwater Sampling
- 6.0 Surface Water and Sediment Sampling
- 7.0 Surface and Subsurface Soil Sampling
- 8.0 Other Sampling Matrices
- 9.0 PFAS Laboratory Requirements
- 10.0 References

Although PFAS sampling procedures are generally similar to conventional sampling, several aspects of sampling and analysis for PFAS are unique, and following these PFAS-specific procedures is critical. PFAS-specific procedures are necessary due to their high tendency for sample cross-contamination, which is related to the following characteristics:

- Extremely low environmental concentrations of interest
- Large numbers of individual analytes that may be present in environmental samples
- Potential presence in many standard sampling materials, especially in Teflon[®] or polytetrafluoroethylene (PTFE)
- Presence in everyday materials including food packaging and clothing
- Greater scrutiny of results than for other contaminants



The objective of this SOP is to establish general PFAS sampling procedures to guide PFAS sampling events across the company, provide defensible PFAS data, and remain consistent with current PFAS sampling guidance and best practices.

Due to anticipated/ongoing changes in procedures and the state of the science for PFAS, this SOP will be reviewed and/or updated annually, at a minimum, during the first quarter of each calendar year. Project teams need to use the most recent version of this document before planning and implementation of field work.

1.1 PFAS BACKGROUND

Since the 1950s, PFAS have been incorporated into many consumer and industrial products. One of the many historical uses is in firefighting foams ("Aqueous Film Forming Foams," or AFFF). AFFF products may be used for fire suppression at facilities where Class B fires (i.e., those involving flammable liquids and gases) may be a concern, including airports, firefighting training areas, and other facilities where flammable hydrocarbons are present. PFAS have also been used for widespread industries including non-stick material (e.g., Teflon®) manufacturing, metal plating, paper/fabric production, plastics, semiconductors, aerospace industries, and in processes such as mist/dust suppression. Environmental releases of PFAS compounds have resulted from their historical uses in AFFF and industrial processes.

In total, the chemical class of PFAS includes thousands of individual compounds. The most well-known and widely regulated of these compounds include perfluorooctanoic acid (PFOA) and perfluoroalkyl sulfonate (PFOS). The United States Environmental Protection Agency (EPA) released final Health Advisory (HA) levels for these compounds of 70 parts per trillion (ppt) (i.e., 0.070 parts per billion); in June 2022, the EPA released updated interim HA levels of 0.004 ppt and 0.020 ppt for PFOA and PFOS, respectively. The EPA also released final HA values for two additional PFAS compounds, perfluorobutane sulfonate (PFBS) and hexafluoropropylene oxide (HFPO) dimer acid (otherwise known as GenX) of 10 and 2,000 ppt, respectively. Furthermore, several states have established their own standard values for PFAS in drinking water, surface water, and soils (ITRC 2022). Many states have adopted values lower than the EPA HA levels.

PFAS also exhibit unique chemical and physical properties, with important implications for sample collection. The molecular structure includes a nonpolar/fluorinated tail and a non-fluorinated head. The polar/nonpolar structure makes PFAS function as surfactants (e.g., substances that decrease a liquid's surface tension), and are prone to accumulate at air/water interfaces (especially where foam may be formed). Because of this tendency to accumulate at interfaces, surface/stormwater sampling should avoid interfaces, if possible, to avoid high-biased sample data. In terms of sampling, PFAS are considered to be "sticky" in that they may temporarily sorb to sampling materials, which increases the risk of cross contamination if procedures described herein are not strictly observed.



1.2 PFAS SAMPLING GUIDANCE DOCUMENTS

The SOP presented herein has been developed in consideration of select state-specific guidance documents as well as the Interstate Regulatory Guidance Council (ITRC). Additional guidance may need to be referenced for site-specific circumstances, for example, several states have published independent guidance documents (in addition to the California and Michigan documents noted herein). PFAS sampling and analytical guidance documents include the following:

- <u>Per- and Polyfluoroalkyl Substances (PFAS) Sampling Guidelines for Non-Drinking Water published</u> by the California State Water Quality Control Board (The Water Boards) Division of Water Quality in September 2020 (The Water Boards 2020).
- <u>General PFAS Sampling Guidance</u> published by the Michigan Department of Environmental Quality (MDEQ) in October 2018 (MDEQ 2018).
- <u>ITRC's guidance document</u>, *Technical Resources for Addressing Environmental Releases of Per- and Polyfluorinated Compounds (PFAS)*, Chapter 11, Sampling and Analytical Methods, provides detailed information on sampling protocols (ITRC 2022).

2.0 PFAS SAMPLING TRAINING REQUIREMENTS

Due to the need for specialized procedures used for PFAS sampling, only personnel who have completed Trihydro's training program should collect environmental samples for PFAS. Trihydro's PFAS sampling training program includes the following elements:

- Initial office-based training conducted by one or more members of the Trihydro PFAS technical team, including PFAS background, overview of this SOP, and discussion of unique aspects of PFAS sampling with a detailed discussion of the material compatibility table. Training should include discussion of procedures commensurate with sampling to be conducted. Office-based training will cover items in the checklist (Attachment A) and is anticipated to require 1 hour for drinking/wastewater sampling conducted above ground (e.g., from spigots) and 1-2 hours for environmental sampling including soils, sediment, surface water, groundwater. The office-based training is considered sufficient for personnel collecting tapwater/spigot sampling; personnel conducting environmental sampling (e.g., groundwater, surface water, soils, and sediment) must complete on-site training.
- On-site training will be led by an experienced PFAS sampler. Experienced PFAS samplers will use the Field Training Checklist included as Attachment B of this SOP to ensure that the applicable aspects of PFAS field techniques are discussed during the on-site training event.
- Annual refreshers will consist of office-based training/discussion to share information learned throughout the company during PFAS sampling events, updates in terms of standard methods, and to provide feedback on lessons learned.



3.0 General PFAS Sampling Procedures

This section provides general information on PFAS sampling procedures, to be used for all PFAS sampling activities. In general, collection of PFAS samples follows similar procedures to those employed for conventional sampling; however, due to the unique properties of PFAS discussed in Section 1, there are several key aspects of PFAS sampling that warrant additional attention. This SOP focuses on areas where PFAS sampling requires different considerations than conventional sampling procedures. PFAS may be present in a wide variety of commercial products including common household items (e.g., food wrappers, Gore-Tex[®] or other waterproof fabrics, stain-resistant fabrics, cosmetics, sunscreens, and moisturizing lotions). Table 1 presents a list of sampling materials that are prohibited or acceptable, following The California Water Boards 2020, MDEQ 2018, and ITRC 2022 guidance. It is very important that PFAS-compatible materials are used and that sampling procedures follow protocols to minimize risk of cross contamination. This section provides guidance on how to manage sampling to minimize risks of PFAS contamination. PFAS sampling procedures for specific media types are provided in subsequent sections.

While planning for PFAS sampling, the following guidelines should be kept in mind:

- Plan ahead to ensure materials and procedures can be properly vetted for PFAS compatibility
- For PFAS field sampling, include extra time, such that the field crew does not have to rush
- Simplify procedures and minimize clutter to reduce cross-contamination risks

3.1 CLOTHING AND PERSONAL CARE PRODUCTS

The sample collection team should be aware of clothing compatibility (per Table 1) with PFAS sampling. PFAS are present in waterproof and stainproof fabrics, and may be present in new clothing, regardless of whether clothing is considered "waterproof". Clothing worn during PFAS sampling should meet the following criteria:

- All clothing should be well-laundered, i.e., washed at least six times after purchase.
- Before sampling, clothing should be laundered without fabric softener or dryer sheets.
- For clothing and jackets worn during PFAS sampling, cotton or synthetic fabrics are acceptable, if the fabrics are not treated to be water/stain resistant (and all clothing regardless of material must be well laundered).
- Clothing containing Gore-Tex[®] (or similar waterproofing) should not be present at the field site; if traveling, such clothing should not be packed next to clothing that will be worn for sampling.
- Waterproof clothing made with polyurethane, PVC, wax-coated fabrics, rubber, or neoprene (e.g., *Helly Hansen Storm Waterproof Rain Jacket*, with a shell made of PVC) is acceptable.



• Do not use unnecessary personal care products on the day of sampling (e.g., nail polish, cologne/perfume, lotions); wash hands with soap and water after applying personal care products on the day of sampling.

3.2 PFAS SAMPLING HEALTH AND SAFETY CONSIDERATIONS

In some circumstances, personal protective equipment (PPE) requirements may create conflicts with the PFAS sampling compatible materials shown in Table 1. Such conflicts should be identified during the planning/work-plan development process so they can be managed. **Do not sacrifice PPE requirements for PFAS sample collection.** Through planning, a solution can generally be found. For example, waterproof steel-toed workboots may be covered by overshoes made of polyvinyl chloride (PVC) or similar PFAS-compatible materials. Sunblock, insect repellant, and/or related materials should be applied ahead of time and hands washed with soap and water after these are applied.

Potential health-and-safety/PFAS conflicts and resolutions should be documented in field notes. The sampler should be conscientious about potential pathways between these products and the sample, and look for ways to eliminate these pathways.

3.3 SAMPLING EQUIPMENT AND MATERIALS

PFAS are potentially present in many common sampling materials; Table 1 provides a summary of materials that are compatible/incompatible with PFAS sampling. Many common sampling materials are not compatible with PFAS, thus it is important that the sampling team is familiar with this table.

Materials that are useful to have on-site for PFAS sampling include the following:

- Polyethylene (PE) sheeting (and scissors to cut the sheeting)
- Packing tape to attach sheeting to sample preparation surfaces (optional)
- Sample staging table (optional)
- Nitrile gloves excess quantity for frequent changing of gloves
- Ziploc bags excess quantity for sample containers, double-bagged ice, and separating/containing sampling equipment
- Untreated paper towels excess quantity for general use
- Waste containers (e.g., contractor bags) to ensure that waste materials may be removed from the sample processing area immediately after being generated, thus avoiding unnecessary clutter
- Loose leaf paper, pre-printed for recording sample log information
- PFAS-compatible pens, such as a Uni-ball Power Tank RT Retractable Ballpoint Pen



If decontamination is required, purchase PFAS-free water from the laboratory along with the sample container order. PFAS-free water may be expected to cost approximately \$20 per liter. If a large volume (e.g., multiple gallons) of decontamination water is required, a local water source may be used only if tested and verified to be 'PFAS-free' ahead of time.

3.4 SAMPLING CONTAINERS

Sampling containers provided by the laboratory for PFAS analysis consist of polypropylene or highdensity polyethylene (HDPE). Glass containers are never suitable for PFAS analysis of water samples, as PFAS can adsorb onto glass; glass containers are not ideal for soil sampling, but may be used if nothing else is available. Teflon-lined lids are not acceptable for PFAS sampling. Before sampling, confirm PFAS compatibility, including sample-container composition with the selected analytical laboratory. For drinking water samples, USEPA method 537.1 requires 250 milliliters (mL) per sample container and USEPA Method 533 requires 100-250 mL per sample container; laboratories generally require two containers per sample. Volume requirements may vary per laboratory requirements; confirm with laboratory before sampling. Requirements for preservatives (Trizma[®] buffer or ammonium acetate) are discussed in Section 8.3.

For non-drinking water matrices, the absence of USEPA-promulgated analytical methods allows for flexibility in the sample quantity and preservation; required quantities, bottles, and preservatives should be confirmed with the analytical laboratory prior to field activities.

3.5 SAMPLING AREA PREPARATION

To minimize the potential for cross contamination, designate separate sampling and preparation spaces within the work area. For PFAS sampling of all media types, the following area preparation steps can facilitate successful PFAS sampling:

- Remove unnecessary materials from the sampling area. This includes materials that are part of the sampling event but are not needed for sample collection (e.g., field notes).
- Under certain circumstances (e.g., residential water sampling), a Ziploc bag may be used to transport/store sampling containers and sampling materials. These materials must be disposed of after a single use and are <u>not</u> to be used at multiple locations.
- Consider using disposable PE sheeting to setup a workspace for sampling equipment. For small, localized sample collection (e.g., from a spigot) use PE sheeting or untreated paper towels to setup a workspace.
- For certain types of sampling, a portable/collapsible table may be used, with PE sheeting used to cover the table. Packaging tape is acceptable to secure PE sheeting, as long as the tape is applied beneath the table surface and does not contact sample containers during processing. The top of a



cooler may also be used for equipment storage, if covered by PE/untreated paper towels or thoroughly decontaminated.

- Have an excess quantity of nitrile gloves accessible; gloves are to be changed frequently, including as a last step before sample collection. Gloves should be kept in the box (or in a clean Ziploc bag) until use and should not be carried in a pocket, or in a similar uncontrolled manner. Avoid handling of the nitrile glove box after donning clean nitrile gloves.
- Make sure personnel that are not equipped for PFAS sampling remain outside of the immediate sampling area (at least 6 feet away).

Preparing sample containers and coolers before the event:

- Always wear clean nitrile gloves while handling sample containers and PFAS-free water containers, even when organizing before the sampling event.
- Preparing bottle sets before the sampling event is helpful to minimize handling of containers required in the field. Preparation might include grouping of bottle sets in Ziploc bags. Sample container labels may be filled out (with all information except sample time) and applied ahead of time. Ziploc bags can be labeled using an Ultra-Fine point sharpie or Uni-ball Power Tank RT Retractable Ballpoint Pen.
- Ensure that sample containers are controlled through the entire preparation process. They may be in a cooler, placed in Ziploc bags, or placed on PE sheeting. Sample containers should be stored in a liner-bag or Ziploc bag within the cooler. Do not place sample containers on 'uncontrolled' surfaces, such as the exposed lid of a cooler, the tailgate of a truck, or a carpeted floor, unless the surface is decontaminated or covered with PE sheeting or clean, untreated paper towels.
- Prepare separate coolers for clean/empty sample containers and filled containers such that clean/empty and filled containers are not mixed in a single cooler.

3.6 SAMPLE COLLECTION AND HANDLING

PFAS are sticky, in that they tend to adhere to solid surfaces, and therefore may be transferred from source to sample during the handling process. The following presents a list of sampling dos and don'ts that mitigate this cross-contamination risk.



Do	Don't
Change gloves frequently, including immediately	Touch anything besides sample containers with final
before sampling.	pair of nitrile gloves.
Keep sample containers controlled through the	Put sample containers or sampling equipment on the
entire sampling process, and keep containers	ground or in contact with any surface that cannot be
closed/sealed until filling with a sample.	shown to be free of PFAS.
Have at least two coolers, one for unused sampling	Put PFAS samples in a cooler with unused sampling
containers and one for the PFAS samples.	containers.
Practice good housekeeping by keeping sample	Bring items into the sample collection area that are
collection area clean and free of used paper towels,	not necessary to the process of sample collection
gloves, sampled media (soil and water).	(notebooks, work plans, food/drink containers, etc.).
	Water bottles for hydration are allowable at the
	sampling site, but should be kept in the car and out of
	the sampling/staging area.
When sampling liquids, fill the container to the	Field filter the PFAS sample. If filtration is required,
shoulder. Some headspace is preferred.	notify the laboratory.
Collect PFAS samples first, then other samples.	Intermingle PFAS and non-PFAS sample containers.
This minimizes contact of PFAS samples with the	
handling of other sampling containers.	
Remove excess sample media (soil, sediment or	Rinse reusable sampling equipment with regular tap
water) to the extent practicable from the exterior of	water. After a thorough decontamination, rinse with
sample containers to minimize cross contamination in	PFAS free water.
cooler and at laboratory.	

3.7 SAMPLE SHIPMENT

PFAS samples also have unique requirements for packaging and shipment. Additional considerations for PFAS sample shipment include use of additional Ziploc bags to mitigate cross-contamination potential during sample handling or during shipment. All sample sets should be packaged in separate Ziploc bags; the two (or more) containers filled for each sample set can be placed in a single sealed bag. If high PFAS concentrations are expected, samples containers may be double-bagged to minimize cross-contamination risk in the cooler (under such circumstances a trip blank should be included, as described in Section 8.4). PFAS samples are shipped to the analytical laboratory in a cooler, via expedited delivery or overnight shipping if possible, following similar protocols used for conventional sampling. Finally, as with conventional sampling, the samples must be received by the laboratory at 4±2 degrees Celsius (°C) or as required by the sample method specified in the work plan. For cooling of samples during shipment, use water-based ice instead of gel ice (e.g., Blue Ice). Under circumstances where gel ice may be needed, make sure the gel ice is double bagged in Ziploc bags and/or properly decontaminated, with an equipment blank collected. Even water-based ice is a potential PFAS source within the coolers, therefore the ice



must be double-bagged in Ziploc (or similar) bags. Clean nitrile gloves should be worn while handling ice, and should be changed prior to handling sample containers.

Additional considerations for PFAS sampling in specific matrices (drinking water, groundwater, surface water/sediment, and other media types) are provided in the following sections:

- Section 4 Drinking Water and Supply Well Sampling
- Section 5 Groundwater Sampling
- Section 6 Surface Water and Sediment Sampling
- Section 7 Surface and Subsurface Soil Sampling
- Section 8 Other Sampling Matrices

3.8 DECONTAMINATION

- To reduce/minimize investigation-derived waste (IDW) a spray-bottle method of decontamination may be used where adequate. Zepp[®] brand spray bottles are recommended.
- Decontamination should use a phosphate-based detergent, such as Alconox[®] or Liquinox[®] Note that Simple Green[®] has not been confirmed to be PFAS free, and is therefore not approved for PFAS sampling decontamination at this time.
- PFAS-free water (lab supplied is preferable) should be used for a final rinse. If a large volume of decontamination water is needed, a local water source may be used, but the water source should be tested and verified as being PFAS-free. Best practice is to use lab-supplied PFAS-free water for a final rinse.
- Equipment blanks should be collected from non-dedicated equipment that contacts the sampled media to validate decontamination procedures.
- Decontaminated equipment may be stored in fresh Ziploc bags, in decontaminated equipment cases, on HDPE sheeting, or similar, until immediately prior to sampling, to minimize risk of contamination.
- Additional decontamination considerations for sampling of different media types are provided in Sections 4 through 7.

3.9 INVESTIGATION DERIVED WASTE

IDW may include purge water, soils, disposable tubing from groundwater sampling, purge water from spigot/sample port sampling, spent PPE, or other solid waste generated during the collection of PFAS samples. Although PFAS compounds are new analytes for many facilities where sampling is conducted, the chemistry of purged groundwater will be similar to that of water generated during regular sampling events. Therefore, depending on local, state, or site-specific requirements, all IDW water may be handled



following normal site-sampling procedures. Other solid waste will be discarded in an appropriate on-site container, following standard site procedures for solid waste. Potential PFAS-impacted IDW will need to be profiled and managed in accordance with local/state or client requirements.

3.10 FIELD DOCUMENTATION

The information documented during the field activities should include, at a minimum:

- Photo-documentation (if allowable photo documentation can be helpful for documenting unconventional site conditions for potential PFAS impacts)
- Descriptions of sample matrices
- Descriptions of sampling locations
- Sample collection dates and times
- Sample container sizes, amounts, types, and preservatives
- Sampling methodology
- Deviations from this SOP or site-specific work plans

An example field documentation form used for PFAS sampling is provided in Attachment C.

3.11 SITE DATA MANAGEMENT

Due to the prolific nature of PFAS, its status as an emerging contaminant, and the high degree of uncertainty surrounding environmental liability associated with PFAS, many PFAS sites are the subject of potential or ongoing litigation. As such, additional care should be used when managing site data. This may include various best practices that should be discussed with the client prior to initiating sampling activities, including:

- Determining what documentation to collect for sample procedures to verify that samples are representative of site conditions.
- Determining if existing judicial orders are present which may direct sample activities, notifications, or document retention and production requirements.
- Being thorough, yet careful to only record data observations (as opposed to including qualitative speculation, judgement, or opinion) when producing field notes, sample logs, sample figures, and other documentation.
- Determining whom may receive/respond to inquiries from members of the public.
- Discussing with field staff and project managers what information can and cannot be disclosed about site activities.



• Evaluating potential conflicts of interest and making staffing and project selection determinations accordingly.

4.0 DRINKING WATER AND SUPPLY WELL SAMPLING

This section provides PFAS sampling considerations for drinking water and supply well matrices. This section is not intended to teach water sampling fundamentals, but rather to provide instruction on differences in procedures and considerations specific to PFAS sampling. Procedures discussed in this section are additional considerations to the general PFAS sampling guidelines provided in Section 3. Due to the potential sensitivity to low-level detections in drinking water samples, drinking water and supply well sampling should be undertaken with the utmost consideration of cross contamination risk, materials used, and planning of sampling procedure.

4.1 EQUIPMENT/MATERIALS

In addition to the general and decontamination supplies listed in Sections 3.3 and 3.8, respectively, additional sample materials and supplies may include:

- Purge water collection buckets (optional), in the event that purge water needs to be contained, or a sample tap is located in a vault or other undrained location.
- A garden hose (optional) may be used to direct purge water from an exterior spigot, if needed to direct drainage to a suitable location; however, the hose must be removed prior to sampling such that a sample is collected directly from the spigot.

4.2 SAMPLING PROCEDURES

Sample collection for PFAS should generally follow these procedures. During most steps, samplers should don new (unused) nitrile gloves, even if it is not expressly identified below. New gloves should always be donned before handling sample containers, at any time.

- Using appropriate pen or ultra-fine Sharpie, fill out sample labels with all information except sample time and apply labels to sample containers. Pre-labeled sample containers may be stored in labeled 1-gallon Ziploc bags prior to sampling.
- Prepare a clean workspace for the sample staging area, using a decontaminated surface, clean PE sheeting, or untreated paper towels.
- Prepare the sampling area, removing moveable/unnecessary materials from the sampling area, including unnecessary hoses, aerators, filters, or other attachments/extensions of the tap (as noted, a hose may be in place during purging from an exterior spigot, only if needed to direct purge water, but must be removed prior to sampling).
- Don new nitrile gloves, changing as needed. Identify the sample port and open to allow purging and stabilization of the water flow for at least 3 minutes (purge time may vary based on project objectives) at a moderate to high flow.



- After purging is complete, reduce the discharge rate to a slow stream (generally less than 1 liter per minute) to minimize potential sample aeration.
- Don new nitrile gloves and collect the sample, filling each sample container to the shoulder.
- After closing sample containers, remove excess water from sample container surface with a fresh, untreated paper towel (excess water can facilitate cross-contamination) and place sample containers inside a new Ziploc bag. Double bag samples if they come from an area with known elevated PFAS levels.
- Place the samples in a cooler with ice, separate from any cooler with empty sample bottles.
- After sample handling is complete, close the sample spigot.

4.3 DECONTAMINATION AND IDW MANAGEMENT

The need for decontamination of reusable sampling equipment is not anticipated for water sampling from spigots. If reusable equipment such as a portable table for sample staging is used, which cannot be covered with PE sheeting, decontaminate using Alconox or similar and PFAS-free water.

Use a plastic contractor's bag (or similar) to contain solid IDW, including PE sheeting, nitrile gloves, Ziploc baggies, and other sampling materials, to minimize risks of cross contamination.

4.4 OTHER NOTES

- If a hose is used to direct water during purging, it must be removed prior to sampling.
- If Teflon[®] tape is visible at the sample port locations where water exists the port, document on the field forms. Although PFAS are associated with Teflon[®] tape production, experience to date suggests that it isn't a significant source of PFAS contamination in samples collected; nevertheless, its presence should be noted.

Domestic water may flow through a pressure tank or treatment system (e.g., water softener) before being discharged from a tap. For domestic wells, depending on sampling objectives, it may be necessary to collect water samples pre-treatment, post-treatment, or both. Pre-treatment sampling may be best if sampling is being conducted to evaluate local source-water impacts, but post-treatment may be best if sampling is conducted to evaluate drinking water exposure.

5.0 GROUNDWATER SAMPLING

This section provides PFAS sampling considerations specific to groundwater matrices. This section assumes general understanding of basic groundwater sampling procedures, and is not intended to teach groundwater sampling fundamentals, but rather to provide instruction on differences in procedures and considerations specific to PFAS sampling. Groundwater sampling typically requires purging of groundwater from wells using standard ("high-volume") or low-flow methods; alternatively, no-purge



methods such as HydraSleeves are available. Where appropriate, Trihydro's preferred groundwater sampling method for PFAS is no-purge sampling using HydraSleeves, to limit risk of cross-contamination and minimize risk of bias in sampling results due to artificially mobilizing PFAS in groundwater during purging. If no-purge sampling is not feasible, or is not accepted by regulatory agencies, low-flow sampling is recommended. Standard, high-volume purging methods should be avoided if possible, but may be required due to deep groundwater or other location-specific needs. Regardless of sampling method, sampling materials should be screened for PFAS compatibility. Additional considerations for sampling materials associated with these methods are provided in this section. The procedures discussed in this section are additional considerations to the general PFAS sampling guidelines provided in Section 3.

5.1 EQUIPMENT/MATERIALS

In addition to the general and decontamination supplies listed in Sections 3.3 and 3.8, respectively, additional sample materials and supplies required for PFAS sampling via no-purge sampling, low-flow sampling, bailer sampling, and submersible pump sampling are described below.

No-purge sampling (preferred). No-purge sampling may be conducted using HydraSleeve or other passive samplers constructed of HDPE or similar PFAS-compatible material. Passive diffusion samplers are also available for PFAS sampling. When ordering HydraSleeves (or similar no-purge sampling devices), communicate with the vendor that they are to be used for PFAS sampling, and materials must be PFAS compatible. PFAS-compatible rope (e.g., cotton or nylon) must be used for HydraSleeve deployment; it is recommended (but not required) to procure the PFAS-compatible rope from the HydraSleeve vendor. Deployment of no-purge sampling equipment can generally follow manufacturer's instructions but should also follow the general PFAS sampling approach described herein.

The HydraSleeve samplers consist of collapsible HDPE plastic sleeves that are deployed in a well at a fixed depth within the screened interval (typically near the bottom of the screened interval). A check valve at the top of the sleeve prevents groundwater from entering the sleeve during deployment. After deployment, the samplers are left in place for a prescribed amount of time (typically a week) to allow groundwater within the well to equilibrate with the formation. For sample collection and recovery, the HydraSleeve sampler is pulled upward, which opens the check valve and allows water to fill the sleeve. The HydraSleeve sampler is then recovered to the surface, and a sample collected from the sleeve. The sleeves are available in 1-liter, 2-inch well diameter size ('Super/SkinnySleeve 1-Liter', part number PFCHDSS-1L) and 2-liter, 2-inch well diameter size ('Super/SkinnySleeve 2-Liter', part number PFCHDSS-2L). For groundwater sampling in 4-inch wells, the HydraSleeve sampler may be deployed with a 4- to 2-inch reducer and spring clip, which is available from the vendor. Non-disposable components (dedicated materials) associated with the HydraSleeves (i.e., reducer, spring clip, and weight) should be dedicated to each well.



Low-flow sampling. Low-flow sampling involves well-purging at a limited flow rate (e.g., <500 mL/min) until parameters stabilize (EPA 1996). A peristaltic pump is recommended for PFAs sampling, if water depth can accommodate a peristaltic pump, to reduce/eliminate the need for equipment decontamination between sampling locations. If needed (e.g., for water too deep for a peristaltic pump), bladder pumps or electric submersible pumps may be used. Dedicated pumps are preferred, otherwise PFAS-compatible decontamination procedures must be completed between locations. For a bladder pump, the pump body should be constructed of stainless steel (or other PFAS compatible material), and the bladder and O-rings must be constructed of polyethylene or similar PFAS-compatible materials, and be replaced between sample locations. If an electric submersible pump is selected, evaluate that the pump is free of PTFE and other fluoropolymer fittings. Additional considerations for low-flow PFAS sampling are as follows:

- For a rental pump used for PFAS sampling, verify with the vendor that the pump is designed and constructed to be PFAS compatible.
- Downhole tubing should be either disposable or dedicated to a single location, and constructed of HDPE or a similar PFAS-compatible material; tubing constructed of Teflon, PTFE, or similar fluoropolymers cannot be used.
- Standard silicone tubing may be used for a peristaltic pump, but the tubing should be replaced between sample locations.
- A flow-through cell with a multi-parameter meter may be used to track parameters stabilization during low-flow purging. The flow-through cell does not need to be completely constructed of PFAS-compatible materials, but the meter/flow-through-cell must be removed from the flow path before sample containers are filled.

Bailer sampling. Samples can also be collected via bailer, though it is generally not preferred due to sample agitation and potential mixing with the air-water interface. Bailer materials are available that are compatible with PFAS sampling, such as HDPE. PFAS-compatible rope (e.g., cotton or nylon) must be used for bailer sampling. When used for PFAS sampling, bailers should be gently lowered across the water surface to minimize turbidity, and should be lowered sufficiently below the water surface such that the sample represents formation water rather than interfacial water.

Submersible pump sampling. High-flow purging with a submersible pump is generally not recommended for PFAS sampling, due to potential for PFAS contamination by pump components, cross-contamination between wells, and the possibility of mobilizing PFAS in a non-representative manner (e.g., via air bubbles) during high-volume purging. However, submersible pumps may be the only practical sampling device for deep wells. When practicable, use dedicated pump systems to eliminate cross contamination. The purge-water flow rate should be kept low, to eliminate or minimize entrained air bubbles in the water stream while purging and sampling.



Additional groundwater sampling considerations.

- Sampling materials should never be placed directly on the ground. Use a clean surface or PE sheeting for work space.
- If turbidity is noted, do not field-filter samples as filtration may affect PFAS concentrations. The laboratory should be informed of highly turbid samples; under certain circumstances, the laboratory may use centrifugation to prepare the sample for analysis.
- Purge water may generally be collected in standard 5-gallon buckets.
- Fluid level or interface probes may be used to monitor water levels before/during sampling. PFAS-compatible decontamination procedures must be followed between locations. Unless necessary, measurement of in-well total depth is not recommended during PFAS sampling to minimize cross-contamination risks.
- PFAS-compatible rope/twine (typically cotton or nylon) may be used for securing HydraSleeves, submersible pumps, or bailers.
- Equipment that contacts water within the well (e.g., pumping equipment and water meters) should not contain or be coated with Teflon[®], unless the Teflon[®] is internal to the equipment and does not contact the external environment. Often, equipment suppliers will label products as "PFAS Testing Approved" or "PFAS-free." It is highly recommended that equipment and supplies be identified as PFAS-free. If unsure whether a product is suitable for collecting a PFAS sample, contact the supplier and/or collect an equipment blank.

5.2 SAMPLING PROCEDURES

Sample collection for PFAS should generally follow these procedures. During most steps, samplers should don new nitrile gloves, even if it is not expressly identified below. New gloves should always be donned before handling sample containers, at any time.

- Decontaminate reusable equipment that will contact groundwater prior to use. Gauge depth to water and determine targeted pump-intake or screened interval for sampling.
- Using appropriate pen or ultra-fine Sharpie, fill out sample labels with all information except sample time (which can be added after the sample is collected and the lid replaced) and apply labels to sample containers. Pre-labeled sample containers may be stored in labeled 1-gallon Ziploc bags prior to sampling.
- Prepare a clean workspace for the sample staging area, using a decontaminated surface, clean PE sheeting, or untreated paper towels.
- Prepare the sample collection area, removing any moveable/unnecessary materials from the sampling area. Deploy PE sheeting as needed for staging of sampling materials, providing workspace to keep materials off the ground.



- Lower the pump, intake tubing, bailer, or passive sampler to the desired sample interval. Importantly, the sample interval should be several feet below the groundwater-air interface to ensure the collection of a representative groundwater sample and avoid sampling of PFAS accumulated at the interface.
- If low-flow purging is performed, connect the water quality meter to the flow path and initiate purging. Collect purge-water in a dedicated container (e.g., plastic 5-gallon bucket) and make sure that water does not splash or come into contact with the sample staging area and sample bottles. Record parameters at regular intervals, in accordance with standard practice for low-flow purging. After groundwater parameters have stabilized, disconnect the water quality meter before sampling.
- Collect the sample don new nitrile gloves and fill the sample containers without touching other equipment or surfaces, including the sample tubing.
- It is preferable to have two personnel for sampling, one person to handle the sample device (e.g., HydraSleeve) and pour, and the other person to manage the sample containers, without needing to set down the sampling device and containers and risk potential cross-contamination.
- After sample containers are filled and closed, use clean, untreated paper towels to remove excess water from the exterior of the sample containers (excess water poses a cross-contamination risk during sample handling). Immediately place sealed sample containers in Ziploc bags, and place the bags in a sample cooler. Always have at least two dedicated coolers, one for clean sample bottles, and one for collected samples, to further minimize risk of cross-contamination during sample collection and handling.

5.3 EQUIPMENT DECONTAMINATION

Ideally, sampling should use disposable or dedicated equipment that does not require decontamination. Rental equipment should be treated as potentially contaminated, and be decontaminated before initial use. If a bladder pump is utilized, the bladder should be changed between sample locations and the pump body thoroughly decontaminated. Reusable equipment, including a pump or water-level meter, should be decontaminated using a Alconox, Liquinox, or Citrinox wash and a final, triple-rinse using laboratorysupplied water that is certified PFAS-free. Note that Simple Green[®] has not been confirmed to be PFAS free, and is therefore not approved for PFAS sampling decontamination at this time.

5.4 OTHER NOTES

If existing sample tubing is present in the well, unless the tubing composition is known, it should be assumed to be PFAS-containing (e.g., Teflon). In this case, it is highly recommended that the tubing be removed from the well, and at least one well volume of water purged from the well prior to sampling. Greater fluid volumes can be removed from the well if deemed necessary, however removal of at least one well volume is required before sampling.



Samples should not be collected from wells with measurable light non-aqueous phase liquids (LNAPL), due to the tendency of PFAS to accumulate at oil/water interfaces (e.g., Brusseau 2018). Similarly, PFAS will also preferentially tend to accumulate at air-water interfaces. To ensure representative sample collection, do not collect groundwater samples directly from the groundwater-air interface, where practicable.

6.0 SURFACE WATER AND SEDIMENT SAMPLING

This section provides PFAS sampling considerations specific to surface water and sediment matrices. This section assumes general understanding of basic surface water and sediment sampling procedures, and is not intended to teach surface water and sediment sampling fundamentals, but rather to provide instruction on differences in procedures and considerations specific to PFAS sampling. The procedures discussed in this section are additional considerations to the general PFAS sampling guidelines provided in Section 3.

6.1 EQUIPMENT/MATERIALS

In addition to the general and decontamination supplies listed in Sections 3.3 and 3.8, respectively, additional sample materials and supplies may include:

- Waders that have not been treated with waterproof coating (Table 1)
- Transfer containers, such as beakers or dippers, and extension rods
- Stainless-steel sample spoons, sample augers, or sample core barrels
- Disposable sample spoons constructed of PFAS-compatible material
- Single-use PVC or acetate sediment sampler liners (as needed)
- HDPE core-liner caps (preferred) or LDPE liner caps (if HDPE are not available) as needed
- Self-retracting utility knife with hook blades (decontaminated)
- Hacksaw with uncoated blade (decontaminated)
- Wrist- or elbow-length nitrile or PVC gloves for sediment sampling beneath shallow surface water

6.2 SURFACE WATER SAMPLING PROCEDURES

Where surface water and sediment samples are to be co-located, surface water samples should be collected first, to minimize potential for suspended sediment in the water sample. Surface-water samples should be collected below the surface and avoid water from the surface film, to avoid sample bias due to PFAS accumulation at air-water interfaces. During most steps, samplers should don new nitrile gloves, even if it is not expressly identified below. New nitrile gloves should always be donned before handling sample containers, at any time. Sample collection for PFAS should generally be conducted in accordance with the following procedures:


- 1. Before use, decontaminate reusable equipment that will contact surface water or sediment.
- 2. Using appropriate pen or ultra-fine Sharpie, fill out sample labels with all information except sample time (which can be added after the sample is collected and the lid replaced) and apply labels to sample containers. Pre-labeled sample containers may be stored in labeled 1-gallon Ziploc bags prior to sampling.
- 3. Prepare a clean workspace for the sample staging area, using a decontaminated surface, clean PE sheeting, or untreated paper towels.
- Select a location where a sample can be collected from a depth of at least 10 centimeters (cm) (4 inches) from the sediment bed, at least 10 cm below the surface-water level, and as close to the center of the channel as practicable.
- 5. Where surface water can be collected by hand, samplers should approach the sample location from downstream.
- 6. Keeping the lid in place, submerge the sample container to the target sample depth.
- 7. Orient the sample container upstream; remove the cap to fill the container. The container should be filled to the shoulder, some headspace is preferred, if practical while filling underwater.
- 8. Replace the cap while the container is still submerged and close tightly before bringing the container above the water's surface.
- 9. Remove excess water from the outside of the sample container with a clean, untreated paper towel, add sample time to label, and immediately place inside a clean Ziploc bag, and place in the sample cooler.

Use of a transfer container is not recommended for PFAS sampling, but under certain circumstances may be required. A transfer container may be needed where sample locations are not directly accessible, such that extension rods or dippers are needed, or if sample containers require preservation and cannot be submerged. Transfer containers may be used under such circumstances, but must be clean and constructed of PFAS-compatible materials.

6.3 SEDIMENT SAMPLING PROCEDURES

Surface water sampling should be completed before sediment sampling. Spoons or scoops may be used to sample shallow sediments, however these methods may not be ideal due to agitation of the sample, mixing and washing during collection, and the inability to accurately determine sediment interval. For deeper/depth-discrete sampling, the preferred sediment sample collection method is to use a sediment sample auger (or similar). General sample collection procedures are as follows:



- 1. Before use, decontaminate reusable equipment that will contact surface water or sediment.
- 2. Using appropriate pen or ultra-fine Sharpie, fill out sample labels with all information except sample time (which can be added after the sample is collected and the lid replaced) and apply labels to sample containers. Pre-labeled sample containers may be stored in labeled 1-gallon Ziploc bags prior to sampling.
- 3. Prepare a clean workspace for the sample staging area, using a decontaminated surface, clean PE sheeting, or untreated paper towels.
- 4. If sediment sampling beneath shallow surface water using a spoon/scoop, don wrist-length nitrile or PVC gloves to avoid contact between skin and surface water, reducing risk potential for cross-contamination.
- 5. Approach the desired sediment sampling location from downstream if using waders. Sample should be collected from the midpoint of the channel, where practicable.
- 6. Drive the sediment sampler into the sediment. It is best to 'overshoot' the target sample depth, so that organics and debris overlying the sediment can be discarded, allowing collection of a representative sample.
- 7. Remove the sediment sampler, and place the sediment on an PE-lined sample table. Be sure to note the top and bottom of the sediment interval.
 - If using a sediment sampler with an acetate liner:
 - The liner can be opened using the self-retracting knife, to identify the desired sample interval. Change gloves after handling the knife. Discard organic material and debris on the surface, and transfer target sample intervals to HDPE sample containers. The samples can be transferred using a decontaminated stainless-steel scoop or disposable scoop. Use a fresh scoop and change nitrile gloves if collecting samples from more than one interval.
 - Alternatively, the liner can be cut into segments, capped with a liner cap, and placed into Ziploc bags for shipping to the analytical laboratory. Remove excess silt and debris from the exterior of the liners before cutting. Place each liner section in its own separate bag.
 - If using a sediment sampler without a liner:
 - Place the sampler on a clean, PE-lined table. Identify the desired sample interval. Do not allow organic material and debris on the surface to be entrained in the sample. Transfer target sample intervals to HDPE sample containers. The samples can be transferred using a decontaminated stainless-steel scoop or disposable scoop. Use a new scoop and change nitrile gloves if collecting samples from more than one interval. Fill the sample container and replace the cap.
- 8. Clean the outside of the sample container with a untreated paper towel, add the time sampled, and place into a Ziploc bag and then directly into the sample cooler.



6.4 EQUIPMENT DECONTAMINATION

Ideally, sampling should use disposable or dedicated equipment that does not require decontamination. Rental equipment should be treated as potentially contaminated, and be decontaminated before first use. Reusable equipment, including a sediment sample spoon or hand-auger, should be decontaminated using a Alconox, Liquinox, or Citrinox wash and a triple-rinse using laboratory-supplied water that is certified PFAS-free. Note that Simple Green[®] has not been confirmed to be PFAS free, and is therefore not approved for PFAS sampling decontamination at this time.

7.0 SURFACE AND SUBSURFACE SOIL SAMPLING

This section provides sampling considerations specific to surface and subsurface matrices. This section assumes general understanding of basic soil sampling procedures, and is not intended to teach soil sampling fundamentals, but rather to provide instruction on differences in procedures and considerations specific to PFAS sampling. Surface soil sampling may be conducted using hand tools or drill equipment. Generally, standard soil sampling and/or drilling equipment is compatible with PFAS sampling, with certain considerations noted in this section. When subcontracting a driller for soil sampling, it is important to communicate PFAS requirements early in the process, so they are able to prepare and plan accordingly. Procedures discussed in this section are additional considerations to the general PFAS sampling guidelines provided in Section 3.

7.1 EQUIPMENT/MATERIALS

In addition to the general and decontamination supplies listed in Sections 3.3 and 3.8, respectively, additional sample materials and supplies may include:

- 1. Disposable polyvinyl chloride (PVC), high density polyethylene (HDPE), or acetate liners
- 2. HDPE liner caps (preferred) or LDPE liner caps (if HDPE are not available) as needed
- 3. Self-retracting utility knife with uncoated hook blades or uncoated razor blades
- 4. Hacksaw with uncoated blade
- 5. Stainless-steel hand auger, trowel, or shovel
- 6. Polyethylene or polyvinyl brush to remove particles during decontamination

Equipment that contacts soil should not contain or be coated with Teflon[®] (or other PFAS incompatible material) unless the Teflon[®] is internal to the equipment and does not contact the external environment. If uncertain, contact the supplier and/or an equipment blank may be collected.

7.2 SAMPLING PROCEDURES

Surface and subsurface soil samples may be collected to delineate surficial and vertical extent of impacts where PFAS are potentially or known to be released to land/soil. Overall, sampling procedures used for PFAS are similar to those used for conventional soil sampling, with certain material limitations and



precautions against cross-contamination as noted herein. Surface and shallow soil samples can be collected using a decontaminated stainless-steel hand auger, trowel, or shovel; a disposable plastic scoop may also be used. If sampling from a hand auger, the sample material may be removed from the auger into a decontaminated stainless-steel bowl. Soil samples collected using a trowel or shovel may be transferred directly into the sample container using a disposable scoop, decontaminated spoon, or a new nitrile glove. Care should be taken to ensure the samples avoid contact with uncontrolled surfaces such as the ground, contaminated equipment, cooler-top, or tailgate.

Several methods are available for PFAS-related subsurface soil sampling, including hand-auger, directpush, hollow-stem auger/split-spoon sampler, or continuous core collection via sonic drill rig or other drill method. Direct push and split spoon samplers, which generate cores in acetate, HDPE, or PVC liners, are preferred due to the minimization of sample contact with drilling equipment, as well as minimization of agitation. For accurate assessment of subsurface PFAS impacts, collection of cores with minimal disturbance is preferred. Drilling methods that produce loose cuttings such as those obtained by auger and rotary drilling processes should be avoided if possible. Additional considerations for drilling are provided in the following section.

After collection, soil core liners may be cut open using a decontaminated stainless-steel cutting device, such as a retractable-blade utility knife. Soil core samples may be transferred to a decontaminated stainless-steel bowl for consolidation and subsampling, or samples may be collected directly from the core liners and transferred to laboratory-provided HDPE or polypropylene sample bottles. Soil samples should be transferred from the core liners using disposable scoops, decontaminated spoons, or new nitrile gloves. If other analytical suites are to be collected (e.g., metals, volatile organic compounds), collect the PFAS samples first and secure the PFAS samples in coolers before collecting other analytical suites to prevent container cross-contamination. Do not touch other sample containers, which may have PTFE-containing septa or lids, prior to collecting the PFAS sample. Place PFAS samples in separate bags or separate coolers from other analytical samples for shipping. When collecting samples, the sample container cap should never be placed directly on the ground during sampling; sample container caps/lids should be held, or only placed on surfaces that are known to be PFAS-free. Once collected, soil sample containers should be stored in their own Ziploc bags within the sample cooler, and placed on double-bagged ice to begin the cooling process in accordance with the procedures in Section 3.7. Soil samples stored in bags should be double bagged.

Alternatively, soil core samples may remain in the PVC, HDPE, or acetate liners for shipping to the analytical laboratory. Full soil cores inside the sample liners should be cut crosswise using a decontaminated, untreated hook blade knife or hacksaw, into the target sample intervals. The core-liner segments can be capped on both ends using HDPE liner caps. LDPE liner caps may be used if HDPE caps are unavailable; however, PFAS compounds may adsorb to LDPE liner caps. Bulk soil on the exterior of each core-liner segments should be removed using clean, untreated paper towels and each core segment should be placed in a Ziploc bag (core segments should be double-bagged if elevated PFAS



concentrations are suspected). The capped/bagged core segments can then be placed in a sample cooler on double-bagged ice.

7.3 DRILLING PROCEDURES

Subsurface soil sampling necessarily involves the use of non-dedicated equipment such as drill rods, core barrels, split spoons, augers, trowels, shovels, and other drilling related equipment. These equipment can be a potential source of cross contamination both from boring to boring as well as between vertical intervals within a single boring. Lubricants used during drilling should not be labeled as containing PTFE or other fluoropolymer. Thorough decontamination of the exterior and interior surfaces of drill rods, core barrels, and other drill rig tooling should be conducted between every boring location. Due to the size and quantity of this equipment, it may not be practical to use laboratory supplied PFAS-free water for decontamination purposes. Therefore, a source of clean decontamination water may be identified and confirmed as PFAS-free by laboratory analysis prior to the field event.

Beyond drilling equipment, there are additional cross-contamination risks inherent to the drilling process. Drillers handle drilling equipment manually when advancing the drilling tooling. Work gloves, boots, and clothing worn by the drillers can pose a cross-contamination risk. Clothing requirements discussed in Section 3 should be communicated to drill crews in advance of the field event. Drill crews should avoid wearing waterproof, water resistant, or stain proof clothing. Nitrile gloves should be worn outside work gloves and changed often when handling drill tooling. Work boot overshoes, PVC coveralls, and other mitigation measures may be considered to limit cross-contamination risks. However, personnel safety is paramount and should not be sacrificed for cross-contamination mitigation. Cross-contamination risks can also be mitigated using procedural measures such as ensuring that drillers do not touch the internal surfaces of drilling equipment (e.g., inside of core barrels) or other surfaces which might come in direct contact with the soil sample. For this reason, it is recommended that PFAS considerations be communicated with the drilling contractor and also included in a kickoff meeting, held with the drill crew in advance of the event where detailed procedures and cross-contamination mitigation best practices are discussed. Selection of a drilling contractor with PFAS-specific experience is also recommended.

7.4 EQUIPMENT DECONTAMINATION

Where possible, sampling should use disposable or dedicated equipment that does not require decontamination. Decontamination of soil-drilling and soil-sampling equipment (cores, grab samples) can be conducted via pressure-washing or using Alconox, Liquinox, and Citranox solutions (see Table 1). Equipment should be scrubbed with a plastic brush and rinsed thoroughly in tap water to wash away debris or material on exposed surfaces. Replace decontamination solution if sediment has accumulated or between locations where high PFAS concentrations may be expected. As a final decontamination step, triple rinse equipment in laboratory-supplied PFAS-free water. Use a spray bottle for the PFAS-free water rinse, to avoid contaminating decon rinse water. PVC or acetate liners should be discarded and not decontaminated between sampling sites.



8.0 OTHER SAMPLING MATRICES

PFAS sampling may be required in other matrices, such as sludge/biosolids, air, non-aqueous phase liquids (NAPLs), asphalt, concrete, and plant or animal tissues. This SOP does not include protocols for these matrices. The general PFAS sampling guidelines should be followed, and a laboratory consulted for specific guidelines on sample requirements. Consult a member of Trihydro's PFAS sampling team for assistance.

9.0 PFAS LABORATORY REQUIREMENTS

This section includes procedures and considerations for initial laboratory communications, PFAS analytical methods, container preservation requirements, and sample quality control/quality analysis (QA/QC) requirements.

9.1 LABORATORY COMMUNICATION

Communication is recommended with the selected analytical laboratory before sampling, or during preproject communications with candidate analytical laboratories, to confirm the following:

- 1. Does the laboratory have the necessary accreditation?
- 2. Can the laboratory meet the required reporting limits for all PFAS analytes?
- 3. Do the laboratory-specific methods (e.g., 537-MOD) use isotope dilution for quantification?
- 4. Can the laboratory accommodate project-specific needs, such as high concentrations or unusual matrices?
- 5. Can the laboratory provide certified PFAS-free water for decontamination and QA/QC samples?
- 6. Can the laboratory meet the required turnaround time? What is the current backlog for PFAS samples?

9.2 ANALYTICAL METHODS

As of July 2022, the EPA has published the following PFAS analytical methods:

- 1. Method 533: drinking water, 24 analytes
- 2. Method 537.1: drinking water, 18 analytes
- 3. Method 8327: non-drinking water aqueous samples, 24 analytes
- 4. DRAFT Method 1633: wastewater, surface water, groundwater, soil, biosolids, sediment, landfill leachate, and fish tissue; 40 analytes
- 5. DRAFT Method 1621: aqueous matrices, adsorbable organic fluorine (AOF) (i.e., total organic fluorine)



For non-drinking-water matrices, most laboratories have established independent methods for PFAS analysis, typically involving isotope dilution to account for matrix interference and including both branched and linear isomers. Although often referred to as 'modified 537' or '537-MOD' these laboratory-independent methods are in fact unrelated to EPA 537.1. To ensure consistent and repeatable analysis for non-drinking water samples, the laboratory should have proper accreditation and have capability to perform analysis that is consistent with U.S. Department of Defense (DoD) Quality System Manual (QSM) Version 5.1 or later (5.3 is the most recent version), Table B-15. QSM 5.3 Table B-15 is not an analytical method, per se, but provides a standardized set of laboratory quality control procedures. Compliance with QSM Table B-15 protocol has generally been required for regulatory-ordered PFAS samples, although this requirement may change as the EPA finalizes more methods. Trihydro's PFAS team recommends that samples be analyzed in compliance with QSM Table B-15 protocol to ensure data quality, even if not specifically required. PFAS analytes associated with each of these methods are provided on Table 2.

- EPA 537.1: Determination of Selected Per-and Polyfluorinated Alkyl Substances in Drinking Water by Solid Phase Extraction and Liquid Chromatography/Tandem Mass Spectrometry. November 2018. Drinking water method for 18 analytes, does not use isotope dilution*.
- EPA 533: Determination of Per- and Polyfluoroalkyl Substances in Drinking Water by Isotope Dilution Anion Exchange Solid Phase Extraction and Liquid Chromatography/Tandem Mass Spectrometry. November 2019. Drinking water method for 25 analytes, uses isotope dilution*.
- 3. **EPA 8327**: Per- and Polyfluoroalkyl Substances by Liquid Chromatography/Tandem Mass Spectrometry (LC/MS/MS). July 2021. Aqueous, non-drinking water matrices (groundwater, surface water, waste water), considered as a screening-level method, does not use isotope dilution*.
- 4. DRAFT EPA 1633: Analysis of Per- and Polyfluoroalkyl Substances (PFAS) in Aqueous, Solid, Biosolids, and Tissue Samples by LC-MS/MS. August 2021. DRAFT method for ground water, surface water, waste water, soil and sediment matrices, using isotope dilution*. This method has not been finalized as of March 2022. Despite "draft" status, the method is being used and required by some states in monitoring permits. Unless required for a specific sampling event, this method is not recommended at this time by Trihydro's PFAS team.
- 5. **DRAFT Method 1621**: Screening Method for the Determination of Adsorbable Organic Fluorine (AOF) in Aqueous Matrices by Combustion Ion Chromatography (CIC). Provides a single result ("AOF") representing total PFAS concentration.
- 6. DoD QSM 5.3 Table B-15: DoD Quality Systems Manual Version 5.3. May 2019. Table B-15: Per- and Polyfluoroalkyl Substances (PFAS) Using Liquid Chromatography Tandem Mass Spectrometry (LC/MS/MS) With Isotope Dilution or Internal Standard. As of March 2022, this is recommended as a standardized method for groundwater, surface water, waste water, soils, and sediment samples. Can be referenced in work plans as "the samples will be analyzed at a certified laboratory using methods compliant with DoD QSM Table B-15" (uses isotope dilution*).



**Note regarding isotope dilution*: the descriptions above indicate which methods use isotope dilution to quantify analytes. Isotope dilution is an internal standard, and methods that do not use isotope dilution use external standards. Isotope dilution increases detection accuracy, which can be very important to quantify and control matrix interference, which can be very important for complex environmental matrices.

The specific analyte list is an important consideration for PFAS site investigation. PFOA, PFOS, perfluorobutane sulfonate (PFBS), and GenX are the only PFAS compounds with USEPA Health Advisory Levels (as of July 2022), but hundreds to thousands of additional PFAS compounds are also present in the environment. Typical laboratory methods quantify a relatively small fraction of these compounds. The specific analyte list for each project should be determined based on method requirements, sampling objectives, and client needs. PFAS analytes associated with the above methods are shown on Table 2. Unless a USEPA method is referenced for a compound list, a list of target PFAS analytes should be attached to the chain of custody (COC) form. State-issued sampling orders may require other PFAS or non-PFAS analytes.

9.3 USE OF PRESERVATIVE

For drinking water samples, each 250 mL sample bottle may be required to contain a preservative. EPA method 537.1 a small amount (1.25 g) of Trizma[®] and method 533 requires 1 g/L ammonium acetate, both of which are included to remove free chlorine from chlorinated drinking water (USEPA 2015). Before sampling drinking water for PFAS analysis, confirm the need for the Trizma[®] or ammonium acetate with the selected analytical laboratory. For groundwater samples or other water matrices, inclusion of Trizma[®] is not required but is considered harmless (in terms of potential effects on measured PFAS concentrations) and may be included.

The Trizma[®] and ammonium acetate buffers are required for samples analyzed via EPA Method 537.1 and EPA Method 533, respectively. The buffer is required regardless of whether the water being sampled is chlorinated.

9.4 FIELD QUALITY ASSURANCE AND QUALITY CONTROL SAMPLES

Field quality-assurance / quality-control (QA/QC) samples are imperative for PFAS analysis. Five different types of QA/QC samples may be collected during the sampling event as described below. Each type of QA/QC sample listed below is provided a "Required" or "Optional" label. QA/QC sampling needs may be determined in a Quality Assurance Project Plan (QAPP).

<u>Field Blanks (Required)</u>: Field blanks (or field reagent blanks) are collected to verify that the sampling environment and site-required PPE worn during the sampling event do not contaminate samples. At a minimum, one field blank should be collected for each site, with each sampling event that involves collecting an aqueous sample. Field blanks are analyzed for the same list of PFAS constituents as



analyzed for associated field samples. The field blank is collected by pouring PFAS-free reagent water received from the laboratory into an empty, clean sample container at the sampling site. Generally, two laboratory-provided sample containers are filled for each field-blank sample.

<u>Equipment Blanks (Required)</u>: Equipment blanks will be prepared and submitted for laboratory analysis to verify that equipment decontamination procedures are effective, and to verify that sampling equipment is PFAS-free and not causing contamination. Equipment blanks are analyzed for the same PFAS constituents as required for the field samples. Minimally, equipment blanks should be collected for sampling equipment that may contact the sample matrix, such as HDPE core liners, bailers, pump tubing, using PFAS-free water provided by the laboratory. Equipment blanks should be collected at a rate of at least 1 per event per piece of equipment used for sampling. Equipment blanks are not required for tapwater sampling, where sample containers are filled directly from source water.

<u>Blind Duplicates (Recommended)</u>: Blind Duplicate samples can be collected to evaluate reproducibility of analytical techniques and the homogeneity of sample matrices. Duplicate samples are submitted for the same PFAS analyses that are required for the field samples. Duplicate samples will be collected at a frequency of 10%, or one for every 10 samples for aqueous sampling matrices. If less than 10 samples are collected during a particular sampling event, one blind duplicate sample will be collected. The duplicate sample will be "blind" to the laboratory, therefore will have a coded identity on its label and on the COC. The actual sampling location and identification will be recorded on the sampling log.

<u>Trip Blanks (Optional)</u>: Trip blanks are laboratory-prepared bottles containing PFAS-free water that travel from the laboratory to the site, and then transported back to the laboratory with the samples in the sample coolers. A set of trip blanks can accompany each cooler that contains PFAS samples. Trip blanks should be supplied by the laboratory and will accompany the sample containers throughout the sampling event. Trip blanks will only be analyzed by the laboratory for PFAS if instructed to do so by the PM; these samples should otherwise be held once received by the laboratory. Trip blanks are generally not required for PFAS samples but may be helpful to identify sources of contamination, should they occur.

<u>Matrix Spikes/Matrix Spike Duplicates (MS/MSD) (Optional)</u>: MS/MSDs can be prepared and analyzed by the laboratory for each matrix sampled. MS/MSDs are samples in which known quantities of specific PFAS compounds are added before extraction and analyses. The recoveries for spiked compounds can be used to assess how well the method for analysis recovers target compounds. MS/MSD samples are submitted for the same PFAS analyses that are required for the field samples.



10.0 REFERENCES

- Brusseau ML. 2018. Assessing the potential contributions of additional retention processes to PFAS retardation in the subsurface. Sci Total Environ. February 1, 2018; 613-614:176-185.
- California Office of Environmental Health Hazard Assessment (OEHHA). 2021. Notification Levels for Chemicals in Drinking Water. oehha.ca.gov. 2021. Available from: <u>https://oehha.ca.gov/water/notification-levels-chemicals-drinking-water.</u>
- California State Water Quality Control Board (The Water Boards), Division of Water Quality. 2020a. Per- and Polyfluoroalkyl Substances (PFAS) Sampling Guidelines for Non-Drinking Water. September 2020. Available from: https://www.waterboards.ca.gov/pfas/docs/sept_2020_pfas_sampling_guidelines.pdf.
- California State Water Resources Control Board. 2021. WQ 2021-0006-DWQ Water Code Sections 13267 and 13383 Order for the Determination of the Presence of Per- and Polyfluoroalkyl Substances at Bulk Fuel Storage Terminals and Refineries. March 12, 2021.
- EPA. 1996. Puls, R.W. and M.J. Barcelona. Low-Flow (Minimal Drawdown) Ground-Water Sampling Procedures. EPA/540/S-95/504. April 1996.
- Interstate Technology Regulatory Council (ITRC). 2022. ITRC's guidance document, Technical Resources for Addressing Environmental Releases of Per- and Polyfluorinated Compounds (PFAS), Chapter 11, Sampling and Analytical Methods, Updated September 2022. Available from: <u>https://pfas-1.itrcweb.org/11-sampling-and-analytical-methods/.</u>
- Michigan Department of Environmental Quality (MDEQ). 2018. General PFAS Sampling Guidance. Revised October 16, 2018. Available from: <u>https://www.michigan.gov/documents/pfasresponse/General_PFAS_Sampling_Guidance_634597_7.pdf.</u>
- United States Environmental Protection Agency (USEPA). 2015. Method 537. Determination of selected perfluorinated alkyl acids in drinking water by solid phase extraction and liquid chromatography/tandem mass spectrometry (LC/MS/MS). Revised October 7, 2015. Available from: https://cfpub.epa.gov/si/si_public_record_report.cfm?dirEntryId=198984&simpleSearch=1&sear chAll=EPA%2F600%2FR-08%2F092.

000-000-000

TABLES

TABLE 1. PFAS SAMPLING ITEMS1SOP FOR CHARACTERIZATION OF PFAS AT BULK FUEL STORAGE TERMINALS AND REFINERIES

Prohibited Items/Materials	Acceptable Items/Materials
Sampling	Equipment ¹
Polytetrafluoroethylene (PTFE), including Teflon [®]	High-density polyethylene (HDPE) materials including
and Hostaflon [®] -containing materials (tubing, bailers,	polypropylene ²
tape, and plumbing paste)	
Polyvinylidene fluoride (PVDF), including Kynar [®] -	Stainless steel
containing materials (tubing, coatings on aluminum	
and steel, lithium-ion batteries)	
Polychlorotrifluoroethylene (PCTFE), including	Nylon or cotton
Neoflon [®] -containing materials (valves, seals,	
gaskets, food packaging)	
Ethylene-tetrafluoro-ethylene (ETFE), including	Polyvinyl chloride (PVC)
Tefzel [®] (wire/cable insulation, pipe liners)	
Fluorinated ethylene propylene (FEP), including	Acetate liners
Teflon [®] FEP and Hostaflon [®] FEP-containing	
materials (wire/cable insulation, pipe liners)	
Low-density polyethylene (LDPE)	Silicone tubing
Aluminum foil	Natural rubber
Sample Labeling an	d Field Documentation
Waterproof field books	Loose paper (non-waterproof)
Plastic clipboards, binders, spiral hard cover	Aluminum field clipboards or with Masonite®; Rite-in-
notebooks	the-Rain is acceptable in staging area if gloves are
	changed after note taking.
Post-It Notes	Ballpoint pens
Regular/thick size markers (Sharpie®)	Fine and Ultra-Fine point Sharpie [®] markers are
	acceptable to label empty sample bottles while in
	staging area provided the lid is on the sample bottle
	and gloves are changed following sample bottle
	labeling.
Re-usable chemical (blue) ice packs	Water-based ice in polyethylene bags (double bagged)
	uipment (PPE) used by Field Personnel ³
Clothing laundered using fabric softener	Synthetic or cotton clothing that has been well-
	laundered clothing, defined as clothing that has been
	washed 6 or more times after purchase
New cotton clothing or synthetic water-resistant/	Waterproof clothing made with polyurethane, PVC,
waterproof clothing or dirt/stain-resistant treated	wax-coated fabrics, rubber, or neoprene
clothing, clothing containing GORE-TEX [™] ,	
Scotchgard [™] , and RUCO [®]	
Boots containing GORE-TEX [™]	Boots made with polyurethane and/or PVC
Latex gloves	Powderless nitrile gloves
Clothes chemically treated for insect resistance and	
ultraviolet protection	
Coated Tyvek [®]	

.

TABLE 1. PFAS SAMPLING ITEMS1SOP FOR CHARACTERIZATION OF PFAS AT BULK FUEL STORAGE TERMINALS AND REFINERIES

Prohibited Items/Materials	Acceptable Items/Materials						
Personal Care Products	, Sun/Biological Protection						
No cosmetics, moisturizers, fragrances, hand cream, or other related products as part of personal cleaning	Sunscreens - Alba Organics Natural Sunscreen, Yes To Cucumbers, Aubrey Organics, Jason Natural Sun						
showering routine on the day of sampling, and 24 hours prior to sampling.	Block, Kiss my face, Baby sunscreens that are "free" or "natural" Insect Repellents - Jason Natural Quit						
	Bugging Me, Repel Lemon Eucalyptus Insect repellant, Herbal Armor, California Baby Natural Bug Spray,						
	BabyGanics Sunscreen and insect repellent - Avon Skin So Soft Bug Guard Plus – SPF 30 Lotion						
Sample	Containers						
LDPE or glass containers	HDPE or polypropylene						
Teflon [®] -lined caps	Unlined polypropylene caps						
Rain	Events						
Waterproof or water-resistant rain gear	Gazebo tent that is only touched or moved before and following sampling activities						
Equipment D	econtamination						
Decon 90 [®] , Simple Green [®]	Alconox [®] , Liquinox [®] , or Citranox [®]						
	Laboratory supplied PFAS-free water						
	Commercially available deionized water if verified to be PFAS-free						
Water from an on-site well	Potable water from municipal drinking-water supply if known to be PFAS-free						
Food Cor	nsiderations						
All food and drink, with exceptions noted herein. Note that fast-food and prepackaged food containers may contain PFAS.	Bottled water and hydration drinks (i.e., Gatorade [®] and Powerade [®]) to be brought and consumed only in the staging area						

Notes:

1. PFAS sampling-item restrictions apply to the entire sample collection and processing area, including vehicles used by sampling personnel

2. The United States Environmental Protection Agency (USEPA) and American Society for Testing and Materials (ASTM) method for the analysis of PFAS in solid and liquids specify polypropylene or HDPE with polypropylene lids. Check with the laboratory regarding their polypropylene or HPDE preference.

3. Sampling personnel includes all personnel who:

- Are directly involved in the collection, handling, and/or processing of samples before the samples leave the site.
- Handle any part of equipment that directly contacts surface water or stormwater.
- Are within 2 to 3 meters (i.e., 6 to 9 feet) of the borehole during soil sampling.

Personnel are not included as sampling personnel if they remain at least 2 to 3 meters away from sample-collection areas before and during sampling.

.

TABLE 2. PFAS REFERENCE TABLE - CHEMICAL NAMES, ACRONYMS, AND ANALYTICAL METHODS PFAS SAMPLING STANDARD OPERATING PROCEDURES TRIHYDRO CORPORATION

Perfluordebatancic acid * PFBA 375-22-4 214.0 C_F_COOH X X X Perfluordebatancic acid * PFFBA 2706-90-3 28-11 C_F_COOH X	-			This table presents a selec	t subset of the 3,0	00+ compoun	ds class	ified as PFAS.	Ar	alyti	cal n	neth	ods
Image: Perfusion of the second state of the	Classificatior Familv	Class	Group	PFAS Compound	Acronym	Abstract Service		fluorinated tail (red)	EPA 537.1	EPA 533	EPA 8327		EPA 1633 (draft)
Perfuscoloscando acid ** PFHyA 307.44 314.1 C_F_*CODH X </td <td></td> <td></td> <td></td> <td>Perfluorobutanoic acid *</td> <td>PFBA</td> <td>375-22-4</td> <td>214.0</td> <td>C₃F₇COOH</td> <td></td> <td>Х</td> <td>Х</td> <td>Х</td> <td>Х</td>				Perfluorobutanoic acid *	PFBA	375-22-4	214.0	C ₃ F ₇ COOH		Х	Х	Х	Х
Verture Perfusional cald ** PFHpA 375-85-9 364.11 C,F,GOOH X				Perfluoropentanoic acid *	PFPeA	2706-90-3	264.1	C₄F ₉ COOH		х	х	Х	Х
Verture PECA 335-67-1 41.1 CF_#s020H X				Perfluorohexanoic acid *	PFHxA	307-24-4	314.1	C₅F ₁₁ COOH	Х	Х	Х	Х	Х
Image: Process of the second				Perfluoroheptanoic acid *	PFHpA	375-85-9	364.1	C ₆ F ₁₃ COOH	Х	Х	Х	Х	Х
Verture Perfluorodecanoic acid ** PFDA 335-76-2 514.1 C_F_WCOOH X <thx< th=""> X X</thx<>				Perfluorooctanoic acid **	PFOA	335-67-1	414.1	C7F15COOH	Х	Х	Х	Х	Х
Image: Section of the sectio			1	Perfluorononanoic acid **	PFNA	375-95-1	464.1	C ₈ F ₁₇ COOH	Х	Х	Х	Х	Х
Image: Section of the sufficiency of the section of the sectin of the section of the sectin of the section of the sect		(AA)		Perfluorodecanoic acid **	PFDA	335-76-2	514.1	C ₉ F ₁₉ COOH	Х	Х	Х	Х	Х
Image: Section of the sufficiency of the section of the sectin of the section of the sectin of the section of the sect	spu	(PF		Perfluoroundecanoic acid **		2058-94-8	564.1	C ₁₀ F ₂₁ COOH					Х
Image: Section of the sectio	noc	Acid								Х			Х
Image: Section of the sectio	L L	lk yl											Х
Image: Section of the sectio	Ŭ	oroa							-				Х
Image: Section of the sufficiency of the section of the sectin of the section of the sectin of the section of the sect	atec	srflue							X				х
Number Production Producion Producion <td>urine a</td> <td>Pe</td> <td></td> <td>Х</td>	urine a	Pe											Х
Number Production Producion Producion <td>lluc</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>X</td> <td></td> <td></td> <td></td> <td>Х</td>	lluc								X				Х
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	VS)		2	•	•				V				X
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	2 H								×	X			X
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	l) si												X
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	nce										X	X	Х
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	osta												X
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	Sub	<			PFOSA	754-91-6					Х	Х	Х
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	Ž	FAS		N-methyl perfluorooctane sulfonamide	N-MeFOSA	31506-32-8	513.2	C ₈ F ₁₇ SO ₂ N(CH ₃)H					Х
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	oall			N-ethyl perfluorooctane sulfonamide	N-EtFOSA	4151-50-2	527.2	C₈F₁₇SO₂N(C₂H₅)H					Х
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	ds			Hexafluoropropylene oxide dimer acid (GenX)	HFPO-DA	13252-13-6	330.2	C ₃ F ₇ O(CF ₂) ₂ COOH	Х	Х			Х
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	N FI			4,8-dioxa-3H-perfluorononanoic acid	ADONA	919005-14-4	378.1	CF ₃ O(CF ₂) ₃ OC ₂ HF ₃ COOH	х	Х			Х
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	Pol	Jers		Nonafluoro-3,6-dioxaheptanoic acid	NFDHA	151772-58-6	296.0	CF ₃ O(CF ₂) ₂ OCF ₂ COOH		Х			х
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	S D	/ Et		Perfluoro(2-ethoxyethane)sulfonic acid	PFEESA	113507-82-7	316.1	C ₂ F ₅ O(CF ₂) ₂ SO ₃ H		х			х
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	er a	balky		Perfluoro-3-methoxypropanoic acid	PFMPA	377-73-1	230.0	CF ₃ O(CF ₂) ₂ COOH		х			х
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	e P	nord		Perfluoro-4-methoxybutanoic acid	PFMBA	863090-89-5	280.0			х			х
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	lac	ш							x				х
$\frac{1}{10000000000000000000000000000000000$	Ser	-											x
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$									~		v	v	X
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$		SIS	2										
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$		ome	3										Х
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	0	rote		8:2 Fluorotelomer sulfonic acid	8:2 FISA	39108-34-4				Х	X	Х	Х
$\begin{bmatrix} v_{1} & v_{2} & v_{3} & v_{4} & v_{5} \\ v_{1} & v_{1} & v_{2} & v_{3} & v_{4} & v_$		Fluc	4	6:2 Fluorotelomer alcohol	6:2 FTOH	647-42-7	364.1	C₆F₁₃(CH₂)₂OH					
$\begin{bmatrix} v_{1} & v_{2} & v_{3} & v_{4} & v_{5} \\ v_{1} & v_{1} & v_{2} & v_{3} & v_{4} & v_$				8:2 Fluorotelomer alcohol	8:2 FTOH	678-39-7	464.1	C₈F₁₇ (CH ₂) ₂ OH					
	Prec	e e	5	N-ethyl perfluorooctanesulfonamido acetic acid	N-EtFOSAA	2991-50-6	585.2	$\textbf{C_8F_{17}SO_2N(C_2H_5)CH_2CO_2H}$	х		Х	Х	Х
	ed /	roalka	Ĺ	N-methyl perfluorooctanesulfonamido acetic acid	N-MeFOSAA	2355-31-9	571.2	$C_8F_{17}SO_2N(CH_3)CH_2CO_2H$	Х		Х	Х	Х
	rinat	erfluor Sulfor	6	N-ethyl perfluorooctane sulfonamido ethanol	EtFOSE	1691-99-2	571.3	C₈F₁₇SO₂N(C₂H₅)(CH₂)₂OH					х
Image: Section of the section of th	lluo			N-methyl perfluorooctane sulfonamido ethanol	MeFOSE	24448-09-7	557.2	$C_8F_{17}SO_2N(CH_3)(CH_2)_2OH$					х
Product <t< td=""><td>Pol</td><td>mer Acids</td><td></td><td>3-Perfluoropropyl propanoic acid</td><td>3:3 FTCA</td><td>356-02-5</td><td>242.1</td><td>C₃F₇C₂H₄COOH</td><td></td><td></td><td></td><td></td><td>х</td></t<>	Pol	mer Acids		3-Perfluoropropyl propanoic acid	3:3 FTCA	356-02-5	242.1	C ₃ F ₇ C ₂ H ₄ COOH					х
ਤ-Perfluoroheptyl propanoic acid 7:3 FTCA 812-70-4 442.1 C ₇ F ₁₅ C ₂ H₄COOH		roteloi xylic /		2H,2H,3H,3H-Perfluorooctanoic acid	5:3 FTCA	914637-49-3	342.1	C ₅ F ₁₁ C ₂ H ₄ COOH					х
		Fluo Carbo		3-Perfluoroheptyl propanoic acid	7:3 FTCA	812-70-4	442.1	C ₇ F ₁₅ C ₂ H ₄ COOH					х

Notes:

* denotes short chain perfluoroalkyl acid

** denotes long chain perfluoroalkyl acid

PFAS Class Acronyms

PFAA: Perfluoroalkyl acid

FASA: Perfluoroalkane sulfonamide

PFAS Group Names and Acronyms 1. PFCA: Perfluoroalkyl carboxylic acid

2. PFSA: Perfluoroalkane sulfonic acid

3. FTSA: Fluorotelomer sulfonic acid

4. FTOH: Fluorotelomer alcohols

5. FASAA: Perfluoroalkyl sulfonamido acetic acids

6. FASE: Perfluoroalkane sufonamido ethanols

References:

ITRC guidance document, Chapter 2. https://pfas-1.itrcweb.org/2-pfas-chemistry-and-naming-conventions-history-and-use-of-pfas-and-sources-of-pfas-releases-to-the-environment-overview/ EPA working list of PFAS compounds: https://www.epa.gov/chemical-research/ord-subset-pfas-research

2_202209_PFAS_reference_TBL-2.xlsx

ATTACHMENT A

OFFICE TRAINING CHECKLIST

ATTACHMENT A. OFFICE TRAINING CHECKLIST PFAS SAMPLING STANDARD OPERATING PROCEDURES TRAINING PROGRAM TRIHYDRO CORPORATION

(development/review in progress)

- 1. PFAS Overview basic information to understand rationale for PFAS sampling approaches and to address basis questions
 - a. Chemistry
 - b. PFAS uses/environmental sources
 - c. Regulatory status
- 2. Unique elements of PFAS sampling
 - a. Hundreds/thousands of compounds
 - b. Presence in common materials
 - c. Highly scrutinized results
- 3. Standard Operating Procedures Overview
 - a. Table of Contents overview/key elements
 - b. Material compatibility table
 - c. General PFAS sampling steps
- 4. Project Sampling Discussion
 - a. Types of sampling
 - b. Additional training needs
 - c. Project specific preparation needs/focus on relevant SOP sections

ATTACHMENT B

FIELD TRAINING CHECKLIST

ATTACHMENT B. FIELD TRAINING CHECKLIST PFAS SAMPLING STANDARD OPERATING PROCEDURES TRAINING PROGRAM TRIHYDRO CORPORATION

(development/review in progress)

- 1. Allowable materials
 - a. Clothing/PPE
 - b. Gloves
 - c. Paper Towels
 - d. Buckets
 - e. Sampling Materials
 - f. Pens/Sharpies
 - g. Field Notes
- 2. Prohibited Materials
 - a. Area Inspection
 - b. Clothing/PPE
 - c. Food wrappers
- 3. Site Preparation and Area Management
 - a. Staging Area
 - b. Sampling Area
 - c. Personnel
 - d. Coolers
 - e. Housekeeping
- 4. Hands
 - a. Awareness
 - b. Changing gloves
- 5. Sampling considerations
 - a. Groundwater pumps, tubing, supplies
 - b. Soil Sampling: drilling and hand-auger
- 6. Sample Container Management
 - a. Pre-collection
 - b. During collection
 - c. Post-collection
- 7. Decontamination
 - a. Plastic brush
 - b. Spray bottles

.

ATTACHMENT C

EXAMPLE FIELD SAMPLING DOCUMENTATION FORM

ATTACHMENT C. EXAMPLE FIELD SAMPLING DOCUMENTATION FORM

Client / Project # :		
Boring / Sample ID Analysis: 537.1 / 537 MOD / Other Sample Depth: Sample Description:	Sample Date/Time: QC samples: Sample Recovery:	
Boring / Sample ID Analysis: 537.1 / 537 MOD / Other Sample Depth: Sample Description:	Sample Date/Time: QC samples: Sample Recovery:	
Boring / Sample ID Analysis: 537.1 / 537 MOD / Other Sample Depth: Sample Description:	Sample Date/Time: QC samples: Sample Recovery:	
Boring / Sample ID Analysis: 537.1 / 537 MOD / Other Sample Depth: Sample Description:	Sample Date/Time: QC samples: Sample Recovery:	
Boring / Sample ID Analysis: 537.1 / 537 MOD / Other Sample Depth: Sample Description:	Sample Date/Time: QC samples: Sample Recovery:	
Sampling Equipment: Field Personnel:	Trihyd	ſO



Western Refining Southwest LLC Gallup Refinery OW-63 PFAS Investigation Work Plan

Appendix C - Standard Operating Procedure for Low Flow Groundwater Sampling



memorandum

To:	Trihydro Employees					
From:	OSE					
Date:	June 24, 2011					
	Standard Operating Procedure –					
Re:	Low-Flow (Micro-Purge) Well Sampling					

1.0 PURPOSE, SCOPE, AND RESPONSIBILITIES

This standard operating procedure (SOP) is intended to provide methods for low-flow sampling of groundwater from monitoring wells. Low-flow (micro-purge) sampling is a method of collecting samples from a well; the method does not require the removal of large volumes of water, and therefore does not overly agitate the water and suspended particles or potentially aspirate volatile organic compounds (VOCs) (which can affect sample integrity).

Low-flow sampling includes collecting water directly from the screened interval without disturbing stagnant water above the screen. This is accomplished by pumping the well at low enough flow rates to maintain minimal drawdown of the water column, followed by in-line sample collection. Typical flow rates for low-flow sampling typically range from 0.1 to 0.5 L/min (Liter per minute). Some regulatory agencies recommend not using peristaltic and suction pumps for VOC sample collection because of de-gassing concerns. Local regulations should be understood prior to choosing equipment.

This SOP is applicable to all Trihydro projects where groundwater samples are collected from a monitoring well via low-flow methods and where no project or program-specific procedure is in use. Detailed safety procedures are included in the site-specific health and safety plan (HASP) and job safety analyses (JSAs). The project manager should be contacted for additional health and safety information.

This SOP is intended for the sole use of Trihydro Corporation and its employees. This SOP cannot be copied or used by others without the express written consent of Trihydro. In Trihydro's sole discretion, this SOP may be modified when field or other conditions warrant.

The Operational and Service Excellence (OSE) Business Unit is responsible for SOP maintenance, management, and revisions. Trihydro employees performing tasks within this SOP are responsible for meeting SOP requirements. For projects where activities within this SOP are necessary, the project manager (or designee) is responsible for ensuring that those activities are conducted in accordance with this and other SOPs. Project team members are responsible for documenting procedural information in sufficient detail (i.e., calculations, field notes, reports, etc.) and reporting these changes to OSE. Such documentation will be included as a component of project records.



2.0 PLANNING AND PROCEDURES

As stated above, low-flow sampling involves removing water directly from the screened interval without disturbing stagnant water above the screen and without significantly lowering the water table. Since this method is not based upon the removal of well volumes, it requires in-line monitoring of water-quality parameters (i.e., pH, specific conductivity, temperature, dissolved oxygen, redox potential) to determine when the groundwater to be sampled has stabilized. The sample is then collected, using the same pump, directly from the discharge tubing.

2.1 VARIABLES

The following variables should be considered in planning for low-flow purging and sampling:

- **Recharge capacity of each well:** The recharge capacity of a well will determine how fast the well should be purged. To prevent water-table drawdown, the purge rate should be no greater than the recharge rate of the groundwater zone.
- Well-construction details, including well depth, diameter, screened interval, screen size, material of construction, and depth to water table: The diameter and well depth determine the size of the pump and the location from which the pump will operate. Peristaltic and suction draw pumps are only viable at depths of less than 25 feet. The pump intake should be placed within the well screen.
- **Pump:** Low-flow purging and sampling can be employed in any well that can be pumped at a constant rate less than or equal to 1.0 L/min. Continuous discharge and cycle discharge pumps with adjustable flow-rate controls should be used to avoid causing continuous drawdown. Whenever possible, dedicated pumps should be installed to avoid disturbing the water column.
- Groundwater quality, including type and concentration of chemical compounds present: Lowflow methods can be used for aqueous-phase contamination, including VOCs, semi-volatile organic compounds (SVOCs), metals, pesticides, polychlorinated biphenyls, radionuclides, and microbiological constituents. Pump parts and tubing should be made of materials that are compatible with the constituents of concern.
- **Regulatory requirements:** As stated in Section 1.0, some regulatory agencies recommend not using peristaltic and suction pumps for VOC sample collection because of de-gassing concerns. Local regulations should be understood prior to selecting equipment.

2.2 EQUIPMENT

The following equipment is recommended for well purging:

□ Required personal protective equipment (PPE), listed in site-specific health and safety plan (HASP) (generally nitrile gloves and safety glasses for low-flow sampling)



- □ Pump and discharge hose and line constructed of compatible materials capable of <1.0 L/min draw rates
- □ Water-level meter
- □ Swabbing materials
- □ Flow-through water-quality meter (for pH, specific conductance, temperature, dissolved oxygen, redox potential) calibrated daily
- □ Nephelometer (calibrated, if required)
- D Photoionization detector (PID) (calibrated, if screening for VOCs is required)
- Drums or tanks to hold purge water
- □ Plastic sheeting
- □ Decontamination solutions: deionized (DI) water and detergent (e.g., Alcinox, Liqui-Nox, Simple Green, depending on the application). Non-phosphate detergents, such as Alconox or Liqui-Nox, should be considered for sites or wells with only trace-level contamination or where phosphates are a constituent of concern. Phosphate detergents, such as Simple Green, should be considered for heavily contaminated sites or wells where phosphates are not a constituent of concern.
- □ Sample containers and preservatives
- □ Sample labels
- □ Chain-of-custody forms
- □ Paper towels
- \Box Ice chest or cooler
- \Box Ice and resealable plastic bags
- □ Field logbook
- □ Calculator
- □ Wrist watch (with digital display)

2.3 PRE-SAMPLING

To prevent cross contaminating other wells, upgradient and background wells should be sampled first. The procedure for pre-sampling is as follows:

- 1. Don a pair of clean nitrile gloves, safety glasses, and other required PPE (listed in HASP).
- 2. Prepare the area surrounding the well by placing plastic sheeting on the ground surface to prevent potential cross-contamination of the pump and discharge hose or sample equipment and materials.



- 3. Place and secure the drum, tank, or suitable purge water container in close proximity to the well for purge-water collection and storage. Purge water must be containerized and disposed of in the manner specified in the project and program plan or as the client directs. Never return purge water to the well. If in doubt, or where requirements are not specified, handle all purge water as waste and dispose of it accordingly.
- 4. If performing VOC screening, measure and record the background organic vapors in the ambient air using a PID (in accordance with manufacturer specifications and recommendations).
- 5. Open the well casing, remove the well cap, and immediately measure and record the organic vapor levels from the head space within the well casing using a PID (in accordance with manufacturer specifications and recommendations).
- 6. Measure the depth to the static water level using the water-level meter.

2.4 WELL PURGING

The procedure for well purging is as follows:

- 1. Review and understand the proper operating and maintenance instructions for the pump prior to placing the pump in the well. Each pump type has specific operating procedures.
- 2. Don a pair of clean nitrile gloves, safety glasses, and other required PPE (listed in HASP).
- 3. Some wells may include a dedicated pump that is already placed in the well along the well screen. If this is the case, review well-construction data to verify the proper placement of the pump intake. Inspect the location where the discharge line and pump support cable exit the well to determine that they are in the proper position (markings should be present at the well head to show this).
- 4. Assemble the pump and discharge line in accordance with manufacturer instructions. Ensure the pump discharge line is long enough so that the pump intake can be located within the well-screen area and the discharge end can reach the purge-water container.
- 5. Slowly lower the pump into the well until it is submerged and at the desired pumping depth.
- 6. Connect the pump discharge to the flow-through water-quality meter (in accordance with the manufacturer's procedure).
- 7. Start the pump and begin monitoring discharge rates and the collected water volume. Adjust flows if necessary to remain in a range of 0.1 to 0.5 L/min without exceeding the well-discharge rate.
- 8. Monitor and record the pH, conductivity, temperature, dissolved oxygen, redox potential, and turbidity at set intervals (2 to 10 minutes; refer to the site work plan for required interval).
- 9. When water-quality parameters are stable (pH, dissolved oxygen, and turbidity), and, as indicated by three consecutive readings within 10 percent, begin sample collection.



2.5 SAMPLE COLLECTION

The procedure for sample collection is as follows:

- 1. Don a pair of clean nitrile gloves, safety glasses, and other required PPE (listed in HASP).
- 2. Prepare sample bottles and preservatives for sampling.
- 3. Immediately after purging, collect the sample through the pump discharge line.
- 4. Fill volatile organic analysis (VOA) vials first (reduce the flow rate of the pump discharge), allowing the liquid to slowly fill the container without agitation, and obtain a meniscus slightly above the top of the vial. (If multiple cycles are needed to fill the VOA, cover the VOA with the cap between cycles to reduce the chance of volatilization).
- 5. Place cap on VOA and check for entrained air by slowly tipping, tapping against the palm of one hand, and observing for bubbles. If bubbles are present, discard the sample and collect again, as above.
- 6. Continue filling sample bottles.
- Add preservatives to the samples as needed, and place the sample bottles on ice. Note that most sample bottles come with preservatives already added. If such is the case, do not overfill the bottles. If a sample bottle containing preservatives is overfilled, discard the overfilled bottle and collect again, as above.
- 8. Replace the well cap, if required, and lock the cover.
- 9. Record the sampling information.
- 10. Secure the area by removing equipment and materials; properly dispose of plastic sheeting and other sampling materials, and close the purge-water container(s).
- 11. Decontaminate the pumping and sampling equipment. Dedicated pumping equipment should not be decontaminated.

3.0 STANDARD OPERATING PROCEDURE NAMING CONVENTION, PROCEDURAL CHANGES, AND REVISION SCHEDULE

This section includes information on the Standard Operating Procedure (SOP) naming convention, procedural changes, and revision schedule.

3.1 NAMING CONVENTION

The SOP naming convention will be included in the upper corner of each page and will appear as follows:

ID #: FS001_LowFlow

Rev. #: Original



Explanation of above:

ID # = Identification Number

FS001_LowFlow: FS = Field Sampling, 001 = Field Sampling SOP #1, LowFlow = Sampling Technique

3.2 PROCEDURAL CHANGES

When procedures change, Trihydro will update and reapprove this SOP. Modifications may address a small component of the SOP or the entire SOP. The OSE Business Unit will facilitate SOP reviews 2 years after the previous revision date. The revision date will be added to the schedule (below), the title page, and the naming convention that appears in the corner of each page.

If an SOP describes a process that is no longer followed, it will be withdrawn from its active file location and archived.

Revision Date	Reason for Revision	Most Recent Revision Date and SOP Library	Facilitator	Technical Reviewer
and Number	Revision	Upload	Facilitator	Reviewer
Original	New SOP	June 24, 2011	David Ludwin	Kirk Hardy

3.3 REVISION SCHEDULE

4.0 GLOSSARY: ACRONYMS, ABBREVIATIONS, AND DEFINITIONS

HASP – health and safety plan: includes a complete list of project personal protective equipment requirements, evacuation routes, medical services, and other pertinent health and safety information

L/min - liter per minute: unit used to measure pump rates

Low-flow - refers to the velocity used during well pumping; draws water to the surface slowly

Micro-purge – another term for low-flow sampling, referred to as such because pre-sampling groundwater removal (purging) is performed at flow rates 2 to 3 orders of magnitude less than typical bailer or pump methods

OSE – Operational and Service Excellence Business Unit: Trihydro's designated authority for facilitating standard operating procedure reviews

PID - photoionization detector: a type of gas detector used to measure volatile organic compounds

PPE – personal protective equipment: minimum-required site-safety equipment; a full list is included in the site-specific HASP



Pump – an electric, compressed air, or inert gas-driven device that raises liquids by means of pressure or suction. The types of pumps used for well purging should be chosen based on the well size and depth, contaminant type, and specific factors affecting the overall performance of the sampling effort. Low-flow and micro-purge sampling is performed using specially constructed pumps, usually of centrifugal, peristaltic, or submersible design, with low draw rates (<1.0 L/min).

Purging – the action of removing groundwater from well using mechanical means from a monitoring well prior to collecting groundwater samples. Purging removes stagnant groundwater from the column, allowing groundwater surrounding the well screen to enter the collection area.

SOP – standard operating procedure: procedure to be followed when performing a routine task

SVOC – **semi-volatile organic compound:** an organic compound with a boiling point higher than water; may vaporize when exposed to temperatures above room temperature

VOC – **volatile organic compound:** gases from certain solids or liquids, including a variety of chemicals, some of which may have short- and long-term adverse health effects

VOA – volatile organic analysis vial: small vial used for groundwater sampling (typically contains preservatives)

5.0 REFERENCES

- ASTM International. 1998. ASTM D6771-02. Standard Practice for Low-Flow Purging and Sampling for Wells and Devices Used for Ground-Water Quality Investigations.
- ASTM International. 2007. ASTM D4448-01. Standard Guide for Sampling Ground-Water Monitoring Wells.
- U.S. Army Corps of Engineers. 2001. Requirements for the Preparation of Sampling and Analysis Plans, Appendix C, Section C.2, EM200-1-3. Washington, DC.
- U.S. Environmental Protection Agency. 2011. Terms of Environment. Available from: (http://www.epa.gov/OCEPATERMS/).
- U.S. Environmental Protection Agency. 2007. Guidance for Preparing Standard Operating Procedures. EPA QA/G-6. Accessed April 1, 2011. Available from: (<u>http://www.epa.gov/quality/qs-docs/g6-final.pdf</u>).
- U.S. Environmental Protection Agency, Region 1, 1996. Low Stress (Low Flow) Purging and Sampling Procedure for the Collection of Ground Water Samples from Monitoring Wells, SOP GW0001, Revision 2. July 30.

QAQ-SCO-P00

Received by OCD: 4/16/2024 4:15:20 PM



Western Refining Southwest LLC Gallup Refinery OW-63 PFAS Investigation Work Plan

Appendix D - Example Logs



Western Refining Southwest LLC Gallup Refinery OW-63 PFAS Investigation Work Plan

Appendix D-1 - Example Soil Sample Log

PFAS SAMPLING FIELD FORM



Sample	Area/Category:				Recorded by:			
	S/	MPLE COLLECTION INFORMATION		PR	ECAUTIONS TAK	KEN PRIOR TO EACH	SAMPLE	
Date	Time	Field Sample Location/ID	Sample Depth [e.g. 0 - 0.5"]	Hammer drill bit deconned	New nitrile gloves	New trowel	PFAS-free sheeting surrounding sample area	SAMPLE DESCRIPTION
				Yes / No / NA	Yes / No	Yes / No / NA	Yes / No	
				Yes / No / NA	Yes / No	Yes / No / NA	Yes / No	
				Yes / No / NA	Yes / No	Yes / No / NA	Yes / No	
				Yes / No / NA	Yes / No	Yes / No / NA	Yes / No	
				Yes / No / NA	Yes / No	Yes / No / NA	Yes / No	
				Yes / No / NA	Yes / No	Yes / No / NA	Yes / No	
				Yes / No / NA	Yes / No	Yes / No / NA	Yes / No	
				Yes / No / NA	Yes / No	Yes / No / NA	Yes / No	
				Yes / No / NA	Yes / No	Yes / No / NA	Yes / No	
				Yes / No / NA	Yes / No	Yes / No / NA	Yes / No	
				OBSERVATIONS,				
		De	escribe any unusual condi	tions, visible impa	icts, deviations	s from work plan.		

Received by OCD: 4/16/2024 4:15:20 PM

8/6/10

.



Western Refining Southwest LLC Gallup Refinery OW-63 PFAS Investigation Work Plan

Appendix D-2 - Example Boring Log

Received by OCD: 4/16/2024 4:15:20 PM



CORPORATION												LOCATION ID						
Lit	holo	gy L	og						Sheet 1 of									
Proje	ect Na	ne	.9				Project Number						Site II)	!			
Drilli	ing Co	mpany				Driller			Ground	Elevati	on				Total Drilled Depth			
															feet-bgs			
Drilli	ing Eq	uipmer	ıt		Drilling M	ethod	Borehole Diameter		Date/Ti	me Dril	ling Sta	arted			Date/Time Total Depth Reached			
							inches											
Туре	of Sa	mpling	Devic	e					Water I First	evel (b		feet-b	gs		Final			
Samp	ole Ha	nmer							Hydrog	eologist			0		Checked by/Date			
Туре	:					Driving Weight	Drop											
Loca	tion D	escript	ion (in	clude sketch in f	ield logbool	k)												
						Description						Es	timate %	6 of	Remarks			
Depth	Interval	Recovery	Blow Counts	(Include litholo & notation, min	ogy, grain siz nerology, be	ze, sorting, angul dding, plasticity, as applicable)	arity, Munsell color name density, consistency, etc.,	ASTM Code		Lithology	Water Content	Gr	Sa	Fi	(Include all sample types & depth, odor, organic vapor measurements, etc.)			
0		L																
	-	╞																
		F																
1	\vdash																	
	F	F																
	F	F																
2		L																
	-	╞																
	F	F																
2	F	-																
3		F																
	F	-																
	F	F																
4	—																	
	F	F																
	┝	┝																
5		L																
	-	┝																
		E																
(-	-																
6		F																
	F	-																
	F	F																
7	—	\vdash																
	F	F																
	F	-																
8		L																
1	F																	
		F																
	F	\vdash																
9	F	F																
1	┢	\vdash																
10	F	F																

Received proCD: 4/16/2024 4:15:20 PM



CORP	ORATIO)		ſŪ								LOCATION ID
Lit	holog	gy L	.og (continued)	Sheet	t 2 of	-	-			
				Description				Est	imate %	of	Remarks
Depth	Interval	Recovery	Blow Counts	(Include lithology, grain size, sorting, angularity, Munsell color name & notation, minerology, bedding, plasticity, density, consistency, etc., as applicable)	ASTM Code	Lithology	Water Content	Gr	Sa	Fi	(Include all sample types & depth, odor, organic vapor measurements, etc.)
10 11	-										
12											
13	- - - -										
14											
15	- - - -										
16	-										
17	-										
18	-										
19	- - -										
20	-										
21											
22	- - -										
23	-	<u>F</u>									

Received proCD: 4/16/2024 4:15:20 PM



CORP	ORATIO	4 112									LOCATION ID
Litl	holo	gy L	.og (d	continued)	Shee	t 3 of					
		Ĩ		Description				Est	timate %	of	Remarks
Depth	Interval	Recovery	Blow Counts	(Include lithology, grain size, sorting, angularity, Munsell color name & notation, minerology, bedding, plasticity, density, consistency, etc., as applicable)	ASTM Code	Lithology	Water Content	Gr	Sa	Fi	(Include all sample types & depth, odor, organic vapor measurements, etc.)
23	_	_									
24											
24											
25											
26											
27											
28											
29											
30											
31											
32	 - -	 - -									
33	-										
34											
35	 - -	F									
36	-	F									

Received proCD: 4/16/2024 4:15:20 PM



CORP	ORATIO	H 112									LOCATION ID
Lit	holo	gy L	.og (d	continued)	Shee	t 4 of					
		Ĩ		Description				Est	timate %	6 of	Remarks
Depth	Interval	Recovery	Blow Counts	(Include lithology, grain size, sorting, angularity, Munsell color name & notation, minerology, bedding, plasticity, density, consistency, etc., as applicable)	ASTM Code	Lithology	Water Content	Gr	Sa	Fi	(Include all sample types & depth, odor, organic vapor measurements, etc.)
36	-	_									
	_	F									
37		Ē									
38	_										
39	-										
40	- - -										
	-										
41	-										
42	-										
43	-										
44	-										
	-										
45	-										
46											
47											
40		E									
48	_	F									
49		F									
Received by OCD: 4/16/2024 4:15:20 PM



		C1						LOCATION ID
Lithology Log (bg (continued) Sheet 5 of Estimate % c		C	Remarks				
Depth Interval Recovery Blow Counts	(Include lithology, grain size, sorting, angularity, Munsell color name & notation, minerology, bedding, plasticity, density, consistency, etc., as applicable)	ASTM Code	Lithology	Water Content	Gr	Sa	Fi	(Include all sample types & depth, odor, organic vapor measurements, etc.)
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$						54		

٦

LOCATION ID

ATTACHMENT D

RED LINE/STRIKE OUT REPORT

OW-63 PFAS Investigation Work Plan



Western Refining Southwest LLC Gallup Refinery Gallup, New Mexico

EPA ID# NMD000333211

December 31, 2022

Revised September 29, 2023April 16, 2024



Table of Contents

1.0	INTRO	DUCTION	4
	1.1	Background	4
	1.2	Hydrogeology	5
	1.3	PFAS-Containing Materials at the Refinery	5
2.0	FIELD	INVESTIGATION ACTIVITIES	7
	2.1	Phase 1: Groundwater Sampling at Existing Monitoring Wells	8
	2.2	Phase 2: Soil Sampling and Temporary Well Installation	9
	2.3	Phase 3: Groundwater Sampling at Temporary Wells1	0
	2.4	Investigation Derived Waste1	
	2.5	Equipment Decontamination1	1
3.0	ANALY	/TICAL METHODS1	3
4.0	QUALI	TY ASSURANCE AND QUALITY CONTROL1	4
	4.1	Field Quality Assurance and Quality Control Samples14	4
	4.2	Laboratory Assurance and Quality Control Samples1	5
	4.3	Data Validation1	5
5.0	SCHED	DULE AND REPORTING1	7
6.0	REFER	ENCES1	8

.



List of Figures

- 1-1. Groundwater and Soil Sampling Location Map, OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico
- 1-2. Potentiometric Surface Map (December 2021), OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico
- 1-3. Potentiometric Surface Map (March 2022), OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico
- 1-4. Potentiometric Surface Map (June 2022), OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico
- 1-5. Potentiometric Surface Map (September 2022), OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico

List of Tables

- 2-1. Summary of PFAS Soil and Groundwater Sample Identification, Sample Methods, and Analytical Methods, OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico
- 2-2. Summary of Existing Wells, OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico
- 2-3. Proposed Groundwater and Soil Sample Constituent List, OW-63 PFAS Investigation Work Plan, Western Refining Southwest LLC, Gallup Refinery, Gallup, New Mexico

List of Appendices

- A. OW-63 PFAS Sampling Results
- B. PFAS Sampling Standard Operating Procedure
- C. Standard Operating Procedure: Low Flow Groundwater Sampling
- D. Example Logs



List of Acronyms

AFFF	aqueous film forming foams
CLP	Contract Laboratory Program
COC	chain of custody
DP	direct push
EDD	electronic data deliverables
ft/day	foot/feet per day
HDPE	high-density polyethylene
I-40	Interstate 40
IDW	investigation derived waste
LCS/LCSD	laboratory control samples/laboratory control sample duplicates
MS/MSD	matrix spike/matrix spike duplicates
NM	New Mexico
NMED	New Mexico Environment Department
PE	polyethylene
PFAS	per- and polyfluoroalkyl substances
PFBS	perfluorobutane sulfonate
PFOA	perfluorooctanoic acid
PFOS	perfluorooctane sulfonate
PID	photoionization detector
PPE	personal protective equipment
PVC	polyvinyl chloride
QA/QC	quality assurance and quality control
QSM	Quality System Manual
SOP	standard operating procedure
SPH	separate phase hydrocarbons
USEPA	United States Environmental Protection Agency
VOC	volatile organic compound

Printed on April 16, 2024

.



1.0 Introduction

Trihydro Corporation (Trihydro) has prepared this per- and polyfluoroalkyl substances (PFAS) Investigation Work Plan (Work Plan) to conduct PFAS sampling in soil and groundwater near monitoring well OW-63 at the Gallup Refinery (Refinery). Figure 1-1 shows the site location and the area surrounding OW-63. This Work Plan was developed per New Mexico Environment Department's (NMED) request in Comment 12 of the "Approval with Modifications 2021 Annual Groundwater Monitoring Report" (NMED 2022), dated August 23, 2022: "...a PFAS plume may be present in the vicinity of OW-63. Submit a work plan to investigate the extent of the PFAS contamination no later than December 31, 2022".

The following objectives were developed to address NMED's comment:

- Identify PFAS-containing materials near OW-63.
- Identify areas where potential PFAS-containing materials have been potentially stored and/or used near OW-63.
- Describe a proposed sampling and analysis plan for various environmental matrices that delineates the extent of PFAS contamination near OW-63.

1.1 Background

Built in the 1950s, the Refinery is located within a rural and sparsely populated area east of Gallup, New Mexico (NM). The nearest population centers are the Pilot Flying J Travel Center refueling plaza, the Interstate 40 (I-40) corridor, and a small cluster of residential homes located on the south side of I-40 approximately 2 miles southwest of the Refinery (Jamestown, NM).

The Refinery was indefinitely idled on October 9, 2020. During operation, the Refinery was a crude oil refining and petroleum products manufacturing facility. There were no organic chemicals, plastics, or synthetic fibers manufactured that contributed to the process flow of wastewater. The Refinery did not manufacturer lubricating oils. As a result of the processing steps, the Refinery produced a wide range of petroleum products including propane, butane, unleaded gasoline, diesel, residual fuel, and commercial products of fertilizer and solid elemental sulfur.

Historically, the Refinery primarily received crude oil via two 6-inch diameter pipelines, which entered the Refinery property from the north (Four Corners Area). In addition, the Refinery also received natural gasoline feedstock via a 4-inch diameter pipeline that came in from the west along the I-40 corridor from the Western Refining Southwest LLC Wingate Plant, which is also indefinitely idled. Crude oil and other products also arrived at the Refinery via railroad cars. These feed stocks were then stored in tanks until refined into products.

Trihydro conducts groundwater sampling for PFAS at OW-63 on a quarterly basis. PFAS sampling in OW-63 began with NMED's request in Comment 30 in the "Disapproval Annual Groundwater Monitoring Report Gallup Refinery – 2019" (NMED, 2020) dated November 23, 2020: "...Well OW-63 is appropriately located to evaluate



for the presence of PFAS in the vicinity of the training area. Propose to conduct PFAS analysis for the groundwater samples collected from well OW-63 in the 2021 Facility-wide Groundwater Monitoring Work Plan." These results are included in the annual groundwater monitoring reports and in Appendix A. Currently, no other wells at the Refinery are sampled for PFAS.

The sections below describe site hydrogeology and PFAS-containing materials likely used at the refinery. More information regarding site background and hydrology can be found in the annual groundwater work plans and reports.

1.2 Hydrogeology

Groundwater flow within the shallow alluvium and the upper Chinle Formation is highly variable due to the presence of complex and irregular stratigraphy including sand stringers, cobble beds, and dense clay layers. Hydraulic conductivity ranges from 30 feet per day (ft/day) for gravel-like sands immediately overlying the Petrified Forest Formation to 3×10^{-5} ft/day in the clay soils located near the surface. Groundwater flow within the Lower Chinle Formation is extremely slow and typically averages less than 2.83 x 10^{-7} ft/day (i.e., less than 0.01 ft per year).

Water level data are collected routinely at the Refinery. Wells at the Refinery have been categorized based on the hydrogeologic unit in which they are screened, including the alluvial/fluvial upper sand aquifer, the Chinle/alluvium aquifer, and the Sonsela Sandstone aquifer. The alluvial/fluvial upper sand aquifer has a limited lateral extent, existing only on the western margin of the Refinery. Groundwater occurrence in this aquifer is sporadic and limited.

Most of the wells monitored lie within the shallow weathered sediments that comprise the Chinle/alluvium aquifer. Within the Chinle/alluvium aquifer, shallow groundwater located under the Refinery property generally flows along the upper contact of the Chinle Formation. The prevailing flow is from the southeast to the northwest, although localized areas may have varying flow directions based on the subsurface geology.

Groundwater within the Sonsela aquifer flows southeast to northwest. Hydraulic heads measured within the Sonsela are generally lower than those observed within the shallow aquifer near the topographic high on which the Refinery process area and tank farm are situated, and higher than those observed within the shallow aquifer in topographically low areas to the west and northwest, near the evaporation ponds. The higher head in the Sonsela in low areas is due to confining pressure from lower permeability Chinle Formation bedrock between the shallow Chinle/alluvium aquifer and the Sonsela Sandstone bed at depth, which makes the Sonsela Sandstone aquifer artesian. Figures 1-2, 1-3, 1-4, and 1-5 show quarterly potentiometric surface maps for the investigation area.

1.3 PFAS-Containing Materials at the Refinery

Since the 1950s, PFAS have been incorporated into many consumer and industrial products. One of the many historical uses is in firefighting foams ("Aqueous Film Forming Foams," or AFFF). AFFF products may be used for fire suppression at facilities where Class B fires (i.e., those involving flammable liquids and gases) may be a



concern, including airports, firefighting training areas, and other facilities where flammable hydrocarbons are present. AFFF formulations include hundreds to thousands of individual fluorinated and non-fluorinated surfactant compounds. Perfluorooctanoic acid (PFOA), perfluorooctane sulfonate (PFOS), and perfluorohexane sulfonate (PFHxS) are potential PFAS constituents in AFFF products, particularly in those produced between the 1960s and 1990s (ITRC 2022a). Modern AFFF products contain little to no PFOA or PFOS but may contain shortchain PFAS compounds such as perfluorobutane sulfonate (PFBS).

Firefighting is a component of petroleum refinery management. AFFF has been stored and historically used for fire suppression at the Refinery. Located to the northwest of OW-63 is the former Fire Training Area, where PFAS-containing foam was confirmed to be used. OW-63 is located downgradient of the Tank Farm and cross gradient of the former Fire Training Area. There are no known applications of PFAS-containing foam in the Tank Farm area immediately adjacent to OW-63. All firefighting foams have been removed from the Refinery.



2.0 Field Investigation Activities

Many PFAS compounds are potentially mobile in groundwater and are prone to accumulate at air/water and oil/water interfaces (Brusseau 2018, ITRC 2022b). The sampling program described herein has been developed to account for these aspects, with sampling designed to identify potentially mobile PFAS within the bulk water phase (i.e., avoiding interfaces) associated with shallow groundwater. The sections below describe the sampling locations, field methods for groundwater sampling and soil sampling, and details of temporary well installation.

This field investigation will be completed in a three-phase plan:

- Phase 1: Groundwater sampling at four existing groundwater monitoring wells (OW-12, OW-14, OW-57, OW-63, and OW-70). These wells are located cross gradient and down gradient of OW-63 (Figure 1-1).
- Phase 2: Soil sampling at five surface locations and three soil boring locations. The three soil boring locations will be constructed as temporary groundwater monitoring wells. Exact locations for the surface sample locations and temporary monitoring wells will be chosen based on groundwater analytical results from Phase 1.
- Phase 3: Groundwater sampling at the three temporary well locations.

Phase 1 of the investigation will be implemented so analytical results from existing groundwater monitoring wells can be used to determine the most beneficial locations for the temporary groundwater monitoring wells. Groundwater samples will be obtained from existing groundwater monitoring wells during Phase 1. After the Phase 1 investigation is complete, the Refinery will schedule a meeting with NMED to discuss and agree upon proposed Phase 2 sample locations.

The Phase 2 soil sampling and temporary groundwater monitoring well installations will occur during the same field event after Phase 1 analytical data are received. Soil sampling will involve surface sample collection and the drilling of boreholes using direct push drilling techniques. Phase 3 of the investigation is for the collection of groundwater samples, which will occur after the temporary groundwater monitoring wells have been installed for a minimum of seven days. Supporting activities include utility location, boring abandonment, waste management, and equipment decontamination. A handheld global positioning system unit will be used to log location coordinates for utilities, soil sampling locations, and the temporary monitoring wells. Table 2-1 presents a summary of the proposed soil and groundwater sample identifications, sample methods, sample type, constituents, and analytical methods.

Sampling will be conducted by experienced PFAS sampling personnel who will review and be familiar with the prohibited material list, in terms of clothing, personal protective equipment (PPE), sunscreens, insect repellent, rain-repellent gear, and other sampling equipment that are prohibited when sampling for PFAS as to prevent cross-contamination. Care will be taken to ensure that any materials contacting sample containers, from the time of removal from laboratory-supplied coolers through completion of sampling, comply with Table 1 of



Trihydro's PFAS Standard Operating Procedure (SOP) (Appendix B). A fresh pair of powderless nitrile gloves will be worn at each location, and gloves will be changed immediately before collecting each sample, in accordance with the SOP. Additional hand washing before donning of the new pair of gloves is necessary if the old pair was compromised or ungloved hands touched items that may contain PFAS. Sampling procedures will be reviewed prior to field activities to identify potential conflicts between site PPE requirements and PFAS-compatible materials. If conflicts are identified, procedures will be developed to minimize PFAS cross-contamination risks without compromising the Refinery's health and safety procedures.

2.1 Phase 1: Groundwater Sampling at Existing Monitoring Wells

The former Fire Training Area was identified as a potential PFAS-containing foam application area at the Refinery. Based on this identification, five existing groundwater wells are selected for PFAS sampling. Figure 1-1 provides the sample well locations. Additional information for OW-12, OW-14, OW-63, OW-57, and OW-70, including the screened interval, depth to groundwater, and total measured depth of well, is shown in Table 2-2. Groundwater samples will be analyzed for the PFAS parameters listed in Table 2-3. The reporting limits for the analytes on Table 2-3 will be dependent upon the lab selected for PFAS analysis. Reporting limits will be evaluated against NMED PFAS screening levels once a lab has been selected.

2.1.1 Fluid Level Monitoring

Fluid levels will be monitored in all wells prior to sampling using an interface probe. Fluid level monitoring will be conducted to evaluate for the presence of separate phase hydrocarbons (SPH) in wells and measure depth to groundwater. Historically, the wells selected for groundwater sampling have not had SPH in them. The interface probe will only be used to measure the fluid surface and SPH thickness (total depth will not be measured as part of the PFAS sampling event) to limit cross-contamination by minimizing contact between groundwater and the interface probe. Any well with detectable SPH will be removed from the monitoring list for this event and, if possible, an alternative well will be selected. The interface probe will be decontaminated prior to first use, and between each monitoring well, using PFAS-compatible methods in accordance with Appendix B.

2.1.2 Groundwater Sample Collection

Groundwater samples will be collected from monitoring wells OW-12, OW-14, OW-63, OW-57, and OW-70 using low flow sampling techniques and analyzed for PFAS compounds (Table 2-3). Low-flow or no-purge sampling approaches are generally preferred for PFAS sampling. PFAS may be associated with suspended solids, droplets of SPH, or entrained gas bubbles, any of which may be mobilized via high-volume purging sampling methods. Low flow sampling involves collecting groundwater directly from the screened interval without disturbing stagnant water above the screen. This is accomplished by pumping the well at low enough flow rates to maintain minimal drawdown of the water column.



Groundwater sampling for PFAS compounds will be conducted using low flow sampling methods in general accordance with the following guidance documents:

- Trihydro's PFAS SOP, included in Appendix B
- Trihydro's SOP for low flow sampling, included in Appendix C

Since this method is not based upon the removal of well volumes, it requires in-line monitoring of water-quality parameters (i.e., pH, specific conductivity, temperature, dissolved oxygen, redox potential) to determine when the groundwater to be sampled has stabilized. Stabilization occurs when three consecutive readings of water-quality parameters are within 10 percent. The sample is then collected, using the same pump, directly from the discharge tubing. Wells with dedicated pumps (i.e., OW-12 and OW-63) will be noted on the field logs and will use existing equipment in place.

Prior to placing the discharge line of the pump into the well, the sampler will verify the screened interval of the well to determine the length of discharge line to be placed in the well. The target sampling depth for each of the wells is the mid-point of the screened interval. This information is used to ensure that the samples are collected within the screened interval, and that water samples are representative of the formation. They will also verify the recharge capacity of the well to determine what flow the pump will be set at so that draw down is not occurring.

Sample containers will be filled immediately from the pump discharge line. Bottles will be filled in accordance with the low flow SOP and laboratory instructions. After being filled, sample containers will be placed in a cooler with double-bagged water-based ice (i.e., Blue Ice[™] or similar substitute materials are prohibited) for shipment.

To the extent practical, disposable sampling equipment will be used at each location to minimize the potential disturbance of formation groundwater and to reduce the risk of cross-contamination. Furthermore, all downhole monitoring or sampling equipment will not contain or be coated with Teflon[®] or other PFAS-incompatible materials (Appendix B). If reusable equipment is required, decontamination will occur as described in Section 2.5.

Equipment to be used during field sampling will be examined to certify that it is in operating condition. This includes checking the manufacturer's operating manual, as well as the instructions for each instrument, to ensure that maintenance requirements are being observed. Sample coolers will be shipped to an analytical laboratory via overnight delivery under chain of custody (COC) protocol.

2.2 Phase 2: Soil Sampling and Temporary Well Installation

Surface soil samples will be collected at five locations within the OW-63 area based on Phase 1 groundwater data and site topography, as identified on Figure 1-1. In addition, surface and subsurface soil samples will be collected from the three proposed temporary groundwater monitoring well boreholes that will be installed within the OW-63 area based on Phase 1 groundwater data, as identified on Figure 1-1. All soil samples will be analyzed for the PFAS parameters listed in Table 2-3.



2.2.1 Surface Soil Sampling

Surface soil samples will be collected from 0 to 1 ft below ground surface (ft bgs). Soil samples will be collected using a PFAS-free disposable hand trowel. At each location, a new hand trowel will be used. Sampling information will be recorded on an example log provided in Appendix D-1.

2.2.2 Subsurface Soil Sampling

Subsurface soil sampling will be conducted using a direct-push (DP) drilling rig capable of advancing continuous soil sample barrels. DP soil sampling will be conducted at three locations to be determined based on analytical results from Phase 1 of the investigation. Soil samples will be collected from the borings at two intervals: the surface (0 to 1 ft bgs) and 1 ft above the water table (approximately 17 to 34 ft-bgs).

Soil sample barrels will be decontaminated prior to each boring. Samples will be collected in an acetate liner or approved equivalent. The acetate sleeve containing the sample interval will be split in half and samples will be transferred directly from the sleeve to a lab-provided sample jar. For these locations, Trihydro field staff will prepare continuous boring logs of soil samples to the water table, recording lithology and appearance of the boring, and performing field screening of the soil cores using a photoionization detector (PID). An example boring log is shown in Appendix D-2.

2.2.3 Temporary Well Installation

Three proposed temporary wells will be completed in the soil borings installed as described in Section 2.2.2. The locations will be determined based on the analytical results from the groundwater sampling in the existing monitoring wells. Temporary wells will be completed with schedule 40 polyvinyl chloride (PVC). Slotted (0.01 inch) PVC well screen will be placed at the bottom of soil borings completed as a temporary well completion. The screen will extend 10 to 15 ft to ensure that the well is screened across the water table. A 10/20 sand filter pack will be installed to 2 ft above the top of the well screen. The well will be completed to the surface with bentonite chips.

2.3 Phase 3: Groundwater Sampling at Temporary Wells

After temporary well completion, the wells will be left to stand for a minimum of 7 days to allow for the possible entry of SPH into the well, if present. After a minimum of 7 days, the temporary wells will be gauged and sampled using the same methods described in Sections 2.1.1 and 2.1.2.

After groundwater samples are collected from the temporary wells, the PVC casing and well screen will be pulled and all borings will be abandoned with bentonite chips, pellets, or grout, from the bottom of the boring to the ground surface. Bentonite chips or pellets placed above the water table will be hydrated with at least 1 gallon of water per 5 feet of boring.



2.4 Investigation Derived Waste

Investigation derived waste (IDW) will include solid IDW (drill cuttings and excess direct-push soil), liquid phase IDW (purged water), and debris (used acetate liners, nitrile gloves, etc.). IDW will be labeled appropriately to identify the generator, contents, date of generation, and provide contact information.

Solid phase IDW will be stored in a lined roll-off container or in sealed Department of Transportation-rated drums at a location to be determined at the site, pending waste characterization. Solid phase IDW is not expected to be characteristically hazardous but may contain PFAS or volatile organic compounds (VOCs) at concentrations requiring disposal at an appropriately licensed solid waste facility. After all solid phase IDW is accumulated, Trihydro will collect a composite sample for waste characterization. Analytical requirements will depend on the receiving solid waste facility and will be determined prior to disposal. IDW will be transported to the disposal facility by a licensed waste hauler.

Liquid phase IDW will be stored in drums at a location to be determined at the site pending characterization for disposal. Liquid phase IDW is not expected to be characteristically hazardous but may contain PFAS or VOCs at concentrations requiring disposal at an appropriately licensed facility. After all liquid phase IDW is accumulated, Trihydro will collect a composite sample for waste characterization. Analytical requirements will depend on the receiving facility and will be determined prior to disposal. IDW will be transported to the disposal facility by a licensed waste hauler.

Investigation debris will be disposed of as non-hazardous municipal waste at a local landfill.

2.5 Equipment Decontamination

Reusable sampling and drilling equipment will be decontaminated between samples using Alconox or a pressure washer, followed by rinsing with PFAS-free potable water. When not in use, cleaned reusable sample equipment will be stored in HDPE plastic bags or sheeting to minimize the potential for cross-contamination.

PFAS tend to adhere to sampling equipment and have been noted in certain detergents. To the extent practical, disposable equipment will be used for each monitoring/temporary well. Reusable sampling components will be decontaminated, for potential future redeployment in the same well, in accordance with Trihydro's SOP (Attachment A) with the following notes/modifications. Specifically, decontamination will also be required for the interface probe and will be performed between each well to reduce the risk of cross-contamination. Decontamination of the reusable components will consist of three steps:

- 1. Wash in Alconox or Liquinox detergents (Decon 90 is on the prohibited material list and will not be used).
- 2. Triple rinse with distilled water.
- 3. Final triple-rinse with commercially available or laboratory-provided PFAS-free deionized water in an HDPE container.

Received by OCD: 4/16/2024 4:15:20 PM



Western Refining Southwest LLC Gallup Refinery OW-63 PFAS Investigation Work Plan

If necessary, sampling equipment will be scrubbed using a polyethylene (PE) or polyvinyl chloride (PVC) brush to remove particulates prior to completing the decontamination steps listed above.

.



3.0 Analytical Methods

PFAS analysis will be conducted by a laboratory with PFAS-specific experience, using method 537.1 or equivalent that utilizes isotope dilution and is compliant with Quality Systems Manual (QSM) version 5.3 (or later) Table B-15. Promulgated United States Environmental Protection Agency (USEPA) Methods 533 and 537 are both specified as drinking water methods and cannot be applied to the sample matrices collected in this event. There are no promulgated USEPA methods for analyzing PFAS in groundwater (Method 1633 is still in draft form). As such, the analytical results for these media using standardized drinking water methods, or non-standardized laboratory specific methods, must be interpreted with caution. Additional discussion is provided in Appendix B.

The selected laboratory will provide fully documented commercial-type data packages (e.g., equivalent to full USEPA Contract Laboratory Program data packages) for all analytical results and electronic data deliverables (EDDs).



4.0 Quality Assurance And Quality Control

This section addresses the qualitative and quantitative criteria that will be used to evaluate the quality of the field and analytical data collected during the field activities.

4.1 Field Quality Assurance and Quality Control Samples

Five kinds of field quality assurance and quality control samples (QA/QC) will be collected during the sampling event as described below.

- <u>Duplicate Samples</u>. Duplicate samples will be collected to evaluate precision associated with the reproducibility of sampling techniques and the homogeneity of sample matrices. One duplicate sample will be collected per matrix, and at a minimum frequency of 10%, or one for every 10 samples. The duplicate sample will be "blind" to the laboratory; therefore, it will have a coded identity on its label and on the COC. The actual sampling location and identification will be recorded on the sampling log.
- 2. <u>Trip Blanks</u>. Trip blanks are generally not required for PFAS samples but may be helpful to identify sources of contamination, should they occur. A trip blank, comprising PFAS-free water supplied by the laboratory, will accompany each cooler that contains PFAS samples. Experience has shown that cross-contamination at analytical laboratories can lead to spurious PFAS detections. The trip blanks prepared by the laboratory can point to the reagent water used by the laboratory as a source of contamination not related to field sampling procedures.
- 3. <u>Field Blanks</u>. Field blanks will be collected in the vicinity of the project area. Field blanks will be collected by pouring laboratory provided PFAS-free water into the appropriate containers and submitted for PFAS analysis. A field blank will be collected at each separate groundwater well, groundwater, and soil sampling event.
- 4. Equipment Blanks. Equipment blanks will be prepared and submitted for laboratory analysis to assess sampling equipment for potential PFAS impacts and to verify that equipment decontamination procedures are effective. One equipment blank will be collected for groundwater samples from the interface probe to verify that decontamination procedures are effective. Additional equipment blanks will be collected from the trowels to verify that each of the batches received from the manufacturer is PFAS free.
- 5. <u>Matrix Spike/Matrix Spike Duplicates (MS/MSD)</u>. MS/MSDs will be prepared and analyzed by the laboratory for each matrix sampled. The following MS/MSDs will be collected: one from a permanent groundwater well and one from a temporary groundwater well. MS/MSDs are samples in which known quantities of specific PFAS compounds are added before extraction and analyses. The recoveries for spiked compounds can be used to assess how well the method for analysis recovers target compounds.



4.2 Laboratory Assurance and Quality Control Samples

QA/QC samples will be analyzed by the laboratory. The laboratory will follow proper QA/QC procedures, including laboratory blanks, duplicates, and spiked samples for calibration and identification of potential matrix effects. Data from the QC samples are used as a measure of performance and as an indicator of potential sources of cross-contamination. In addition, for PFAS analysis, the laboratory will follow QC procedures compliant with QSM Table B-15 QC. QC data generated by the laboratory are submitted with the results in the fully documented commercial type data packages.

- 1. <u>MS/MSD</u>. MS/MSD will be performed if sufficient sample is recovered and indicated on the COC. If not, lab will perform laboratory control samples (LCS) and laboratory control sample duplicates (LCSD).
- 2. <u>Surrogate Spiking</u>. Surrogate compounds are added before sample preparation for organics to all samples prior to extraction and analysis. The review for surrogate compounds can be used to assess method accuracy for each sample matrix.

4.3 Data Validation

Analytical data received from the laboratory will undergo Trihydro's data validation process. Minimally, data will be evaluated by the Tier I and Tier II data validation process. Trihydro uses the following guidance documents for validation of organic and inorganic data:

- Data for organic analyses are evaluated according to validation criteria set forth in the USEPA Contract Laboratory Program (CLP) National Functional Guidelines for Organic Superfund Methods Data Review, document number EPA-540-R-20-005, November 2020 with additional reference to the USEPA CLP National Functional Guidelines for Organic Data Review, document number EPA 540/R-99/008, October 1999.
- Review of PFAS data will also use criteria set forth in the Department of Defense / Department of Energy QSM for Environmental Laboratories, Version 5.3, 2019. This reference document has specific criteria for review of PFAS data in Appendix C, Table B-15 that are used in conjunction with the National Functional Guidelines.
- Data for inorganic analyses is evaluated according to validation criteria set forth in the USEPA CLP National Functional Guidelines for Inorganic Superfund Methods Data Review, document number EPA-542-R-20-006, November 2020 with additional reference to the USEPA CLP National Functional Guidelines for Inorganic Data Review, document number EPA 540-R-04-004, October 2004.
- Review of field duplicates will be conducted according to the USEPA Region 1 New England Environmental Data Review Supplement for Region 1 Data Review Elements and Superfund Specific Guidance/Procedures, EQADR-Supplement2, September 2020.

Precision, accuracy, method compliance, and completeness of the data packages will be assessed during the data validation process. Precision is determined by evaluating the calculated relative percent difference values



from: laboratory duplicate pairs, MS/MSD pairs, and LCS/LCSD pairs. Laboratory accuracy is established by reviewing the demonstrated percent recoveries of the following items to identify potential biases in the analytical data: MS/MSD samples, LCS/LCSD samples, and organic system monitoring compounds (surrogates). Field accuracy is established by collecting and analyzing field QA/QC samples to monitor for possible ambient or cross-contamination during sampling and transportation. Method compliance is established by reviewing sample integrity, holding times, detection limits, surrogate recoveries, laboratory blanks, initial and continuing calibrations (where applicable), and the LCS/LCSD percent recoveries against method-specific requirements. Completeness is evaluated by determining the overall ratio of the number of samples and analyses planned versus the number of samples with valid analyses. Determination of completeness includes a review of the COC, laboratory analytical methods, and other laboratory and field documents associated with the analytical data set



5.0 Schedule and Reporting

The scheduling of field activities associated with the Work Plan are dependent upon regulatory review and approval. Field coordination will commence upon written approval of the Work Plan by NMED. Trihydro estimates the field portion of the Work Plan will take approximately one to two weeks to complete over several months due to the phased approach. Phase 1 through 3 of the investigation are planned to be completed in 2023, pending written Work Plan approval. Interpretation of results and preparation of documents are planned to be completed in late 2023 or early 2024, pending field investigation.

The final report will include the following:

- 1. A description of the sampling activities performed and deviations from the Work Plan
- 2. A summary table of the analytical results (including QA/QC samples)
- 3. A copy of the COC forms
- 4. A copy of the field sampling logs
- 5. A copy of existing monitoring well construction details and historical survey data for OW-12, OW-14, OW-57, OW-63, and OW-70
- 6. A copy of the site map showing the sampling/monitoring locations
- 7. A copy of laboratory certified analytical results



6.0 References

- Armstrong, M., M.J. Seitz, F. Beetle-Moorcroft, and D.S. Lipson. 2020. No-Purge Groundwater Sampling for PFAS. Groundwater–Vol. 58, No. 6. November-December 2020.
- Brusseau. 2018. Assessing the Potential Contributions of Additional Retention Processes to PFAS Retardation in the Subsurface. Science of the Total Environment 613–614 (2018) pp. 176–185.

Giant Refining Company-Cinzia Refinery. 2001. No Further Action Report, SWMUs 7, 9, 10, 11, 12, 13. Revision 0.0, Volume II pp. 7-1. August.

- Interstate Technology Regulatory Council (ITRC). 2022a. History and Use of Per- and Polyfluoroalkyl Substances (PFAS) Found in the Environment. Updated July 2022. Available from: <u>https://pfas-1.itrcweb.org/wpcontent/uploads/2022/09/HistoryandUse_PFAS_Fact-Sheet_090722_508.pdf</u>.
- ITRC. 2022b. Fate and Transport of Per- and Polyfluoroalkyl Substances (PFAS). July 2022. Available from: <u>https://pfas-1.itrcweb.org/wp-content/uploads/2022/09/FT_PFAS_Fact_Sheet_083122_508.pdf</u>.
- NMED. 2020. Disapproval Annual Groundwater Monitoring Report Gallup Refinery 2019, Western Refining Southwest LLC, Gallup Refinery, McKinley County, Gallup, New Mexico, EPA ID #NMD000333211, HWB-WRG-20-013. November 23.
- NMED. 2022. Approval with Modifications 2021 Annual Groundwater Monitoring Report, Western Refining
- Southwest LLC, Gallup Refinery, McKinley County, Gallup, New Mexico, EPA ID #NMD000333211, HWB-WRG-22-006. October 18.

District I 1625 N. French Dr., Hobbs, NM 88240 Phone: (575) 393-6161 Fax: (575) 393-0720 District II

811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III

1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

District IV

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. Santa Fe, NM 87505

Page 166 of 166

CONDITIONS

Action 334190

CONDITIONS OGRID: Operator: Western Refining Southwest LLC 267595 539 South Main Street Action Number: Findlay, OH 45840 334190 Action Type: [UF-DP] Discharge Permit (DISCHARGE PERMIT)

CONDITIONS

Created By	Condition	Condition Date
joel.stone	Approved for OCD record retention purposes.	7/25/2024