

Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-015-31719
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Yates AS Fee Com
8. Well Number 6
9. OGRID Number 7377
10. Pool name or Wildcat Penasco Draw; Morrow

<p>SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)</p>	
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other	
2. Name of Operator EOG Resources, Inc.	
3. Address of Operator 104 South Fourth Street, Artesia, NM 88210	
4. Well Location Unit Letter <u>K</u> : <u>1550</u> feet from the <u>South</u> line and <u>1600</u> feet from the <u>West</u> line Section <u>25</u> Township <u>18S</u> Range <u>25E</u> NMPM Eddy County	
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3464' GR	

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	P AND A <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPL <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>	
DOWNHOLE COMMINGLE <input type="checkbox"/>		Notify OCD 24 hrs. prior to any work done	
CLOSED-LOOP SYSTEM <input type="checkbox"/>			
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

EOG Resources, Inc. plans to plug and abandon this well as follows:

- MIRU all safety equipment as needed. NU BOP. POOH with production equipment.
- Set a CIBP at 8900' with ~~X~~ sx Class "H" cement on top to 8724'. WOC and tag. This will cover Morrow perfs and top. **Spot 25 sx Cl H Cmt**
- Spot a 25 sx Class "H" cement plug from 8648'-8428'. This will cover Atoka top.
- Spot a 25 sx Class "H" cement plug from 8212'-7992'. This will cover Strawn top.
- Spot a 25 sx Class "H" cement plug from 7660'-7440'. This will cover Canyon top.
- Spot a 25 sx Class "C" cement plug from 5726'-5479'. This will cover Wolfcamp top.
- Spot a 25 sx Class "C" cement plug from 4330'-4083'. This will cover Abo top.
- Spot a 25 sx Class "C" cement plug from 3720'-3473'. This will cover Tubb top.
- Spot a 25 sx Class "C" cement plug from 2117'-1870'. This will cover Glorieta top.
- Perforate at 1264'. Spot a 25 sx Class "C" cement plug from 1264'-1017'. WOC and tag. This will cover casing shoe.
- Spot a 25 sx Class "C" cement plug from 756'-509'. This will cover San Andres top.
- Perforate at 446'. Spot a 25 sx Class "C" cement plug from 446'-199'. WOC and tag. This will cover casing shoe.
- Spot a ~~X~~ sx Class "C" cement plug from ~~X~~ up to surface. Backfill as needed. **Spot 25 sx Cmt 100' to surface**
- Cut off wellhead and install dry hole marker. Clean location as per regulated.

Wellbore schematics attached.

Spud Date:

Rig Release Date:

****SEE ATTACHED COA's****

Must be plugged by 6/11/2022

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tina Huerta TITLE Regulatory Specialist DATE May 20, 2021

Type or print name Tina Huerta E-mail address: tina_huerta@eogresources.com PHONE: 575-748-4168

For State Use Only

APPROVED BY: [Signature] TITLE Staff Manager DATE 6/11/2021

Conditions of Approval (if any):

CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water **will not** be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

Yates AS Fee Com #6 Current

Sec-TWN-RNG: Sec. 25-18S-25E API: 30-015-31719
FOOTAGES: 1550'FSL & 1600'FWL GL: 3464
KB:

CASING DETAIL

#	HOLE SIZE	SIZE	WGHT	GRADE	Top	Bottom	Sx Cnt	Circ/TOC	TOC Method
A	17 1/2	13 3/8	48	H-40	0	396	450	Surface	Circ
B	12 1/4	9 5/8	36	J-55	0	1,214	965	Surface	Circ
C	7 7/8	5 1/2	15.5/17	J55/P110	0	9,200	1310	Surface	Circ

FORMATION TOPS

Formation	Top	Formation	Top
San Andres	706	Canyon	7610
Glorieta	2067	Strawn	8162
Tubb	3670	Atoka	8598
Abo	4280	Morrow	8850
Wolfcamp	5676	Chester	9135

TUBING DETAIL

#	Joints	Description	Length	OD	ID	Grade	Wt (lb/ft)	Top (ftKB)	Btm (ftKB)
		2-7/8" tubing with packer set at 6100'							

Perforation Detail

Formation	Top	Bottom	Treatment
A	Morrow	8,980	9,006
			Acidize w/1000 gals 7.5% MSA

Prepared by: Hiram C

PBTD: 9,198 MD
TD: 9,200 MD

Yates AS Fee Com #6 Proposed

Plug 12: Surface Plug

Plug 11: Casing Shoe

Plug 10: San Andres Top

Plug 9: Casing Shoe

Plug 8: Glorieta Top

Plug 7: Tubb Top

Plug 6: Abo Top

Plug 5: Wolfcamp Top


Plug 4: Canyon Top

Plug 3: Abo Top

Plug 2: Strawn Top

Plug 1: CIBP + Morrow Perfs + Morrow Top

Perf A



Sec-TWN-RNG: Sec. 25-18S-2SE
FOOTAGES: 1550FSL & 1600FWL
API: 30-015-31719
GL: 3464
KB:

CASING DETAIL

#	HOLE SIZE	SIZE	WGHT	GRADE	Top	Bottom	Sx Cmt	Circ/TOC	TOC Method
A	17 1/2	13 3/8	48	H-40	0	396	450	Surface	Circ
B	12 1/4	9 5/8	36	J-55	0	1,214	985	Surface	Circ
C	7 7/8	5 1/2	15.5/17	J55/P-110	0	9,200	1310	Surface	Circ

FORMATION TOPS

Formation	Top	Bottom	Formation	Top
San Andres	706		Canyon	7610
Glorieta	2067		Strawn	8162
Tubb	3670		Abo	8598
Abo	4280		Morrow	8950
Wolfcamp	5676		Chester	9135

Perforation Detail

Formation	Top	Bottom	Treatment
A	Morrow	8,980	9,006
			Acidize w/1000 gals 7.5% MSA

PLUGS

#	Sx	Class	Top	Bottom	Δ	Notes	Tag
1	20	H	8724	8900	176	Morrow Perfs + Morrow Top	Y
2	25	H	8428	8648	220	Abo Top	N
3	25	H	7992	8212	220	Strawn Top	N
4	25	H	7440	7660	220	Canyon Top	N
5	25	C	5479	5726	247	Wolfcamp Top	N
6	25	C	4083	4330	247	Abo Top	N
7	25	C	3473	3720	247	Tubb Top	N
8	25	C	1870	2117	247	Glorieta Top	N
9	25	C	1017	1264	247	Casing Shoe	Y
10	25	C	509	756	247	San Andres Top	N
11	25	C	199	446	247	Casing Shoe	Y
12	6	C	0	50	50	Surface Plug	Y

Prepared by: Hiram C 5/19/21

P8TD: 9,198 MD
TD: 9,200 MD

District I

1625 N. French Dr., Hobbs, NM 88240
Phone:(575) 393-6161 Fax:(575) 393-0720

District II

811 S. First St., Artesia, NM 88210
Phone:(575) 748-1283 Fax:(575) 748-9720

District III

1000 Rio Brazos Rd., Aztec, NM 87410
Phone:(505) 334-6178 Fax:(505) 334-6170

District IV

1220 S. St Francis Dr., Santa Fe, NM 87505
Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

CONDITIONS

Action 29007

CONDITIONS

Operator: EOG RESOURCES INC P.O. Box 2267 Midland, TX 79702	OGRID: 7377
	Action Number: 29007
	Action Type: [C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By	Condition	Condition Date
gcordero	None	6/11/2021